An Oshkosh Corporation Company

Service and Maintenance Manual

Model

800AJ

PVC 2001


31215046

December 26, 2019 - Rev A

ANSI

CE

AS/NZS



MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046

Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1 - SPECIFICATIONS		
1.1	Operating Specifications	1-1
1.2	Capacities	1-1
1.3	Tires	1-1
1.4	Engine Data	1-1
1.5	Component Data	1-2
	Drive System	1-2
	Swing System	1-2
	Auxiliary Power Pump	1-2
1.6	Torque Requirements	1-3
1.7	Hydraulic Oil	1-3
1.8	Major Component Weights	1-4
	Critical Stability Weights	1-4
1.9	Operator Maintenance	1-6
1.10	Threadlocking Compound	1-11
1.11	Torque Charts	1-12
	SAE Fastener Torque Chart	1-12
	Metric Fastener Torque Chart	1-18
SECTION 2 - GENERAL		
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventative Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Reassembly	2-2
	Pressure-Fit Parts	2-2
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage and Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-3
	Battery	2-3
	Lubrication and Servicing	2-3
2.3	Lubrication and Information	2-3
	Hydraulic System	2-3
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4
2.4	Cylinder Drift Test	2-5
	Theory	2-5
	Cylinder Leakage Test	2-5
	Cylinder Thermal Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-6

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
2.6	Welding on JLG Equipment	2-6
	Do the Following When Welding on JLG Equipment	2-6
	Do NOT Do the Following When Welding on JLG Equipment	2-6
SECTION 3 - CHASSIS & TURNTABLE		
3.1	Tires & Wheels	3-1
	Tire Damage	3-1
	Tire Replacement	3-1
	Wheel Replacement	3-1
	Wheel Installation	3-1
3.2	Lockout Cylinder Bleeding	3-2
3.3	Oscillating Axle Lockout Test	3-5
3.4	Chassis Tilt Indicator System	3-8
3.5	Drive Orientation System	3-8
3.6	Transport Position Sensing System	3-8
3.7	Beyond Transport - Drive Speed Cutback System	3-8
3.8	Drive/Steer – Boom Function Interlock System	3-8
3.9	Oscillating Axle System	3-9
3.10	Drive System	3-9
3.11	Drive Hub (Torque)	3-10
	Disassembly	3-10
	Cleaning and Inspection	3-10
	Repair	3-10
	Assembly	3-12
3.12	Drive Brake	3-18
	Disassembly	3-18
	Inspection	3-18
	Assembly	3-18
3.13	Drive Motor	3-20
	Description	3-20
	Shaft Seal Replacement	3-20
	Loop Flushing Valve	3-21
	Troubleshooting	3-22
	Disassembly	3-23
	Inspection	3-27
	Assembly	3-29
	Initial Start-up Procedures	3-34
3.14	Swing Drive	3-36
	Roll, Leak and Brake Testing	3-36
	Tightening and Torquing Bolts	3-37
	Motor Control Valve Disassembly	3-38
	Motor and Brake Disassembly	3-39
	Main Drive Disassembly	3-40
	Hub-Shaft Disassembly	3-41
	Carrier Disassembly	3-42
	Hub-Shaft Assembly	3-43
	Carrier Assembly	3-43
	Main Drive Assembly	3-44
	Motor and Brake Assembly	3-45
	Motor Control Valve Assembly	3-46
3.15	Swing Motor	3-53
	Disassembly and inspection	3-53
	Assembly	3-60
	One Piece Stator Construction	3-68
3.16	Swing Hub Installation	3-69
	Procedure For Setting Swing Gear Backlash	3-69
	Swing Drive Lubrication	3-70
3.17	Swing Hub Removal	3-70

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
3.18	Swing Bearing	3-71
	Turntable Bearing Mounting Bolt Condition Check	3-71
	Wear Tolerance	3-74
	Swing Bearing Replacement	3-74
	Swing Bearing Torque Values	3-75
3.19	Tilt Indicator System	3-77
3.20	Spark Arrester Cleaning Instructions	3-77
3.21	Rotary Coupling	3-78
3.22	Generator	3-84
	Maintenance Schedule	3-84
	Overload Protection	3-84
	Inspecting Brushes, Replacing Brushes, and Cleaning Slip Rings	3-84
	Troubleshooting	3-86
	Generator Disassembly and Assembly	3-87
	Lead Connection List for Generator	3-94
3.23	Auxiliary Power System	3-95
3.24	Deutz Engine	3-96
3.25	Deutz Engine - TD2.9L4	3-117
	Check Oil Level	3-117
	Change Engine Oil	3-117
	Change Oil Filter	3-118
	Change Fuel Filters	3-118
	Replacing the Fuel Pre-Filter	3-119
	Water in Fuel Sensing System (Optional)	3-119
	Draining Water	3-119
	Auxiliary Fuel Filter	3-120
3.26	Deutz Engine - D2011Lo4	3-121
	Glow Plugs	3-121
	Check Oil Level	3-121
	Replacing Engine Oil	3-122
	Replacing the Oil Filter	3-123
	Replacing the Primary Fuel Filter	3-123
3.27	Dual Fuel System	3-124
	Changing from Gasoline to LP Gas	3-124
	Changing from LP Gas to Gasoline	3-124
3.28	Deutz EMR 2	3-124
3.29	Ford Engine	3-186
3.30	Counterweight	3-198

SECTION 4 - BOOM & PLATFORM

4.1	Platform Load Control System	4-1
4.2	Machine Safety System Override (MSSO) (CE only)	4-1
4.3	Platform	4-1
	Platform Valve Removal	4-1
	Platform Valve Installation	4-2
	Platform Support Removal	4-2
	Support Installation	4-3
4.4	Rotator and Platform Level Cylinder	4-6
	Removal	4-6
	Installation	4-6

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >

Fault group	Fault no. (in SERDIA)	Fault locality/ Fault description	SPN	FMI	Cause	Remarks	Help
Zero error display	-	No faults	524287	31	No active faults present		
Revolutions / speed acquisition	01	Speed sensor 1	190	8	Sensor failure. Distance from gear too far. Additional fault impulses. Cable joint interrupted.	Governor in emergency operation (if sensor 2 available). Emergency switch-off (if sensor 2 not available or failed).	Check distance. Check cable connection. Check sensor and replace if required.
						Governor in emergency operation (with sensor 1) Emergency switch-off (if sensor 1 not available or failed).	
	03	Speed sensor	84	8	Tacho failed. Additional fault impulses. Cable connection interrupted.	Governor in emergency operation.	Check cable connection and Tacho. Replace if required.
	04	Excess speed switch-off	190	0	Speed was/is in excess of limit.e.	Engine stop.	Check parameter (21). Check speed settings.
					Check PID setting. Check rods. Check actuator and replace if required. Check cable to actuator (impulse on incorrect speed). Check No. of teeth. For vehicles check for possible thrust mode.		
Sensors	07	Charge air pressure	102	2	Fault at corresponding sensor entry (e.g. short circuit or cable break).	With failure of the sensor, the associated monitoring function is de-activated.	Check sensor cable. Check sensor and replace if required. Check fault limits for sensor.
	08	Oil pressure	100	2			
	09	Coolant temperature	110	2			
	10	Charge air temperature	105	2			
	11	Fuel temperature	174	2			

NOTE: SID is equal to 512. To get SPN #, add 512 + number. For example, SID 254 would be 512+254 or an SPN of 766.

Figure 3-102. EMR2 Fault Codes - Sheet 1 of 5

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046


Order the manual at mid-west-tech.com >

Pressing the ESC key [ESC] after starting calibration and before calibration is complete will display the CAL FAILED message. This will not disturb the prior calibration information.

7. Press ENTER [ENTER]. The analyzer screen will read:



8. If the platform is empty, press ENTER [ENTER]. The screen will read:



NOTE: *Accessory weight will reset to 0 lb each time the machine is re-calibrated and will need to be re-entered.*

NOTE: *The Accessory weight will be temporarily stored in the Control System until calibration has been completed successfully.*

Refer to Table 6-8, Accessory Weights. Use the up and down analyzer keys to enter the accessory weight(s) (in lbs). When all the accessory weights are entered, press ENTER [ENTER]. The screen will read:



Table 6-8. Accessory Weights

Accessory	Weight
SkyWelder (stick welder)	70 lb (32 kg)
SkyWelder Prep	Prepony = 15 lb (7 kg) Full install = 70 lb (32 kg)
SkyCutter (plasma cutter)	70 lb (32 kg)
SkCutter / SkyWelder Combo	140 lb (64 kg)
Fire Extinguisher	45 lb (20 kg)
Overhead Soft Touch	80 lb (36 kg)
Work Surface	20 lb (9 kg)

NOTE: *Not all Accessories are available on every JLG model. Some Accessory combinations are prohibited due to excessive weight and/or load restriction. If any installed JLG Accessories are labeled with weight decals but are not listed in the table above, include their weight when entering the ACC WEIGHT value.*

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >




Figure 7-23. Electrical Schematic - Sheet 3 of 17


MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >


5. Install the pin into the center hole, then slide the washer over the pin. Install the snap ring into the groove in the pin.






NOTE: *When installing snap rings make sure they are seated in the pin groove and closed properly.*





MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >

Table 5-10. Bulkhead Fittings (BH) - INCH



TYPE/FITTING IDENTIFICATION				FASTENING JAM NUT for Bulkhead Connectors					
				Torque					
				[Ft-Lb]			[N-m]		
MATERIAL	TYPE	Dash Size	Thread Size (UNF)	Min	Nom	Max	Min	Nom	Max
STEEL FITTINGS	O-RING FACE SEAL (ORFS) BULKHEAD FITTING	4	9/16-18	15	16	17	20	22	23
		6	11/16-16	25	27	28	34	37	38
		8	13/16-16	55	58	61	75	79	83
		10	1-14	85	90	94	115	122	127
		12	13/16-12	135	142	149	183	193	202
		14	15/16-12	170	179	187	230	243	254
		16	17/16-12	200	210	220	271	285	298
		20	1 11/16-12	245	258	270	332	350	366
		24	2-12	270	284	297	366	385	403
	TYPE	Dash Size	Thread Size (UNF)	Torque [Ft-Lb] Min	Nom	Max	Torque [N-m] Min	Nom	Max
	37° FLARE (JIC) BULKHEAD FITTING	3	3/8-24	8	9	9	11	12	12
		4	7/16-20	13	14	14	18	19	19
		5	1/2-20	20	21	22	27	28	30
		6	9/16-18	25	27	28	34	37	38
		8	3/4-16	50	53	55	68	72	75
		10	7/8-14	85	90	94	115	122	127
		12	1 1/16-12	135	142	149	183	193	202
		14	1 3/16-12	170	179	187	230	243	254
		16	1 5/16-12	200	210	220	271	285	298
		20	1 5/8-12	245	258	270	332	350	366
		24	1 7/8-12	270	284	297	366	385	403
		32	2 1/2-12	310	326	341	420	442	462

MidWestTech | JLG 800AJ Boom Lift Service Manual | Publication 31215046 Order the manual at mid-west-tech.com >