Illustrated Parts Manual

Models
E400An/
E400AJP/
E400AJPn/
M400AJP/
M400AJPn

SN 0300189901
through 0300208528
P/N
3121646

November 16, 2018 - Rev G

ANSI

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 13

FIGURE 1-1. STEERING INSTALLATION - E400AJP/M400AJP 14
FIGURE 1-2. STEERING INSTALLATION - E400AN/E400AJPN/M400AJPN 16
FIGURE 1-3. HUB - SPINDLE ASSEMBLY - RH 18
FIGURE 1-4. HUB - SPINDLE ASSEMBLY - LH - E400AJP/M400AJP 20
FIGURE 1-5. HUB - SPINDLE ASSEMBLY - RH - E400AN/E400AJPN/M400AJPN 22
FIGURE 1-6. HUB - SPINDLE ASSEMBLY - LH - E400AN/E400AJPN/M400AJPN 24
FIGURE 1-7. WHEEL DRIVE - E400AN - E400AJP/E400AJPN 26
FIGURE 1-8. WHEEL DRIVE - E400AN/E400AJP/E400AJPN - UL LISTED 30
FIGURE 1-9. WHEEL DRIVE - M400AJP/M400AJPN 34
FIGURE 1-10. HUB - DRIVE ASSEMBLY 38
FIGURE 1-11. DRIVE MOTOR ASSEMBLY 42
FIGURE 1-12. TIRE/WHEEL - IN240/55-17.5 PNEUMATIC 44
FIGURE 1-13. TIRE/WHEEL - IN240/55 - 17.5 FOAM FILL 46
FIGURE 1-14. TIRE/WHEEL - SOLID NON-MARKING 48
FIGURE 1-15. TIRE/WHEEL - 26 X 7 X 20 - SOLID NON MARKING 50
FIGURE 1-16. TIRE/WHEEL - IN240/55-17.5 PNEUMATIC NON MARKING 52
FIGURE 1-17. TIRE/WHEEL - IN240/55-17.5 FOAM FILL NON MARKING 54
FIGURE 1-18. TIRE/WHEEL - IN240/55-17.5 PNEUMATIC TS 56
FIGURE 1-19. WHEEL COVER INSTALLATION - IN240/55-17.5 TIRES ONLY 58
FIGURE 1-20. MOTOR/PUMP/TANK - E400AN/E400AJP/E400AJPN 60
FIGURE 1-21. MOTOR/PUMP/TANK - M400AJP 62
FIGURE 1-22. MOTOR/PUMP/TANK - E400AN/E400AJP/E400AJPN - UL LISTED 64
FIGURE 1-23. MOTOR/PUMP/TANK - M400AJPN 66
FIGURE 1-24. MOTOR/PUMP ASSEMBLY 68
FIGURE 1-25. HYDRAULIC TANK ASSEMBLY - E400AN/E400AJP/E400AJPN 70
FIGURE 1-26. HYDRAULIC TANK ASSEMBLY - M400AJP/M400AJPN 72
FIGURE 1-27. VALVE INSTALLATION - FRAME MOUNTED - E400AN 74
FIGURE 1-28. VALVE INSTALLATION - FRAME MOUNTED - E400AJP/E400AJPN 76
FIGURE 1-29. VALVE INSTALLATION - FRAME MOUNTED - M400AJP/M400AJPN 78
FIGURE 1-30. BRAKE/STEER VALVE ASSEMBLY 80
FIGURE 1-31. BATTERY BOX INSTALLATION 82
FIGURE 1-32. BATTERY BOX INSTALLATION - AGM BATTERIES 84
FIGURE 1-33. BATTERY BOX INSTALLATION - CE AND AUSTRALIAN SPECS 86
FIGURE 1-34. BATTERY BOX INSTALLATION - AGM BATTERIES (CE AND AUSTRALIAN SPECS) 88
FIGURE 1-35. BATTERY CHARGER INSTALLATION - E400AN/E400AJP/E400AJPN (ALL SPECS EXCEPT CE AND AUSTRALIAN SPECS) 90
FIGURE 1-36. BATTERY CHARGER INSTALLATION - E400AJP/E400AJPN (AUSTRALIAN SPEC) 92
FIGURE 1-37. BATTERY CHARGER INSTALLATION - E400AN/E400AJP/E400AJPN (ANSI EXPORT AND CE SPECS) 94
FIGURE 1-38. BATTERY CHARGER INSTALLATION - M400AJP (ALL SPECS EXCEPTED CE, AUSTRALIAN AND UL SPECS) 96
FIGURE 1-39. BATTERY CHARGER INSTALLATION - M400AJP (AUSTRALIAN SPEC) 98
FIGURE 1-40. BATTERY CHARGER INSTALLATION - M400AJP (ANSI EXPORT AND CE SPECS) 100
FIGURE 1-41. BATTERY CHARGER INSTALLATION - M400AJPN 102
FIGURE 1-42. BATTERY CHARGER INSTALLATION - M400AJPN (AUSTRALIAN SPEC) 104
FIGURE 1-43. BATTERY CHARGER INSTALLATION - M400AJPN (ANSI EXPORT AND CE SPECS) 106
FIGURE 1-44. INVERTER INSTALLATION - E400AJP/M400AJP 108
FIGURE 1-45. INVERTER INSTALLATION - E400AN/E400AJPN/M400AJPN 110
FIGURE 1-46. FRAME COVER INSTALLATION - E400AJP 112
FIGURE 1-47. FRAME COVER INSTALLATION - M400AJP 114
FIGURE 1-48. FRAME COVER INSTALLATION - E400AN/E400AJPN 116
FIGURE 1-49. FRAME COVER INSTALLATION - M400AJPN 118

SECTION 2 - TURNTABLE 121

FIGURE 2-1. VALVE INSTALLATION - TURNTABLE MOUNTED - E400AN 122
FIGURE 2-2. VALVE INSTALLATION - TURNTABLE MOUNTED - E400AJP/E400AJPN 124
FIGURE 2-3. VALVE INSTALLATION - TURNTABLE MOUNTED - M400AJP/M400AJPN 126
FIGURE 2-4. MAIN CONTROL VALVE ASSEMBLY 128
FIGURE 2-5. RELEVELING VALVE ASSEMBLY 132
FIGURE 2-6. JIB VALVE ASSEMBLY 134
FIGURE 2-7. MOTION ALARM INSTALLATION 136
FIGURE 2-8. TURNTABLE BEARING AND SWING DRIVE INSTALLATION 138
FIGURE 2-9. SWING BEARING ASSEMBLY 140
FIGURE 2-10. SWING MOTOR ASSEMBLY 142

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-11. REMOTE BEARING LUBE INSTALLATION - OPTIONAL 144
FIGURE 2-12. DRIVE ORIENTATION INSTALLATION 146
FIGURE 2-13. FUEL TANK AND BATTERY INSTALLATION - M400AJP/M400AJPN 148
FIGURE 2-14. GROUND CONTROL BOX ASSEMBLY - E400A & E400AN - ALL SPECS EXCEPT CE SPEC 150
FIGURE 2-15. GROUND CONTROL BOX ASSEMBLY – E400A & E400AN – CE SPEC (Prior to SN 0300200792) 152
FIGURE 2-16. GROUND CONTROL BOX ASSEMBLY - E400A - CE SPEC (SN 0300200792 through 0300208528) 154
FIGURE 2-17. GROUND CONTROL BOX ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN - ALL SPECS EXCEPT CE SPEC 156
FIGURE 2-18. GROUND CONTROL BOX ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN - CE SPEC (Prior to SN 0300200792) 158
FIGURE 2-19. GROUND CONTROL BOX ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN - CE SPEC (SN 0300200792 through 0300208528) 160
FIGURE 2-20. MOTOR CONTROLS INSTALLATION - M400AJP/M400AJPN 162
FIGURE 2-21. STROBE LIGHT INSTALLATION (AMBER) - OPTIONAL 164
FIGURE 2-22. STROBE LIGHT INSTALLATION - UL LISTED - OPTIONAL 166
FIGURE 2-23. STROBE LIGHT ASSEMBLY (AMBER) 168
FIGURE 2-24. HOOD INSTALLATION - E400AN 170
FIGURE 2-25. HOOD INSTALLATION - E400AJP/E400AJPN/M400AJP/M400AJPN 172
FIGURE 2-26. BEACON LIGHT INSTALLATION - BLUE (SN 0300200116 through 0300208528) 174

SECTION 3 - ENGINE 177

FIGURE 3-1. KUBOTA MOTOR/GENERATOR INSTALLATION - M400AJP/M400AJPN 178
FIGURE 3-2. KUBOTA MOTOR/GENERATOR ASSEMBLY - M400AJP/M400AJPN 180
FIGURE 3-3. KUBOTA MOTOR/GENERATOR COMPONENTS 182

SECTION 4 - BOOM 185

FIGURE 4-1. BOOM AND CYLINDERS INSTALLATION - E400AN 186
FIGURE 4-2. BOOM AND CYLINDERS INSTALLATION - E400AJP/E400AJPN/M400AJP/M400AJPN 188
FIGURE 4-3. MAIN BOOM ASSEMBLY - E400AN 192
FIGURE 4-4. MAIN BOOM ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN 196
FIGURE 4-5. JIB INSTALLATION 198
FIGURE 4-6. ROTATOR ASSEMBLY - E400AN 200
FIGURE 4-7. ROTATOR ASSEMBLY - PLATFORM SUPPORT TO JIB - E400AJP/E400AJPN/M400AJP/M400AJPN 202
FIGURE 4-8. ROTATOR ASSEMBLY - MAIN BOOM TO JIB - E400AJP/E400AJPN/M400AJP/M400AJPN 204
FIGURE 4-9. PLATFORM SUPPORT WITHOUT LOAD SENSING 206
FIGURE 4-10. PLATFORM SUPPORT INSTALLATION - WITH LSS - E400AJP/M400AJP/E400AJPN/M400AJPN 208
FIGURE 4-11. PLATFORM SUPPORT INSTALLATION - WITH LSS - E400AN 212
FIGURE 4-12. CABLES AND CLAMPS INSTALLATION - E400AN 216
FIGURE 4-13. CABLES AND CLAMPS INSTALLATION - E400AJP/E400AJPN/M400AJP/M400AJPN 218
FIGURE 4-14. LIMIT SWITCHES INSTALLATION 220

SECTION 5 - PLATFORM 223

FIGURE 5-1. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY (SN 0300189901 through 0300200791) 224
FIGURE 5-2. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY (SN 0300200792 through 0300208528) 226
FIGURE 5-3. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY (SN 0300189901 through 0300200791) 228
FIGURE 5-4. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY (SN 0300200792 through 0300208528) 230
FIGURE 5-5. PLATFORM ASSEMBLY - 5FT/1.52M - WITH STOP (SN 0300189901 through 0300200791) 232
FIGURE 5-6. PLATFORM ASSEMBLY - 6FT/1.83M - SIDE GATE ENTRY (SN 0300200792 through 0300208528) 234
FIGURE 5-7. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY (SN 0300189901 through 0300200791) 236
FIGURE 5-8. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY (SN 0300200792 through 0300208528) 238
FIGURE 5-9. PLATFORM ASSEMBLY - 5FT/1.52M - DROP BAR ENTRY (SN 0300189901 through 0300200791) 240
FIGURE 5-10. PLATFORM ASSEMBLY - 5FT/1.52M - DROP BAR ENTRY (SN 0300200792 through 0300208528) 242
FIGURE 5-11. TRAY ASSEMBLY 244
FIGURE 5-12. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E400AN 246
FIGURE 5-13. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E400AN -UL LISTED 248
FIGURE 5-14. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - WITH SKYGUARD (SN 0300200792 through 0300208528) 250
FIGURE 5-15. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION – E400AN WITH SKYGUARD (SN 0300200792 through 0300208528) 252
FIGURE 5-16. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E400AJP/E400AJPN/M400AJP/M400AJPN 254
FIGURE 5-17. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E400AJP/E400AJPN/M400AJP/E400AJPN - UL LISTED 256
FIGURE 5-18. PLATFORM CONSOLE ASSEMBLY - E400AN (SN 0300189901 through 0300194237) 258
FIGURE 5-19. PLATFORM CONSOLE ASSEMBLY - E400AN (SN 0300194238 through 0300208528) 262

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >

FIGURE 5-20. PLATFORM CONSOLE ASSEMBLY - UL LISTED - E400AN (SN 0300189901 through 0300194237) 266
FIGURE 5-21. PLATFORM CONSOLE ASSEMBLY - E400AN - UL LISTED (SN 0300194238 through 0300208528) 270
FIGURE 5-22. PLATFORM CONSOLE ASSEMBLY - E400AN (SN 0300189901 through 0300194237) 274
FIGURE 5-23. PLATFORM CONSOLE ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN (SN 0300194238 through 0300208528) 278
FIGURE 5-24. PLATFORM CONSOLE ASSEMBLY - E400AN - UL LISTED (SN 0300189901 through 0300194237) 282
FIGURE 5-25. PLATFORM CONSOLE ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN - UL LISTED (SN 0300194238 through 0300208528) 286
FIGURE 5-26. PLATFORM CONSOLE ASSEMBLY - WITH SKYGUARD (SN 0300200792 through 0300208528) 290
FIGURE 5-27. PLATFORM CONSOLE ASSEMBLY - WITH SKYGUARD – E400AN (SN 0300200792 through 0300208528) 294
FIGURE 5-28. LIGHT PANEL DECAL INSTALLATION 298
FIGURE 5-29. SEALED ENCLOSURES - UL LISTED 300
FIGURE 5-30. CONTROLLER ASSEMBLY - DRIVE AND STEER (SN 0300189901 through 0300194237) 302
FIGURE 5-31. CONTROLLER ASSEMBLY - DRIVE AND STEER (SN 0300194238 through 0300208528) 304
FIGURE 5-32. CONTROLLER ASSEMBLY - LIFT AND SWING (SN 0300189901 through 0300194237) 306
FIGURE 5-33. CONTROLLER ASSEMBLY - LIFT AND SWING (SN 0300194238 through 0300208528) 308
FIGURE 5-34. FOOTSWITCH ASSEMBLY 312
FIGURE 5-35. MOTOR CONTROLS INSTALLATION - M400AJP/M400AJPN 314
FIGURE 5-36. CROSS RAIL INSTALLATION 316
FIGURE 5-37. PIPE RACK INSTALLATION 318

SECTION 6 - CYLINDER 321

FIGURE 6-1. JIB CYLINDER ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN 322
FIGURE 6-2. LIFT CYLINDER ASSEMBLY - LOWER - E400AN (ORIGINAL EQUIPMENT) 324
FIGURE 6-3. LIFT CYLINDER ASSEMBLY - LOWER - E400AN (SERVICE REPLACEMENT) 326
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - LOWER - E400AJP/E400AJPN/M400AJP/M400AJPN (ORIGINAL EQUIPMENT) 328
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - LOWER - E400AJP/E400AJPN/M400AJP/M400AJPN (SERVICE REPLACEMENT) 330
FIGURE 6-6. LIFT CYLINDER ASSEMBLY - MID - E400AN (ORIGINAL EQUIPMENT) 332
FIGURE 6-7. LIFT CYLINDER ASSEMBLY - MID - E400AN (SERVICE REPLACEMENT) 334
FIGURE 6-8. LIFT CYLINDER ASSEMBLY - MID - E400AJP/E400AJPN/M400AJP/M400AJPN (ORIGINAL EQUIPMENT) 336
FIGURE 6-9. LIFT CYLINDER ASSEMBLY - MID - E400AJP/E400AJPN/M400AJP/M400AJPN (SERVICE REPLACEMENT) 338
FIGURE 6-10. LIFT CYLINDER - UPPER - E400AN (ORIGINAL EQUIPMENT) 340
FIGURE 6-11. LIFT CYLINDER - UPPER - E400AN (SERVICE REPLACEMENT) 342
FIGURE 6-12. LIFT CYLINDER - UPPER - E400AJP/E400AJPN/M400AJP/M400AJPN (ORIGINAL EQUIPMENT) 344
FIGURE 6-13. LIFT CYLINDER - UPPER - E400AJP/E400AJPN/M400AJP/M400AJPN (SERVICE REPLACEMENT) 346
FIGURE 6-14. MASTER CYLINDER ASSEMBLY - E400AN 348
FIGURE 6-15. MASTER CYLINDER ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN 350
FIGURE 6-16. PLATFORM LEVEL CYLINDER - E400AN 352
FIGURE 6-17. PLATFORM LEVEL CYLINDER - JIB - E400AJP/E400AJPN/M400AJP/M400AJPN 354
FIGURE 6-18. STEER CYLINDER ASSEMBLY 356
FIGURE 6-19. TELESCOPE CYLINDER ASSEMBLY - E400AN 358
FIGURE 6-20. TELESCOPE CYLINDER ASSEMBLY - E400AN (SERVICE REPLACEMENT) 360
FIGURE 6-21. TELESCOPE CYLINDER ASSEMBLY - E400AN (SERVICE REPLACEMENT) 362
FIGURE 6-22. TELESCOPE CYLINDER ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN 364
FIGURE 6-23. TELESCOPE CYLINDER ASSEMBLY - E400AJP/E400AJPN/M400AJP/M400AJPN (SERVICE REPLACEMENT) 366
FIGURE 6-24. COUNTERBALANCE VALVE ASSEMBLY 368

SECTION 7 - HYDRAULIC 371

FIGURE 7-1. HYDRAULIC DIAGRAM - E400AN 372
FIGURE 7-2. HYDRAULIC DIAGRAM - E400AJP/E400AJPN 376
FIGURE 7-3. HYDRAULIC DIAGRAM - M400AJP/M400AJPN 380
FIGURE 7-4. HYDRAULIC DIAGRAM LIST 384

SECTION 8 - ELECTRICAL 385

FIGURE 8-1. ELECTRICAL DIAGRAM LIST 386
FIGURE 8-2. BATTERY CHARGER HARNESS 388
FIGURE 8-3. BEACON LIGHT HARNESS (BLUE BEACON ONLY) 390
FIGURE 8-4. CONTACTOR CABLE KIT - E400AN/E400AJP/E400AJPN 392
FIGURE 8-5. CONTACTOR CABLE KIT - E400AN/E400AJP/E400AJPN - UL LISTED 394
FIGURE 8-6. CONTACTOR CABLE KIT - M400AJP - M400AJPN 396
FIGURE 8-7. CONTACTOR PLATE ASSEMBLY AND HARNESSES 398

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
20	7012540	1	Seal Kit - 7012975 Cartridge	
21	70000381	1	Cartridge, Plug	
22	7017406	4	Plug (Not Shown)	

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
101	2920151	1	Light (Located on Ground Control Box)	
102	4460226	2	Socket, Female	
103	4460424	1	Connector - 2 Position	
104	4922926	1	Harness, Indicator Lamp (Not Shown - Located at Ground Control Box)	
104	4460320	1	Plug, Male - 2 Position	
104	4460227	2	Pin, Male	
104	4460042	1	Terminal, Ring	
104	4460313	1	Terminal, Ring	
104	4460265	1	Connector - 9 Position	
104	4460226	3	Socket, Female	

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >

FIGURE 8-1. ELECTRICAL DIAGRAM LIST

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	Note: For information, refer to Service Manual or contact JLG Customer Service Department.	
	1870227	Ref	ELECTRICAL SCHEMATIC	
		Ref	GROUND CONTROL BOX WIRING DIAGRAM Options:	
	4933388		GROUND CONTROL BOX WIRING DIAGRAM (**Prior to SN 0300200792**)	
	1001189765		GROUND CONTROL BOX WIRING (**SN 0300200792 through 0300208528**)	
	1001190300	Ref	BATTERY CHARGER INDICATOR HARNESS - CE SPEC	
	4933060	Ref	PLATFORM ELECTRICAL DIAGRAM - E400An	
	4933181	Ref	PLATFORM ELECTRICAL DIAGRAM - E400An - UL LISTED	
	4933105	Ref	PLATFORM ELECTRICAL DIAGRAM - E400AJP/E400AJPn/M400AJP/M400AJPn	
	4933182	Ref	PLATFORM ELECTRICAL DIAGRAM - E400AJP/E400AJPn/M400AJP/M400AJPn - UL LISTED	
	1870227	Ref	ELECTRICAL SCHEMATIC	
	1001189074	Ref	SKYGUARD HARNESS	
	1001189076	Ref	SKYGUARD CAN HARNESS	
	1001149563	Ref	SKYGUARD SENSOR WIRING DIAGRAM	

MidWestTech | JLG E400AJP, E400AJP narrow, E400A narrow, M400AJP, M400AJP narro... Order the manual at mid-west-tech.com >