Illustrated Parts Manual

Model
400SC
460SJC

SN 0300000100 to SN 0300272447
excluding 0300270239

P/N
3121706

April 6, 2020 - Rev N

ANSI

CE

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 13

FIGURE 1-1. FRAME UNDERCARRIAGE WITH CARRIER TRACKS 14
FIGURE 1-2. UNDERCARRIAGE ASSEMBLY 16
FIGURE 1-3. TRACK ASSEMBLY - RUBBER (BRIDGESTONE POLAND) 18
FIGURE 1-4. FRAME UNDERCARRIAGE WITH EXCAVATOR TRACKS 20
FIGURE 1-5. TRACK ASSEMBLY - RUBBER (BRIDGESTONE JAPAN) 22
FIGURE 1-6. FRAME UNDERCARRIAGE WITH NON-MARKING TRACKS 24
FIGURE 1-7. TRACK ASSEMBLY - RUBBER 26
FIGURE 1-8. FRAME UNDERCARRIAGE WITH STEEL TRACKS 28
FIGURE 1-9. TRACK ASSEMBLY - STEEL 30
FIGURE 1-10. FRAME UNDERCARRIAGE STEEL TRACKS WITH PADS 32
FIGURE 1-11. IDLER ASSEMBLY 34
FIGURE 1-12. DRIVE HUB ASSEMBLY 36
FIGURE 1-13. DRIVE MOTOR ASSEMBLY 38

SECTION 2 - TURNTABLE 41

FIGURE 2-1. CONTROL VALVES INSTALLATION - 400SC 42
FIGURE 2-2. CONTROL VALVES INSTALLATION - 460SJC 44
FIGURE 2-3. MAIN VALVE ASSEMBLY - 400SC 46
FIGURE 2-4. MAIN VALVE ASSEMBLY - 460SJC 50
FIGURE 2-5. 2 SPEED/BRAKE RELEASE VALVE ASSEMBLY 54
FIGURE 2-6. SWING DRIVE INSTALLATION (SN 0300000100 through 0300249939) 56
FIGURE 2-7. SWING DRIVE INSTALLATION (SN 0300249939 through 0300272447) 58
FIGURE 2-8. SWING HUB/MOTOR ASSEMBLY (SN 0300000100 through 0300249939) 60
FIGURE 2-9. SWING HUB/MOTOR ASSEMBLY (SN 0300249939 through 0300272447) 64
FIGURE 2-10. TURNTABLE BEARING INSTALLATION (WITHOUT TURNTABLE BEARING SPACER) 68
FIGURE 2-11. TURNTABLE BEARING INSTALLATION (WITH TURNTABLE BEARING SPACER) 70
FIGURE 2-12. BEARING LUBE INSTALLATION 72
FIGURE 2-13. TURNTABLE LOCK INSTALLATION 74
FIGURE 2-14. ROTARY COUPLING INSTALLATION (WITHOUT TURNTABLE BEARING SPACER) 76
FIGURE 2-15. ROTARY COUPLING INSTALLATION (WITH TURNTABLE BEARING SPACER) 78
FIGURE 2-16. TANKS INSTALLATION 80
FIGURE 2-17. AUXILIARY PUMP AND BATTERY INSTALLATION (WITHOUT DISCONNECT) 82
FIGURE 2-18. AUXILIARY PUMP AND BATTERY INSTALLATION (WITH DISCONNECT) (SN 0300259635 through 0300272447) 84
FIGURE 2-19. AUXILIARY PUMP ASSEMBLY 86
FIGURE 2-20. ELECTRICAL INSTALLATION - 400SC (SN 0300000100 through 0300259635) 88
FIGURE 2-21. ELECTRICAL INSTALLATION - 400SC (SN 0300259635 through 0300272447) 90
FIGURE 2-22. ELECTRICAL INSTALLATION - 460SJC 92
FIGURE 2-23. TURNTABLE COVERS INSTALLATION (SN 0300227267 through 0300272447) 94
FIGURE 2-24. GROUND CONTROL ASSEMBLY - 400SC (ANSI AND CSA SPECS) (SN 0300259635 through 0300272447) 96
FIGURE 2-25. ELECTRICAL PANEL ASSEMBLY 98
FIGURE 2-26. GROUND CONTROL ASSEMBLY 100
FIGURE 2-27. GROUND CONTROL DECAL AND KEY SWITCH INSTALLATION - 400SC (CE SPECS) 102
FIGURE 2-28. GROUND CONTROL DECAL AND KEY SWITCH INSTALLATION - 400SC (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 104
FIGURE 2-29. GROUND CONTROL DECAL AND KEY SWITCH INSTALLATION - 460SJC (CE SPECS) 106
FIGURE 2-30. GROUND CONTROL DECAL AND KEY SWITCH INSTALLATION - 460SJC (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 108
FIGURE 2-31. BEACON LIGHT INSTALLATION - AMBER 110
FIGURE 2-32. BEACON LIGHT INSTALLATION - BLUE (SN 0300000100 through 0300217319) 112
FIGURE 2-33. BEACON LIGHT INSTALLATION - BLUE (SN 0300217319 through 0300259634) 114
FIGURE 2-34. BEACON LIGHT INSTALLATION - BLUE (SN 0300259635 through 0300272447) 116
FIGURE 2-35. BEACON LIGHT INSTALLATION - RED (SN 0300000100 through 0300217319) 118
FIGURE 2-36. BEACON LIGHT INSTALLATION - RED (SN 0300217319 through 0300259634) 120
FIGURE 2-37. BEACON LIGHT INSTALLATION - RED (SN 0300259635 through 0300272447) 122
FIGURE 2-38. HOOD INSTALLATION 124
FIGURE 2-39. HOOD ASSEMBLY - ENGINE SIDE 128
FIGURE 2-40. HOOD ASSEMBLY - TANK SIDE 130
FIGURE 2-41. STEEL HOOD INSTALLATION (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 132
FIGURE 2-42. STEEL HOOD ASSEMBLY - ENGINE SIDE (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 136
FIGURE 2-43. STEEL HOOD ASSEMBLY - TANK SIDE (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 138
FIGURE 2-44. SOUND REDUCTION INSTALLATION - WITH STEEL HOODS (OPTIONAL) 140

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 3 - ENGINE 143

FIGURE 3-1. ENGINE INSTALLATION (DEUTZ 2011L03) (T4I) (CE SPECS) 144
FIGURE 3-2. ENGINE AND PUMP SUB-ASSEMBLY (DEUTZ 2011L03) (T4I) (CE SPECS) 148
FIGURE 3-3. ENGINE ASSEMBLY (DEUTZ 2011L03) (T4I) (CE SPECS) 150
FIGURE 3-4. ENGINE COMPONENTS - DEUTZ D2.3L3 (CE SPECS) 154
FIGURE 3-5. ENGINE INSTALLATION - DEUTZ D2.9L4 (T4F) (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (SN 0300234013 through 0300272447) 158
FIGURE 3-6. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 (T4F) (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (SN 0300234013 through 0300272447) 164
FIGURE 3-7. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (T4F) (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (SN 0300234013 through 0300272447) 166
FIGURE 3-8. ENGINE INSTALLATION - DEUTZ D2.3L3 (T4I) (WITH ARCTIC PACKAGE) (ANSI EXPORT SPECS) (SN 0300234013 through 0300272447) 172
FIGURE 3-9. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.3L3 (T4I) (WITH ARCTIC PACKAGE) (ANSI EXPORT SPECS) (SN 0300234013 through 0300272447) 178
FIGURE 3-10. ENGINE ASSEMBLY - DEUTZ D2.3L3 ENGINE (T4I) (WITH ARCTIC PACKAGE) (ANSI EXPORT SPEC) (SN 0300234013 through 0300272447) 180
FIGURE 3-11. ENGINE INSTALLATION (DEUTZ D2.9L) (T4F) (ANSI, CSA AND ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 184
FIGURE 3-12. ENGINE AND PUMP SUB-ASSEMBLY (DEUTZ D2.9L) (T4F) (ANSI, CSA AND ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 190
FIGURE 3-13. ENGINE ASSEMBLY - (DEUTZ D2.9L) (T4F) (ANSI, CSA AND ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 192
FIGURE 3-14. BREATHER HEATER INSTALLATION - DEUTZ D2.9L4 ENGINE WITH ARCTIC PACKAGE 198
FIGURE 3-15. ENGINE COMPONENTS - (DEUTZ D2.9L) (T4F) (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 200
FIGURE 3-16. ENGINE INSTALLATION - DEUTZ T4I ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 204
FIGURE 3-17. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ T4I (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 208
FIGURE 3-18. ENGINE ASSEMBLY - DEUTZ T4I ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 210
FIGURE 3-19. ENGINE COMPONENTS - DEUTZ D2011 (STAGE V) (SN 0300000100 through 0300255433) 214
FIGURE 3-20. PUMP COUPLING KIT 218
FIGURE 3-21. PISTON PUMP ASSEMBLY (FRONT) 220
FIGURE 3-22. PISTON PUMP ASSEMBLY (REAR) 224
FIGURE 3-23. GEAR PUMP ASSEMBLY 228
FIGURE 3-24. CATALYTIC SPARK ARRESTOR INSTALLATION - ANSI EXPORT AND CE SPECS 230
FIGURE 3-25. SPARK ARRESTOR INSTALLATION - ANSI AND ANSI EXPORT SPECS (SN 0300234013 through 0300272447) 232
FIGURE 3-26. SPARK ARRESTOR INSTALLATION - ANSI EXPORT AND CE SPECS 234
FIGURE 3-27. ENGINE BAFFLE INSTALLATION 236
FIGURE 3-28. ENGINE BAFFLE INSTALLATION - STEEL (SN 0300227267 through 0300272447) 238
FIGURE 3-29. ENGINE TRAY JACK 240
FIGURE 3-30. OIL COOLER INSTALLATION (CE SPECS) 242
FIGURE 3-31. OIL COOLER INSTALLATION (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 244
FIGURE 3-32. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT SEPC) (SN 0300234013 through 0300272447) 246
FIGURE 3-33. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2.9L4 ENGINE) (ANSI, ANSI EXPORT AND CSA SPECS) (SN 0300224020 through 0300272447) 250
FIGURE 3-34. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT AND CE SPECS) (SN 0300000100 through 0300237337) 254
FIGURE 3-35. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT AND CE SPECS) (SN 0300237337 through 0300272447) 258
FIGURE 3-36. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2.9L4 ENGINE) (ANSI, ANSI EXPORT AND CSA SPECS) (SN 0300224020 through 0300272447) 262
FIGURE 3-37. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT AND CE SPECS) 266
FIGURE 3-38. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2.9L4) (ANSI, ANSI EXPORT AND CSA SPECS) (SN 0300224020 through 0300272447) 270
FIGURE 3-39. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT SPECS) (SN 0300234013 through 0300272447) 274
FIGURE 3-40. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2.3L3 ENGINE) (ANSI EXPORT SPEC) (SN 0300234013 through 0300272447) 278

SECTION 4 - BOOM 281

FIGURE 4-1. BOOM AND CYLINDER INSTALLATION - 400SC 282
FIGURE 4-2. BOOM AND CYLINDERS INSTALLATION - 460SJC 284

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >

FIGURE 4-3. MAIN BOOM ASSEMBLY - 400SC 286
FIGURE 4-4. MAIN BOOM ASSEMBLY - 460SJC 288
FIGURE 4-5. JIB BOOM ASSEMBLY - 460SJC (SN 0300000100 through 0300262057) 292
FIGURE 4-6. JIB BOOM ASSEMBLY - 460SJC (SN 0300262057 through 0300272447) 294
FIGURE 4-7. ROTATOR ASSEMBLY - 400SC (SN 0300000100 through 0300244379) 296
FIGURE 4-8. ROTATOR ASSEMBLY - 400SC (SN 0300244379 through 0300272447) 298
FIGURE 4-9. ROTATOR ASSEMBLY - 460SJC 300
FIGURE 4-10. POWER TRACK INSTALLATION 302
FIGURE 4-11. CAPACITY SWITCH INSTALLATION 304
FIGURE 4-12. TRANSPORT SWITCHES INSTALLATION 306
FIGURE 4-13. PLATFORM SUPPORT INSTALLATION - WITHOUT LSS 308
FIGURE 4-14. PLATFORM SUPPORT INSTALLATION - WITH 4 CELL LSS 310
FIGURE 4-15. PLATFORM SUPPORT INSTALLATION - WITH 1 CELL LSS 312
FIGURE 4-16. CABLES AND CLAMPS INSTALLATION - 400SC 314
FIGURE 4-17. CABLES AND CLAMPS INSTALLATION - 4000W GENRATOR - 400SC (SN 0300000100 through 0300214184) 316
FIGURE 4-18. CABLES AND CLAMPS INSTALLATION - 4000W-50HZ GENRATOR - 400SC - ANSI EXPORT AND CE SPECS (SN 0300214184 through 0300272447) 318
FIGURE 4-19. CABLES AND CLAMPS INSTALLATION - 4000W-60HZ GENRATOR - 400SC - ANSI EXPORT SPECS (SN 0300224020 through 0300272447) 320
FIGURE 4-20. CABLES AND CLAMPS INSTALLATION - 460SJC - CE SPECS 322
FIGURE 4-21. CABLES AND CLAMPS INSTALLATION - 460SJC - ANSI EXPORT SPECS 324
FIGURE 4-22. BOOM REST INSTALLATION 326
FIGURE 4-23. DRIVE DISABLE SWITCH INSTALLATION (SN 0300239462 through 0300250672) 328

SECTION 5 - PLATFORM 331

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X .91M) - DROP BAR ENTRY 332
FIGURE 5-2. PLATFORM ASSEMBLY - 30IN X 5FT (76.2CM X 1.5M) WITH SWING GATE 334
FIGURE 5-3. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE 336
FIGURE 5-4. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH SWING GATE 338
FIGURE 5-5. PLATFORM ASSEMBLY - 30IN X 5FT (76.2CM X 1.5M) WITH DROP BAR 340
FIGURE 5-6. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH DROP BAR 342
FIGURE 5-7. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH DROP BAR 344
FIGURE 5-8. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH SWING GATE 346
FIGURE 5-9. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH DROPBAR 348
FIGURE 5-10. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) TRI-ENTRY WITH DROPBAR (SN 0300261352 through 0300272447) 350
FIGURE 5-11. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) TRI-ENTRY WITH DROPGATE (SN 0300261352 through 0300272447) 352
FIGURE 5-12. CONSOLE BOX INSTALLATION (SN 0300000100 through 0300259635) 354
FIGURE 5-13. CONSOLE BOX INSTALLATION (SN 0300259635 through 0300272447) 356
FIGURE 5-14. CONSOLE BOX ASSEMBLY (SN 0300000100 through 0300220076) 358
FIGURE 5-15. CONSOLE BOX ASSEMBLY (SN 0300220076 through 0300259635) 362
FIGURE 5-16. CONSOLE BOX ASSEMBLY (SN 0300259635 through 0300272447) 366
FIGURE 5-17. CONTROLLER ASSEMBLY (DRIVE AND STEER) 370
FIGURE 5-18. CONTROLLER ASSEMBLY (LIFT AND SWING) 372
FIGURE 5-19. FOOTSWITCH ASSEMBLY 374
FIGURE 5-20. LIGHT PANEL INSTALLATION - 400SC (ANSI, ANSI EXPORT AND CSA SPECS) (SN 0300234013 through 0300272447) 376
FIGURE 5-21. LIGHT PANEL INSTALLATION - 400SC (CE SPEC) 378
FIGURE 5-22. LIGHT PANEL INSTALLATION - 460SJC 380
FIGURE 5-23. TRAY INSTALLATION 382
FIGURE 5-24. SOFT TOUCH INSTALLATION - 36IN X 8FT (91.5CM X 2.44M) PLATFORM (OPTIONAL) 384
FIGURE 5-25. SKYGUARD SYSTEM INSTALLATION (SN 0300000100 through 0300259635) 386
FIGURE 5-26. SKYGUARD SYSTEM INSTALLATION (SN 0300259635 through 0300272447) 388
FIGURE 5-27. CROSS RAIL INSTALLATION 390
FIGURE 5-28. SKYGLAZIER INSTALLATION 392
FIGURE 5-29. SKYWELDER INSTALLATION (50HZ) 396
FIGURE 5-30. SKYWELDER INSTALLATION (60HZ) (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 398
FIGURE 5-31. SKYWELDER PREP PACKAGE (60HZ) (ANSI EXPORT SPECS) (SN 0300224020 through 0300272447) 400
FIGURE 5-32. WELDER ASSEMBLY 402
FIGURE 5-33. SKYEYE INSTALLATION 404
FIGURE 5-34. SKYLINE INSTALLATION 406

SECTION 6 - CYLINDER 409

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >

FIGURE 3-22. PISTON PUMP ASSEMBLY (REAR)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001189236	Ref	PISTON PUMP ASSEMBLY (REAR)	D
1	7022355	1	Shaft Assembly (Includes Items 2-4)	
2	70005271	1	Shaft	
3	7021238	1	Ring, Retaining	
4	7021239	1	Bearing, Roller	
5	See Note	NSS	O-Ring (Use Item 100)	
6	See Note	NSS	Seal, Lip (Use Item 100)	
7	70005245	1	Screw	
8	7022331	1	Link, Control Summing	
9	7022332	1	Link, Control Feedback	
10	7022333	1	Link, Neutral Adjust	
11	70005246	1	Screw, Neutral Adjust	
12	See Note	NSS	Nut, Seal (Use Item 100)	
13	70005247	1	Plug (Includes Item 14)	
14	7022322	1	O-Ring	
15	7022321	1	Plug Assembly	
16	70005248	1	Controller, Electrical	
17	70005249	4	Screw M6 x 50	
18	70005250	3	Screw M6 x 60	
19	7022336	1	Spool Assembly	
20	70005251	1	Spring	
21	70005252	1	Adapter	
22	7022338	1	Gasket, Control	
23	See Note	1	Housing Assembly (Note: Not Available - Purchase Complete Rear Pump Assembly)	
24	7021248	1	Side Cover Assembly	
25	7021249	1	Bearing, Needle	
26	70005253	1	Pin	
27	70004890	2	Screw M6 x 20	
28	See Note	NSS	Gasket, Side Cover (Use Item 100)	
29	70004892	4	Screw M6 x 30	
30	70005254	1	Screen, Filter	
31	70005255	1	Plug	
32	7007419	2	Plug Assembly	
33	7007420	2	Plug	
34	70005255	2	Plug	
35	7021257	1	Ring, Retaining	
36	70004890	1	Screw	
37	7022340	1	Bracket, Lifting	
38	7007419	2	Plug Assembly (Not Shown)	
39	70004893	1	Key	
40	7022341	1	Ring, Retaining	
41	7022357	1	Spacer	
42	7021259	1	Bearing, Journal	
43	70004894	1	Gerotor Cover Assembly (Includes Item 42)	
44	7021262	1	O-Ring	
45	70005257	1	Pin	
46	7024800	1	Spring	
47	70005258	1	Valve, SCR (Includes Item 46)	
48	7024800	1	Spring	

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >

FIGURE 6-7. LIFT CYLINDER ASSEMBLY - JIB - 460SJC (USAGE MAY VARY) (SN 0300245226 through 0300245251)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001228012	Ref	LIFT CYLINDER ASSEMBLY - JIB	C
		Ref	Note: Original Cylinder May Have Been Replaced with Service Replacement. Identify PN Stamped on Cylinder Before Ordering Parts.	
1	See Note	NSS	Barrel (Note: Not Available for Purchase)	
2	70006572	1	Rod	
3	70006571	1	Head	
4	70006570	1	Piston	
5	70023915	1	Screw	
6	70006569	1	Spacer	
7	4640509	2	Cartridge, Valve	
7	2900792	2	Seal Kit - 4640509 Valve	
8	0962336	4	Bushing	
9	2220883	6	Plug, O-Ring	
10	2220885	2	Plug, O-Ring	
100	70006568	1	Seal Kit (Includes Items 101-111)	
101	See Note	NSS	Ring, Wear (Note: Use Item 100)	
102	See Note	NSS	O-Ring (Note: Use Item 100)	
103	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
104	See Note	NSS	Seal, Rod (Note: Use Item 100)	
105	See Note	NSS	O-Ring (Note: Use Item 100)	
106	See Note	NSS	Wiper (Note: Use Item 100)	
107	See Note	NSS	Ring, Wear (Note: Use Item 100)	
108	See Note	NSS	Seal (Note: Use Item 100)	
109	See Note	NSS	O-Ring (Note: Use Item 100)	
110	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
111	See Note	NSS	O-Ring (Note: Use Item 100)	

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >

FIGURE 9-3. DECAL INSTALLATION - CE SPEC - 460SJC

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001217213	Ref	DECAL INSTALLATION - REFERENCE CHART	A
	1001217488	Ref	DECAL INSTALLATION - REFERENCE CHART (TURNTABLE)	A
	1001217214	Ref	DECAL INSTALLATION - TURNTABLE	A
1	1705921	1	Decal - Tipping/Electrocution (Platform)	
2	1705822	1	Decal - Electrocution/Safety Manual	
3	1705961	3	Decal - Electrocution	
4	1701518	3	Decal - Warning Crushing	
8	1001159323	2	Decal - JLG 8 Black	
10	1702773	2	Decal - JLG 5	
12	1704277	3	Decal - Attach Lanyard Here	
13	1001171339	2	Decal - Capacity (Platform)	
14	1001171339	1	Decal - Capacity (Ground Control)	
15	1705084	1	Decal - Sound Power Level	
15	1001204510	1	Decal - Sound Power Level	
16	1701504	1	Decal - Hydraulic Oil	
20	1701509	1	Decal - Manual	
22	1701500	2	Decal - Lift	
25	0860520	1	Box, Manual Storage	
26	4751400	4	Washer 1/4	
27	3311405	4	Nut 1/4	
29	1705828	1	Decal - Footswitch	
40	1704412	1	Decal - Hydraulic Oil Chart	
43	0641406	4	Bolt 1/4 x 3/4	
46	1001197408	1	Decal - MSSO	
54	1701518	2	Decal - Warning Crushing	
	1001190872	Ref	DECAL INSTALLATION - REFERENCE CHART (FRAME)	H
	1001191076	Ref	DECAL INSTALLATION - FRAME	E
101	1701499	6	Decal - No Lift	
102	1701529	2	Decal - Arrow	
103	1702300	4	Decal - Tie Down	
104	See Note	NSS	Decal - Bar Code (Note: Not Available for Purchase)	
105	1001202228	1	Decal - Machine Motion Hazard	
107	3572044	1	Plate, Decal Mounting **(SN 0300000100 through 0300227267)**	
107	1001093553	1	Plate, Decal Mounting **(SN 0300227267 through 0300272447, Excluding 0300270239)**	
108	3820001	5	Rivet	
109	1701500	2	Decal - Lift	

MidWestTech | JLG 400SC, 460SJC Boom Lift Parts Manual | Publication 3121706 Order the manual at mid-west-tech.com >