An Oshkosh Corporation Company

Service and Maintenance Manual

Model

H340AJ

PVC 2007

31217121

July 16, 2020 - Rev A

ANSI

CE

AS/NZS

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121

Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1 - SPECIFICATIONS		
1.1	Operating Specifications	1-1
1.2	Dimensional Data	1-1
1.3	Capacities	1-1
1.4	Tires	1-1
1.5	Engine Data	1-1
1.6	Hydraulic Oil	1-2
	Oil Sampling	1-2
1.7	Major Component Weights	1-3
1.8	Maintenance and Lubrication	1-5
1.9	Thread Locking Compound	1-8
1.10	Torque Charts	1-9
	SAE Fastener Torque Chart	1-9
	Metric Fastener Torque Chart	1-15
SECTION 2 - GENERAL		
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventive Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Reassembly	2-3
	Pressure-Fit Parts	2-3
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage and Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-3
	Battery	2-3
	Lubrication and Servicing	2-3
2.3	Lubrication and Information	2-3
	Hydraulic System	2-3
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4
2.4	Cylinder Drift	2-5
	Theory	2-5
	Cylinder Leakage Test	2-5
	Cylinder Thermal Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-6
2.6	Welding on JLG Equipment	2-6
	Do the Following When Welding on JLG Equipment	2-6
	DO NOT Do the Following When Welding on JLG Equipment	2-6

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

SECTION NO. **TITLE** **PAGE NO.**

SECTION 3 - CHASSIS & TURNTABLE

3.1 Tires & Wheels ... 3-1
Tire Replacement ... 3-1
Wheel and Tire Replacement ... 3-1
Wheel Installation ... 3-1
3.2 Oscillating Axle System ... 3-4
3.3 Lockout Cylinder Bleeding ... 3-4
3.4 Oscillating Axle Lockout Test ... 3-5
3.5 Drive System ... 3-8
3.6 Drive Orientation System ... 3-8
3.7 Drive Motor ... 3-10
Removal ... 3-10
Ball Bearing Repair/Replacement ... 3-10
Assembly/Disassembly ... 3-10
Installation ... 3-10
3.8 Drive Hub ... 3-12
Removal ... 3-12
Assembly/Disassembly ... 3-12
Installation ... 3-12
3.9 Swing Motor ... 3-13
Removal ... 3-15
Preparation Before Disassembly ... 3-17
Disassembly and Inspection ... 3-17
Assembly ... 3-24
One Piece Stator Construction ... 3-30
Two Piece Stator Construction ... 3-31
Final Checks ... 3-31
Installation ... 3-31
3.10 Swing Bearing ... 3-32
Removal ... 3-32
Installation ... 3-35
Turntable Bearing Mounting Bolt Condition Check ... 3-36
Wear Tolerance ... 3-36
Swing Bearing Torque Value ... 3-36
Disassembly ... 3-38
Assembly ... 3-39
3.11 Engine Operating States ... 3-50
3.12 Kubota Engine ... 3-51
Retrieving Engine Hours ... 3-53
Fuel Level Sensor ... 3-55
Coolant Sensor ... 3-56
Engine Oil Pressure Switch ... 3-56
Glow Plugs ... 3-57
3.13 Chassis Tilt Indicator System ... 3-58
3.14 Fuel Reserve / Cut-Out System ... 3-58
3.15 Hot Weather operation ... 3-58
3.16 Cold Weather Operation ... 3-58
3.17 Generator ... 3-59
Ball Bearing Repair/Replacement ... 3-59

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
3.18	Battery Charger	3-60
	Indications on the Charger 3-LED Display	3-60
	Troubleshooting Instructions	3-61
	Instructions for using the Delta-Q QuiQ Programmer CTQuiQ Programming Kit	3-67
	Connecting a QuiQ Charger to your Computer	3-68
	Starting QuiQ Programmer CT	3-69
	Programming Delta-Q QuiQ and QuiQ-dci Chargers	3-70
	View Charge Tracking Data with QuiQ Programmer CT	3-71
	Selecting a Charge Profile	3-71
	Battery Testing	3-72
3.19	Battery Maintenance, Quarterly	3-72
3.20	Counterweight	3-73
SECTION 4 - BOOM & PLATFORM		
4.1	Boom Systems	4-1
	Platform Control Enable System	4-1
	Transport Position Sensing System	4-1
	Beyond Transport Position - Drive Speed Cutback System	4-1
	Drive/Steer – Boom Function Interlock System (CE ONLY)	4-1
	Platform Load Sensing System	4-1
	Jib Lift End of Stroke Dampening	4-1
	Ground Control Keyswitch System	4-1
	Side Entry Platform	4-2
	Function Speed Control System	4-2
	Emergency Decent System	4-2
4.2	Platform	4-3
	Support Removal	4-3
	Support Installation	4-4
4.3	Boom Removal and Installation	4-6
	Main Boom Removal	4-6
	Mid Boom Removal	4-6
	Lower Boom Removal	4-7
	Lower Boom Installation	4-8
	Mid Boom Installation	4-8
	Main Boom Installation	4-9
4.4	Boom Maintenance	4-9
	Disassembly of the Main Boom	4-9
	Inspection	4-11
	Assembly of the Main Boom	4-11
4.5	Jib	4-15
	Removal	4-15
	Disassembly	4-15
	Inspection	4-15
	Assembly	4-16
	Installation	4-16
4.6	Boom Cleanliness Guidelines	4-16
4.7	Hose Routing	4-18
4.8	Powertrack Maintenance	4-18
	Remove Link	4-18
	Install New Link	4-21
	Replace Fixed End Brackets	4-24
	Replace Moving End Brackets	4-25

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

3.20 COUNTERWEIGHT

If the counterweight has been removed, ensure the retaining bolts are torqued to the proper value as shown in Figure 3-40., Counterweight Bolt Torque.




Figure 3-40. Counterweight Bolt Torque

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

Diagnostics & Troubleshooting

If SkyGuard does not function when the sensor is engaged, first verify the configuration under the MACHINE SETUP: SKYGUARD OPTION menu using the handheld Analyzer. Ensure the selected configuration matches the actual system installed on the machine. If not, select the correct configuration, then verify operation.

Additionally, use the handheld analyzer to navigate to the DIAGNOSTICS: FEATURES → SKYGUARD INPUTS menu to determine additional SkyGuard fault information.

Engage the SkyGuard sensor and observe the Analyzer to determine if the switch/relay closes.

If the status of the switch/relay remains OPEN while the SkyGuard sensor is actively engaged, it is possible the sensor has failed and should be replaced immediately.

If the status of the switch/relay remains CLOSED while the SkyGuard sensor is actively engaged, a power or ground wire may not be making good contact or may be loose or broken. Additionally, there is a low probability that both relays may have failed.

If the switch/relay status is in disagreement, then one may have failed or is not installed correctly. In this case, the machine will be inoperable.

FAULT CODES

Refer to Table 6-17 for more fault code information

- **0039** - SkyGuard switch activation fault
- **2563** - switch disagreement fault

Table 4-2. SkyGuard Function Table

Drive Forward	Drive Reverse	Steer	Swing	Tower Lift Up	Tower Lift Down	Boom Lift Up	Boom Lift Down	Boom Tele Out	Boom Tele In	Jib Lift	Basket Level	Basket Rotate
R*/C**	R	C	R	R	C	R	R	R	C	C	C	C
R = Indicates Reversal is Activated												
C = Indicates Cutout is Activated												
* DOS Enabled Disregard when boom is in line and driving forward with or without steering and no other function active												
** DOS Disabled and any function is active if the machine is driving forward and in line												

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

7.9 WIRING HARNESS CONNECTOR LABELS

Connector Labels

Connectors between harnesses are identified by the prefix "X" and a sequentially assigned number. An optional suffix (letters & numbers) may be added when multiple terminations occur at one device or when there are optional connections.

Examples:

X25 connects to X25 in another harness.

X65A, X65B connect to different portions of one device

X163 connects to X163A in ANSI and X163B in CE machines

Component Labels

Every component on the vehicle has a unique identification. A standard prefix letter is assigned according to the table below, followed by a unique sequential number. An optional suffix (letters & numbers) may be added when multiple terminations occur at one device.

Terminals that are not loaded into connectors are considered independent components and labeled in the same fashion.


Table 7-1. Wiring Harness Connector Labels

Component	Category	Label
Audible	Alarms	AH
	Horns	
Battery	Batteries	BT
	Battery Terminals	
Control Module	Ground	CO
	LSS	
	Platform	
Engine	Alternator	EC
	Cold Start	
	Controller	
	Coolant Temp	
	Fuel Pump	
	Fuel Solenoid	
	Glow Plugs	
	Oil Pressure	
	Starter	
Fuse & CB Fuse FC	Fuse	FC
	Fusible Link	FC
	Circuit Breaker	CB
Gauge & Display	Board	GD
	Cluster	
	Hourmeter	
	LMI	
	Speedometer	
Inline	Resistor	R
	Diode	D
Joystick & Steering	Electronic	JS
	Hydraulic	
Lights	Dome	LB
	Headlights	
	Simple	
	Taillights	
Membrane Panel		MP
Miscellaneous	Radio	MS
	Speakers	
	Splice Blocks	
	T-Connectors	


MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >

4. Pull moving end over track so new connection is positioned in curve of powertrack. Round half-shears will rotate into cut-outs.





5. Parts shown below connect new link to powertrack.



6. Push pin through center hole then slide washer on pin.





7. Install snap ring in groove on pin. Repeat pin installation steps for all center holes with rivets removed.




MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >


5. Loosen and remove all but a few of the bolts securing the turntable to the swing bearing.



6. Place a drain pan under the flow divider valve to catch any escaping hydraulic oil. Tag and disconnect the hoses from the flow divider valve that go up through the turntable. Cap or plug all openings so no dirt enters the system.




7. Remove the drive orientation and lockout switches so they don't get broken during the removal procedure.



8. Swing the engine tray back into position and secure it in place with the retaining bolt.

9. Attach chains and slings to support the upperstructure. Begin with the chain at the approximate lengths as shown below and adjust as necessary to maintain the turntable in a level position during lifting. For gross machine weight Figure 3-17.



10. Remove the remaining turntable bolts that were left in place earlier in the procedure.

11. Disconnect all cables or harnesses routed through the bearing on the chassis to turntables.

12. Lift the turntable off of the bearing and place it out of the way on adequate blocking.



13. Remove the bolts securing the bearing to the frame. It may be necessary to disconnect more hoses on the flow divider valve. If so, tag and disconnect all hoses and cap or plug all openings to prevent dirt from entering the hydraulic system.

NOTE: *The swing bearing assembly weighs approximately 125 lb (56.6 kg).*

MidWestTech | JLG H340AJ Boom Lift Service Manual | Publication 31217121 Order the manual at mid-west-tech.com >