An Oshkosh Corporation Company

Service and Maintenance Manual

Model

E600
E600J
E600JP
M600
M600J
M600JP

P/N - 3121813

December 18, 2012

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
SECTION A - INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS		
A	General	A-1
B	Hydraulic System Safety	A-1
C	Maintenance	A-1
SECTION 1 - SPECIFICATIONS		
1.1	Capacities	1-1
1.2	Operating specifications	1-1
1.3	Generator	1-1
1.4	Battery Charger	1-1
1.5	Drive/Steer System	1-1
1.6	Tires	1-1
1.7	Function Speeds	1-2
	Machine Orientation When Doing Speed Tests	1-2
	Test Notes	1-2
1.8	Pressure Settings	1-2
1.9	Torque Requirements	1-3
1.10	Major Component Weights	1-3
1.11	Serial Number Location	1-3
1.12	Hydraulic Oil	1-4
1.13	Operator Maintenance	1-5
SECTION 2 - GENERAL		
2.1	Machine Preparation, Inspection, and Maintenance	2-1
	General	2-1
	Preparation, Inspection, and Maintenance	2-1
	Pre-Start Inspection	2-1
	Pre-Delivery Inspection and Frequent Inspection	2-1
	Annual Machine Inspection	2-1
	Preventative Maintenance	2-1
2.2	Service and Guidelines	2-2
	General	2-2
	Safety and Workmanship	2-2
	Cleanliness	2-2
	Components Removal and Installation	2-2
	Component Disassembly and Reassembly	2-3
	Pressure-Fit Parts	2-3
	Bearings	2-3
	Gaskets	2-3
	Bolt Usage and Torque Application	2-3
	Hydraulic Lines and Electrical Wiring	2-3
	Hydraulic System	2-3
	Lubrication	2-3
	Battery	2-3
	Lubrication and Servicing	2-3
2.3	Lubrication and Information	2-4
	Hydraulic System	2-4
	Hydraulic Oil	2-4
	Changing Hydraulic Oil	2-4
	Lubrication Specifications	2-4

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >


SECTION NO.	TITLE	PAGE NO.
2.4	Cylinder Drift Test	2-5
	Platform Drift	2-5
	Cylinder Drift	2-5
2.5	Pins and Composite Bearing Repair Guidelines	2-5
2.6	Welding on JLG Equipment	2-6
	Do the Following When Welding on JLG Equipment	2-6
	Do NOT Do the Following When Welding on JLG Equipment	2-6
2.7	Applying Silicone Dielectric Compound to Electrical Connections	2-6
SECTION 3 - CHASSIS & TURNTABLE		
3.1	Tires & Wheels	3-1
	Tire Inflation	3-1
	Tire Damage	3-1
	Tire Replacement	3-1
	Wheel Replacement	3-1
	Wheel Installation	3-1
3.2	Drive Hub -REAR (Prior to S/N 0300112585)	3-2
	Disengaging for Towing	3-2
	Engaging after Towing is Complete	3-3
	Disassembly	3-5
	Disassembly of Cover	3-5
	Disassembly of the first stage planetary assembly (7)	3-5
	Disassembly of second stage planet gears (1)	3-5
	Assembly of first stage planetary assembly (7)	3-5
	Assembly of end cover unit (8)	3-6
	Final Assembly	3-6
	Initial Start-Up and After Repairs	3-6
	Oil Change Interval-Gear Drive	3-6
3.3	Drive Hub (S/N 115723 to Present)	3-6
	Roll and Leak Testing	3-6
	Tightening and Torquing Bolts	3-7
	Main Disassembly	3-7
	Output Carrier Disassembly	3-10
	Input Carrier Disassembly	3-12
	Hub-Spindle Disassembly	3-13
	Cover Disassembly	3-14
	Input Carrier Assembly	3-15
	Output Planet Gear Assembly	3-15
	Output Carrier Assembly	3-16
	Hub-Spindle Assembly	3-16
	Cover Subassembly	3-17
	Main Assembly	3-17
3.4	Drive Brake - Mico	3-21
	Disassembly	3-21
	Assembly	3-21
	Bleeding	3-21
3.5	Speed Sensor Adjustment	3-24
	Adjustment Procedure	3-24
	Speed Sensor Installation Verification	3-27
	Verification w/ Analyzer Procedure	3-27

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >

SECTION NO.	TITLE	PAGE NO.
3.6	Oscillating Axle Lockout Test (If Equipped)	3-31
3.7	Oscillation Cylinder Bleeding	3-31
	Bleeding Procedure	3-31
	Checking Oscillation Cylinders	3-31
3.8	Swing Drive	3-32
	Roll, Leak and Brake Testing	3-32
	Tightening and Torquing Bolts	3-32
	Motor Control Valve Disassembly	3-32
	Motor and Brake Disassembly	3-34
	Main Disassembly	3-36
	Hub-shaft Disassembly	3-37
	Carrier Disassembly	3-38
	Hub-Shaft Sub-Assembly	3-39
	Carrier Sub-Assembly	3-39
	Main Assembly	3-40
	Motor-Brake Subassembly	3-40
	Motor-Brake Assembly	3-40
	Motor Control Valve Assembly	3-41
	Tube Fitting Assembly Procedures	3-41
	Procedure for Setting Gear Backlash	3-41
3.9	Swing Bearing	3-42
	Turntable Bearing Mounting Bolt Condition Check	3-42
	Wear Tolerance	3-43
	Replacement of Swing Bearing	3-45
	Swing Bearing Torque Value	3-46
	Swing Drive Installation	3-46
	Setting Backlash	3-46
3.10	Battery Maintenance and Charging	3-47
	Battery Maintenance, Quarterly	3-47
	Optional On Board Generator	3-47
	Battery Charging (On Board Charger)	3-47
	Removing the Battery Box	3-48
3.11	Generator (Prior to S/N 88375)	3-52
	Timing Sequences	3-54
	To Connect the JLG Control System Analyzer to the Generator	3-55
	Alarms and Fault Flash Codes	3-55
	Output Current and Voltage Settings	3-57
	Priming the Fuel Line	3-58
3.12	Generator (S/N 88375 to Present)	3-59
	Engine	3-59
	Alternator	3-59
	Dynamo and Dynamo Voltage Regulator	3-59
	Dynamo Output Fuse	3-59
	Control Fuse	3-59
	Start Battery	3-61
	Engine Starter	3-61
	Start Control Relay	3-61
	Fuel Control Relay	3-62
	Glow Plug Control Relay	3-62
	Glow Plug	3-62
	Fuel Pump	3-63
	Fuel Solenoid	3-63

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >

2. Generator Engine (If Equipped)




Lube Point(s) - Fill Cap
Capacity - Refer to Engine Manual
Lube - EO
Interval - 3 Months or 150 hours of operation
Comments - Check level daily/Change in accordance with engine manual.

3. Hydraulic Tank




Lube Point(s) - Fill Cap
Capacity -
Prior to S/N 51941 - 15 gal. tank (56.7 L)
S/N 51941 to present - 15.9 gal. system (56.7L)
12.4 gal. (46.9 L) to Full Mark
Lube - HO
Interval - Check Level daily; Change every 2 years or 1200 hours of operation.

4. Hydraulic Filter



Interval - Change after first 50 hrs. and every 6 months or 300 hrs. thereafter or as indicated by Condition Indicator.
Comments - Under certain conditions, it may be necessary to replace the filter on a more frequent basis.

5. Swing Drive Hub (S/N 58845 to Present)



Lube Point(s) - Level/Fill Plug
Capacity - 24 oz. (0.7 L)
Lube - EPGL
Interval - Check level every 3 months or 150 hrs of operation; change every 2 years or 1200 hours of operation

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >

Troubleshooting

Table 4-1. Troubleshooting

Problem	Cause	Solution
1. Shaft rotates slowly or not at all	a. Insufficient torque output	a. Verify correct operating pressure. Do not exceed OEM's pressure specifications. Load may be above maximum capacity of the actuator.
	b. Low rate of fluid flow	b. Inspect ports for obstructions and hydraulic lines for restrictions and leaks.
	c. Control or counterbalance valve has internal leak	c. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.
	d. Piston and/or shaft seal leak	d. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.
	e. Corrosion build-up on the thrust surfaces	e. Re-build the actuator. Remove all rust then polish. Replacement parts may be needed.
	f. Swollen seals and composite bearings caused by incompatible hydraulic fluid	f. Re-build the actuator. Use fluid that is compatible with seals and bearings.
2. Operation is erratic or not responsive	a. Air in actuator	a. Purge air from actuator. See bleeding procedures.
3. Shaft will not fully rotate	a. Twisted or chipped gear teeth	a. Check for gear binding. Actuator may not be able to be re-built and may need to be replaced. Damage could be a result of overload or shock.
	b. Port fittings are obstructing the piston	b. Check thread length of port fittings. Fittings should during stroke not reach inside the housing bore.
4. Selected position cannot be maintained	a. Control or counterbalance valve has internal leak	a. Disconnect hydraulic lines and bypass valve. Leave valve ports open and operate the actuator through housing ports (do not exceed OEM's operating pressure). The valve must be replaced if a steady flow of fluid is seen coming from the valve ports.
	b. Piston and/or shaft seal leak	b. Remove the plug and the housing's valve ports. Operate the actuator through the housing ports. Conduct the internal leakage test as described in the Testing section on page 24 of this manual.
	c. Air in actuator	c. Purge air from actuator. See bleeding procedures

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >




Figure 7-21. Electrical Schematic - Sheet 2 of 4

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >

SECTION 5. HYDRAULICS

5.1 LUBRICATING O-RINGS IN THE HYDRAULIC SYSTEM

When assembling connectors in the hydraulic that use o-ring fittings, it is necessary to lubricate all fittings with hydraulic oil prior to assembly. To lubricate the fittings, use one of the following procedures.

NOTE: *All O-ring fittings must be pre-lubricated with hydraulic oil prior to assembly.*


Cup and Brush

The following is needed to correctly oil the o-ring in this manner:

- A small container for hydraulic oil
- Small paint brush



1. Hold the fitting in one hand while using the brush with the other hand to dip into the container. Remove excess hydraulic oil from the brush so an even film of oil is applied on the o-ring.



2. Holding the fitting over the hydraulic oil container, brush an even film of oil around the entire o-ring in the fitting, making sure the entire o-ring is completely saturated.



3. Turn the o-ring on the other side of the fitting and repeat the previous step, ensuring the entire o-ring is coated with hydraulic oil.



MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >

7.11 DEUTSCH CONNECTORS

DT/DTP Series Assembly




Figure 7-12. DT/DTP Contact Installation

1. Grasp crimped contact about 25mm behind the contact barrel.
2. Hold connector with rear grommet facing you.
3. Push contact straight into connector grommet until a click is felt. A slight tug will confirm that it is properly locked in place.
4. Once all contacts are in place, insert wedgelock with arrow pointing toward exterior locking mechanism. The wedgelock will snap into place. Rectangular wedges are not oriented. Thy may go in either way.

NOTE: *The receptacle is shown - use the same procedure for plug.*

DT/DTP Series Disassembly




Figure 7-13. DT/DTP Contact Removal

1. Remove wedgelock using needlenose pliers or a hook shaped wire to pull wedge straight out.
2. To remove the contacts, gently pull wire backwards, while at the same time releasing the locking finger by moving it away from the contact with a screwdriver.
3. Hold the rear seal in place, as removing the contact may displace the seal.

MidWestTech | JLG E600, E600J, E600JP, M600, M600J, M600JP Boom Lift Service Manu... Order the manual at mid-west-tech.com >