OPERATORS & SAFETY
Service & Maintenance
Illustrated Parts

Models
10VP
15VP
20VP

3123001
September 15, 1997

An Oshkosh Corporation Company

AUSTRALIAN OFFICE

JLG INDUSTRIES, INC.
P.O. Box 5119
11 Bolwarra Road
Port Macquarie, Australia
Telephone: 065 811111
Fax: 065 810122

EUROPEAN OFFICE

JLG INDUSTRIES (EUROPE)
Kilmarting Place,
Tannochside Park
Uddingston, Scotland, G71 5PH
Telephone: 01698 811005
Main Fax: 01698 811055
Parts Fax: 01698 811455

WORLD HEADQUARTERS

JLG INDUSTRIES, INC.
1 JLG Drive
McConnellsburg, PA.
17233-9533
USA
Telephone: (717) 485-5161
Fax: (717) 485-6417

MidWestTech | JLG 10VP, 15VP, 20VP Vertical Mast Operation, Parts, Service Manual | Publication 3123001

Order the manual at mid-west-tech.com >

SUBJECT - SECTION, PARAGRAPH	PAGE NO.
INTRODUCTION - OPERATION SAFETY PRECAUTIONS	a
INTRODUCTION - MAINTENANCE SAFETY PRECAUTIONS	b
A. General	b
B. Hydraulic System Safety	b
C. Maintenance	b
EFFECTIVITY CHANGES	c
TABLE OF CONTENTS	i
LIST OF ILLUSTRATIONS	ii
LIST OF TABLES	ii
SECTION 1 - SAFETY PRECAUTIONS	
1-1. General	1-1
1-2. Electrocution Hazard	1-1
1-3. Transporting Machine	1-1
1-4. Pre-Operational Safety	1-2
1-5. Operation Safety	1-3
SECTION 2 - PREPARATION AND INSPECTION	
2-1. General	2-1
2-2. Preparation For Use	2-1
2-3. Delivery and Frequent Inspection	2-1
2-4. Daily Walk-Around Inspection	2-2
2-5. Daily Functional Check	2-4
2-6. Torque Requirements	2-5
2-7. Battery Charging	2-5
SECTION 3 - USER RESPONSIBILITIES AND MACHINE CONTROLS	
3-1. General	3-1
3-2. Personnel Training	3-1
3-3. Operating Characteristics and Limitations	3-2
3-4. Controls and Indicators	3-2
SECTION 4 - MACHINE OPERATION	
4-1. Machine Description	4-1
4-2. General	4-1
4-3. Machine Operation	4-2
4-4. Stowing Machine	4-3
4-5. Transporting, Lifting and Tie-Down Procedures	4-4
SECTION 5 - OPTIONAL EQUIPMENT	
5-1. Optional Equipment	5-1
SECTION 6 - EMERGENCY PROCEDURES	
6-1. General	6-1
6-2. Emergency Controls and Their Locations	6-1
6-3. Emergency Operation	6-1
6-4. Incident Notification	6-2
SECTION 7 - SPECIFICATIONS	
7-1. Capacities	7-1
7-2. Component Data	7-1
7-3. Performance Data	7-1
7-4. Torque Requirements	7-2
7-5. Lubrication	7-2
7-6. Pressure Adjustment	7-2
7-7. Cylinder Specifications	7-2
7-8. Serial Number Locations	7-2

MidWestTech | JLG 10VP, 15VP, 20VP Vertical Mast Operation, Parts, Service Manual | P... Order the manual at mid-west-tech.com >

SUBJECT-SECTION, PARAGRAPH — PAGE NO.

SECTION 8 - SERVICE PROCEDURES

8-1. General 8-1
8-2. Servicing and Maintenance Guidelines 8-1
8-3. Lubrication Information 8-4
8-4. Mast Assembly and Disassembly Procedure 8-5
8-5. Mast to Base Frame Installation 8-15
8-6. Mast Chains and Sequencing Cables Adjustment 8-16
8-7. Torque Limiting Clutch - Maintenance 8-18
8-8. Preventive Maintenance and Inspection Schedule 8-19

SECTION 9 - TROUBLESHOOTING

9-1. General 9-1
9-2. Troubleshooting Information 9-1
9-3. Hydraulic Circuit Checks 9-1
9-4. Electrical Circuit Checks 9-1

SECTION 10 - ILLUSTRATED PARTS MANUAL

Illustrated Parts – Table of Contents 10-0-1

LIST OF ILLUSTRATIONS

FIGURE NO. — TITLE — PAGE NO.

2-1. Daily Walk-Around Inspection 2-3
2-2. Charger Assembly 2-5
2-3. Battery Fluid Level 2-5
3-1. Ground Controls 3-3
3-2. Platform Controller 3-3
3-3. Brake Release Over-Center Handle 3-4
3-4. JLG's Pot-Hole-Protection Override Over-Center Handle 3-5
4-1. Forklift Truck Lifting Pockets & Tie Down Bar Locations 4-4
7-1. Torque Chart 7-3
7-2. Lubrication Chart 7-4
8-1. Mast Section - Assembly Reference 8-6
8-2. 10VP Mast Assembly 8-9
8-3. 15VP Mast Assembly 8-10
8-4. 20VP Mast Assembly 8-11
8-5. Mast Chains/Cables Routing Diagram 8-17
8-6. Checking Torque Limit Clutch - Torque Setting 8-18
8-7. Torque Limit Clutch - Adjustment Components 8-19
9-1. LED Battery/Flash Code Indicator Strip 9-2
9-2. Pictorial Overview of Electrical System ..... 9-6\7

LIST OF TABLES

TABLE NO. — TITLE — PAGE NO.

1-1. Minimum Safe Approach Distances *(to energized power lines)* 1-1
4-1. Machine Interlock Switch - Operating Conditions 4-2
7-1. Recommended Hydraulic Oils 7-2
7-2. Lubrication Specifications 7-2
8-1. Chain Stretch Tolerance 8-3
8-2. Preventive Maintenance and Inspection Schedule 8-16
9-1. MC-1 WARNING Codes 9-3
9-2. MC-1 ERROR Codes 9-4
9-3. Miscellaneous Problems Troubleshooting *(no warning or error code displayed)* 9-8
9-4. Hydraulic Troubleshooting 9-10

MidWestTech | JLG 10VP, 15VP, 20VP Vertical Mast Operation, Parts, Service M... Order the manual at mid-west-tech.com >