Illustrated Parts Manual

Models
266, 307,
266 LoPro,
Agrovector
26.6, 30.7,
26.6 LP

3126025

Revised
September 26, 2017

An Oshkosh Corporation Company

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | Publication 3126025

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 9

FIGURE 1-1. FRAME SHROUDING AND TRIM, COVERS (Prior to SN 1160005247) 10
FIGURE 1-2. FRAME SHROUDING AND TRIM, COVERS (SN 1160005247 to Present) 14
FIGURE 1-3. FRAME SHROUDING AND TRIM, CAB AND MIRRORS 18
FIGURE 1-4. AXLE AND FENDER INSTALLATION (266, 26.6, 266 LOPRO & 26.6 LP) 22
FIGURE 1-5. AXLE AND FENDER INSTALLATION (307 & 30.7) 24
FIGURE 1-6. FRENCH HOMOLOGATION INSTALLATION 26

SECTION 2 - BOOM 29

FIGURE 2-1. FIRST BOOM SECTION (266, 266 LOPRO, 26.6 & 26.6 LP) 30
FIGURE 2-2. FIRST BOOM SECTION (307 & 30.7) 32
FIGURE 2-3. SECOND BOOM SECTION (266, 266 LOPRO, 26.6 & 26.6 LP) 34
FIGURE 2-4. SECOND BOOM SECTION (307 & 30.7) 36
FIGURE 2-5. QUICK SWITCH ASSEMBLY 38
FIGURE 2-6. HYDRAULIC QUICK SWITCH ASSEMBLY 40
FIGURE 2-7. JD QUICK ATTACH 42

SECTION 3 - ATTACHMENTS 45

FIGURE 3-1. CARRIAGE ASSEMBLY 46
FIGURE 3-2. BUCKETS 48
FIGURE 3-3. MULTI-PURPOSE BUCKETS 50
FIGURE 3-4. FORK MOUNTED HOOK 52
FIGURE 3-5. TRUSS BOOM 54
FIGURE 3-6. MANURE BUCKET 56
FIGURE 3-7. FORK 58
FIGURE 3-8. SIDE SHIFT CARRIAGE 60
FIGURE 3-9. BALE HANDLER 62
FIGURE 3-10. ROUND TINE FORK 64
FIGURE 3-11. CONCRETE BUCKET 66

SECTION 4 - ENGINE AND ATTACHING PARTS 69

FIGURE 4-1. ENGINE ASSEMBLY 70
FIGURE 4-2. DEUTZ ENGINE 74
FIGURE 4-3. FUEL TANK AND LINES 76
FIGURE 4-4. RADIATOR ASSEMBLY 80
FIGURE 4-5. AIR CLEANER INSTALLATION 82
FIGURE 4-6. EXHAUST INSTALLATION 84

SECTION 5 - DRIVE TRAIN 87

FIGURE 5-1. FRONT AXLE 88
FIGURE 5-2. FRONT AXLE - HOUSING (266, 266 LOPRO, 26.6 & 26.6LP) 90
FIGURE 5-3. FRONT AXLE - HOUSING (307 & 30.7) 92
FIGURE 5-4. FRONT AXLE - HOUSING AND STEERING CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 94
FIGURE 5-5. FRONT AXLE - HOUSING AND STEERING CYLINDER (307 & 30.7) 96
FIGURE 5-6. FRONT AXLE - BEVEL GEAR SET 98
FIGURE 5-7. FRONT AXLE - DIFFERENTIAL 100
FIGURE 5-8. FRONT AXLE - DOUBLE U-JOINT (266, 266 LOPRO, 26.6 & 26.6LP) 102
FIGURE 5-9. FRONT AXLE - DOUBLE U-JOINT (307 & 30.7) 104
FIGURE 5-10. FRONT AXLE - BRAKES (266, 266 LOPRO, 26.6 & 26.6LP) 106
FIGURE 5-11. FRONT AXLE - BRAKES (307 & 30.7) 108
FIGURE 5-12. FRONT AXLE - WHEEL HUB AND FINAL REDUCTION (266, 266 LOPRO, 26.6 & 26.6LP) 110
FIGURE 5-13. FRONT AXLE - WHEEL HUB AND FINAL REDUCTION (307 & 30.7) 112
FIGURE 5-14. FRONT AXLE - TRANSMISSION HOUSING 114
FIGURE 5-15. FRONT AXLE - LOWER AND UPPER SHAFT (266, 266 LOPRO, 26.6 & 26.6LP) 116
FIGURE 5-16. FRONT AXLE - LOWER AND UPPER SHAFT (307 & 30.7) 118
FIGURE 5-17. REAR AXLE 120
FIGURE 5-18. REAR AXLE - HOUSING 122
FIGURE 5-19. REAR AXLE - SWIVEL HOUSING AND STEERING CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 124
FIGURE 5-20. REAR AXLE - SWIVEL HOUSING AND STEERING CYLINDER (307 & 30.7) 126
FIGURE 5-21. REAR AXLE - BEVEL GEAR SET 128
FIGURE 5-22. REAR AXLE - DIFFERENTIAL (266, 266 LOPRO, 26.6 & 26.6LP) 130

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 5-23. REAR AXLE - DIFFERENTIAL (307 & 30.7) 132
FIGURE 5-24. REAR AXLE - DOUBLE U-JOINT (266, 266 LOPRO, 26.6 & 26.6LP) 134
FIGURE 5-25. REAR AXLE - DOUBLE U-JOINT (307 & 30.7) 136
FIGURE 5-26. REAR AXLE - WHEEL HUB AND FINAL REDUCTION (266, 266 LOPRO, 26.6 & 26.6LP) 138
FIGURE 5-27. REAR AXLE - WHEEL HUB AND FINAL REDUCTION (307 & 30.7) 140
FIGURE 5-28. DRIVE SHAFT 142
FIGURE 5-29. TIRES AND RIMS 144

SECTION 6 - CAB 147

FIGURE 6-1. CAB ASSEMBLY 148
FIGURE 6-2. CAB INTERIOR ASSEMBLY 152
FIGURE 6-3. SEAT ASSEMBLY 154
FIGURE 6-4. CAB WINDOWS 156
FIGURE 6-5. CAB DOOR ASSEMBLY 158
FIGURE 6-6. WIPER ASSEMBLY (Prior to SN 1160005646) 160
FIGURE 6-7. WIPER ASSEMBLY (SN 1160005646 to Present) 162
FIGURE 6-8. AIR CIRCULATION INSTALLATION 164

SECTION 7 - CONTROLS 167

FIGURE 7-1. BOOM JOYSTICK 168
FIGURE 7-2. STEERING COLUMN AND ATTACHING PARTS 170
FIGURE 7-3. ACCELERATOR PEDAL ASSEMBLY 172
FIGURE 7-4. BRAKE PEDAL ASSEMBLY 174

SECTION 8 - HYDRAULIC CIRCUITS 177

FIGURE 8-1. SUPPLY CIRCUIT 178
FIGURE 8-2. DUMP CIRCUIT 182
FIGURE 8-3. FRONT DRIVE CIRCUIT (266, 266 LOPRO, 26.6 & 26.6LP) 186
FIGURE 8-4. FRONT DRIVE CIRCUIT (307 & 30.7) 188
FIGURE 8-5. STEER SELECT 190
FIGURE 8-6. SERVICE/PARK BRAKE 192
FIGURE 8-7. LIFT CYLINDER 194
FIGURE 8-8. CROWD CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 196
FIGURE 8-9. CROWD CYLINDER (307 & 30.7) 198
FIGURE 8-10. TILT AND TILT COMPENSATING CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 200
FIGURE 8-11. TILT AND TILT COMPENSATING CYLINDER (307 & 30.7) 202
FIGURE 8-12. AUXILIARY FUNCTION (266, 266 LOPRO, 26.6 & 26.6LP) 204
FIGURE 8-13. AUXILIARY FUNCTION (307 & 30.7) 206
FIGURE 8-14. REAR HYDRAULIC OUTLET 208

SECTION 9 - HYDRAULIC COMPONENTS 211

FIGURE 9-1. LIFT CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 212
FIGURE 9-2. LIFT CYLINDER (307 & 30.7) 214
FIGURE 9-3. CROWD CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 216
FIGURE 9-4. CROWD CYLINDER (307 & 30.7) 218
FIGURE 9-5. TILT CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 220
FIGURE 9-6. TILT CYLINDER (307 & 30.7) 222
FIGURE 9-7. COMPENSATING CYLINDER (266, 266 LOPRO, 26.6 & 26.6LP) 224
FIGURE 9-8. COMPENSATING CYLINDER (307 & 30.7) 226
FIGURE 9-9. FORK LOCKING CYLINDER 228
FIGURE 9-10. FORK LOCKING CYLINDER ASSEMBLY 230
FIGURE 9-11. MAIN CONTROL VALVE (266;26.6 Prior to SN 1160003518; 307;30.7 Prior to SN 1160003514; 266 LoPro;26.6 LP Prior to SN 1160003525) 232
FIGURE 9-12. MAIN CONTROL VALVE (266;26.6 SN 1160003518 to Present; 307;30.7 SN 1160003514 to Present; 266 LoPro;26.6 LP SN 1160003525 to Present) 234
FIGURE 9-13. FRONT DRIVE MOTOR (266, 266 LOPRO, 26.6 & 26.6LP) 236
FIGURE 9-14. FRONT DRIVE MOTOR (307 & 30.7) 238
FIGURE 9-15. HYDROSTATIC TRANSMISSION PUMP 240
FIGURE 9-16. HYDRAULIC TANK ASSEMBLY 242
FIGURE 9-17. IMPLEMENT PUMP 244
FIGURE 9-18. AUXILIARY DIVERTER VALVE 246

SECTION 10 - ELECTRICAL 249

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >

FIGURE 10-1. ELECTRICAL INSTALLATION 250
FIGURE 10-2. ENGINE HARNESS (266 & 26.6 Prior to SN 1160002246; 307 & 30.7 Prior to SN 1160002233; 266 LoPro & 26.6 LP Prior to SN 1160002238) 254
FIGURE 10-3. ENGINE HARNESS (266 & 26.6 SN 1160002246 to Present; 307 & 30.7 SN 1160002233 to Present; 266 LoPro & 26.6 LP SN 1160002238 to Present) 256
FIGURE 10-4. REAR CHASSIS HARNESS (Prior to SN 1160001559) 258
FIGURE 10-5. REAR CHASSIS HARNESS (SN 1160001559 to Present) 260
FIGURE 10-6. FRONT CHASSIS HARNESS 262
FIGURE 10-7. PWM VALVE CONTROLLER ASSEMBLY 264
FIGURE 10-8. ROOF HARNESS 266
FIGURE 10-9. MAIN HARNESS (Prior to SN 1160001559) 268
FIGURE 10-10. MAIN HARNESS (SN 1160001559 to Present) 272
FIGURE 10-11. GROUND HARNESS 276
FIGURE 10-12. BUCKET SHAKE SWITCH 278
FIGURE 10-13. LMIS INSTALLATION 280
FIGURE 10-14. LMIS AUDIBLE TOWER/BEACON INSTALLATION 284
FIGURE 10-15. LSI SWITCH 286
FIGURE 10-16. LMI OPTION 288

SECTION 11 - DECALS 291

FIGURE 11-1. FRAME AND BOOM DECALS 292
FIGURE 11-2. CAB DECALS 296
FIGURE 11-3. MACHINE DECALS, 266 AND 266 LOPRO 300
FIGURE 11-4. MACHINE DECALS, 307 302
FIGURE 11-5. MACHINE DECALS, 26.6 AND 26.6 LP 304
FIGURE 11-6. MACHINE DECALS, 30.7 306

SECTION 12 - OPTIONS 309

FIGURE 12-1. HITCH KIT ASSEMBLY 310
FIGURE 12-2. AUTOMATIC HITCH ASSEMBLY 312
FIGURE 12-3. HYDRAULIC HITCH INSTALLATION 314
FIGURE 12-4. FRONT CAB GLASS SHIELD 318
FIGURE 12-5. CAB WORKLIGHT INSTALLATIONS 320
FIGURE 12-6. BOOM WORKLIGHT INSTALLATION 322
FIGURE 12-7. ROTATING BEACON INSTALLATION 324
FIGURE 12-8. AIR CONDITIONER INSTALLATION (Prior to SN 1160004769) 326
FIGURE 12-9. AIR CONDITIONER INSTALLATION (SN 1160004769 to Present) 328
FIGURE 12-10. WHEEL CHOCK INSTALLATION 330
FIGURE 12-11. DRAW BAR COUPLING INSTALLATION 332
FIGURE 12-12. DUAL BOOM AUX HYDRAULIC, MANUAL 334
FIGURE 12-13. DUAL BOOM AUX HYDRAULIC, ELECTRICAL 336
FIGURE 12-14. 6 TON HITCH INSTALLATION 338
FIGURE 12-15. 14 TON HITCH INSTALLATION 340
FIGURE 12-16. SPEEDOMETER INSTALLATION 342
FIGURE 12-17. SUN SCREEN INSTALLATION 344
FIGURE 12-18. GROUND WIRE INSTALLATION (Prior to SN 1160002125) 346
FIGURE 12-19. DUMP VALVE INSTALLATION 348
FIGURE 12-20. BOOM AUXILIARY ELECTRIC 350
FIGURE 12-21. HYDRAULIC TRAILER BRAKES 266, 266 LOPRO, 26.6, 26.6 LP 352
FIGURE 12-22. HYDRAULIC TRAILER BRAKES 307, 30.7 354
FIGURE 12-23. OPTION HARNESS 358
FIGURE 12-24. PRESSURE MODULATOR VALVE 360
FIGURE 12-25. PITON FLXE HITCH INSTALLATION 362

SECTION 13 - RECOMMENDED SPARE PARTS 365

FIGURE 13-1. RECOMMENDED SPARE PARTS 366

PART NUMBER INDEX 369

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >

FIGURE 3-9. BALE HANDLER

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	0240117	1	BALE HANDLER, TUBE TYPE, (CE), (includes items 1 thru 11)	A
1		Ref	WELDMENT	
2	N.S.S.	1	ATTACH WELDMENT, (includes items 23 thru 26)	
4	7029345	8	HEX HD CAPSCREW, M12X45-8.8	
5	7029346	4	STRAP	
6	7029347	1	TUBE ARM, LEFT	
7	7029348	1	TUBE ARM, RIGHT	
8	7029349	8	FLAT WASHER, M12	
9	7029350	8	HEX LOCKNUT, M12-8	
10	7029351	4	HEX HD CAPSCREW, M22X180-8.8	
11	7029352	4	HEX LOCKNUT, M22-8	
23	7029353	4	PLATE	
24	7029354	4	U-BOLT	
25	7029355	8	HEX HD CAPSCREW, M16X130-8.8	
26	7029356	16	HEX LOCKNUT, M16-8	
	0240118	1	BALE HANDLER, SPIKE TYPE, (CE), (includes items 101 thru 103)	A
101		Ref	WELDMENT	
102	7029344	1	ATTACH WELDMENT, (includes items 113 thru 116)	
103	7029357	8	SPIKE	
113	7029353	4	PLATE	
114	7029354	4	U-BOLT	
115	7029355	8	HEX HD CAPSCREW, M16X130-8.8	
116	7029356	16	HEX LOCKNUT, M16-8	
	2902440	1	SPIKE TYPE TO TUBE TYPE CONVERSION KIT, (CE), (includes items 4 thru 11)	A
	2902441	1	TUBE TYPE TO SPIKE TYPE CONVERSION KIT, (CE), (includes item 103)	A

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >

FIGURE 6-2. CAB INTERIOR ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1	8002820	1	IGNITION KEY SWITCH	
1	8008049	1	KEY, (ignition, cab door, rear cover and engine cover)	
2	3933128	1	HAZARD SWITCH	
3	2420207	1	TACH-FUEL-WATER DASHBOARD	
4	8002819	1	LMI INDICATOR	
5	2420212	2	BLANK PLATE	
5		Ref	TRAILER BRAKE INDICATOR, (optional), (See OPTIONS SECTION for Breakdown)	
6	4360596	1	HEAD-PARK LIGHT SWITCH	
7		Ref	JOYSTICK, (See CONTROLS SECTION for Breakdown)	
8	4360595	1	REAR WIPER-WASHER SWITCH	
9	4360602	1	JOYSTICK LOCKOUT SWITCH	
10	8004763	14	END SWITCH TRIM RING	
11	1359720	9	BLANK SWITCH PLATE	
12		Ref	CONTINUOUS AUXILLIARY HYDRAULIC SWITCH, (See CONTROLS SECTION for Breakdown)	
13	4360586	1	STEER MODE SWITCH	
14		Ref	PARKING BRAKE VALVE, (See HYDRAULIC CIRCUITS SECTION for Breakdown)	
15		Ref	SPEEDOMETER INSTALLATION, (optional), (See OPTIONS SECTION for Breakdown)	
15	1120593	1	PLUG, (Used in place of optional speedometer)	
16	1001005960	1	LOAD CHART HOLDER	
17	2920213	1	INTERIOR LIGHT ASSEMBLY	
18	1001093318	6	SCREW	
19	1001098150	6	WASHER	
22	1001094077	2	SCREW	
23	8466306	1	LEVEL INDICATOR GAUGE	
24	1001093319	8	SCREW	
26	7029486	3	SCREW	
27	7029538	1	FUSE COVER, (266, 307, 26.6, 30.7)	
27	7029564	1	FUSE COVER, (266 LoPro, 26.6 LP)	
29	7029560	1	ROOF LINING, (266, 307, 26.6, 30.7)	
29	7029561	1	ROOF LINING, (266 LoPro, 26.6 LP)	
30	1001093344	1	LEVEL INDICATOR BRACKET	
31	7029547	1	DASH COVER	
32	70020207	1	BOTTOM COVER	
33	70021477	1	FLOOR MAT	
34	1001096902	1	INSULATION	
34	0274916	1	AXLE CENTERING INDICATOR INSTALLATION, (includes item 101)	C
101	2420218	1	AXLE CENTERING INDICATOR	

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >

FIGURE 8-2. DUMP CIRCUIT

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
1		Ref	MAIN CONTROL VALVE, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
2	2143024	1	ELBOW, 90	
3	3460459	1	TUBE ASSY, (266, 26.6)	
3	3460460	1	TUBE ASSY, (307, 30.7)	
3	3460569	1	TUBE ASSY, (266 LoPro, 26.6 LP)	
4	2754407	1	HOSE ASSY, (266, 307, 26.6, 30.7)	
4	2754799	1	HOSE ASSY, (266 LoPro, 26.6 LP)	
5	2140221	1	CONNECTOR	
6		Ref	RETURN FILTER, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
7	2754252	1	HOSE ASSY, (266, 266 LoPro, 26.6, 26.6 LP)	
7	2754313	1	HOSE ASSY, (307, 30.7)	
8		Ref	DRIVE MOTOR, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
9	2754258	1	HOSE ASSY	
10	2142207	1	SWIVEL NUT RUN TEE	
11	2140827	1	CONNECTOR	
12	2754255	1	HOSE ASSY	
13	2754253	1	HOSE ASSY	
14	2143607	1	SWIVEL UNION	
15	1001094414	1	SWIVEL RUN TEE	
16		Ref	HYDROSTATIC TRANSMISSION PUMP, (See HYDRAULIC COMPONENTS SECTION for Breakdown)	
17	2754248	1	HOSE ASSY	
18	2140419	2	ELBOW, 90	
19	2754249	1	HOSE ASSY	
20	2140819	1	CONNECTOR	
21	2140921	1	CONNECTOR	
22	2120193	1	FILTER	
22	2120150	1	ELEMENT	
22	7020020	1	INDICATOR	
23	4641389	1	CHECK VALVE	
24	1321142	1	CLAMP	
27	2755065	1	HOSE ASSY **(266;26.6 Prior to SN 1160003812)**	
27	1001099001	1	HOSE ASSY **(266;26.6 SN 1160003812 to Present)**	
27	2755089	1	HOSE ASSY **(307;30.7 Prior to SN 1160003815)**	
27	1001099000	1	HOSE ASSY **(307;30.7 SN 1160003815 to Present)**	
27	2755077	1	HOSE ASSY **(266 LoPro;26.6 LP Prior to SN 1160003818)**	
27	1001098999	1	HOSE ASSY **(266 LoPro;26.6 LP SN 1160003818 to Present)**	
28	1062255	2	TIE STRAP	
32	2142708	1	CONNECTOR	
33	2140829	1	CONNECTOR, (266, 266 LoPro, 26.6, 26.6 LP)	
33	2140810	1	CONNECTOR, (307, 30.7)	
34	2754297	1	HOSE ASSY (266, 307, 26.6, 30.7)	
34	2754761	1	HOSE ASSY (266 LoPro, 26.6 LP)	
35	2142715	1	CONNECTOR	
36		Ref	STEERING VALVE, (See CONTROLS SECTION for Breakdown)	
37	2754302	1	HOSE ASSY (266, 307, 26.6, 30.7)	
37	2754762	1	HOSE ASSY (266 LoPro, 26.6 LP)	

MidWestTech | JLG 26.6, 26.6 LP, 266, 266 LoPro, 30.7, 307 Telehandler Parts Manual | P... Order the manual at mid-west-tech.com >