FORD

Service Manual

CL-25
COMPACT LOADER



40002510

Reprinted

MidWestTech | Ford CL-25 Compact Loader Service Manual | Publication 40002510 Order the manual at mid-west-tech.com >

SECTION 1
HYDRAULIC SYSTEM

HYDRAULIC CIRCUIT 1.1
- Specifications 1.1.1
- General information 1.1.2
- Control functions 1.1.3
- Maintenance schedule 1.1.4

GEAR PUMP 1.2
- Specifications 1.2.1
- General information 1.2.2
- Testing, Hydraulic pump flow 1.2.3
- Removal 1.2.4
- Disassembly and Inspection 1.2.5
- Start-up after repair 1.2.6

CONTROL VALVE 1.3
- Specifications 1.3.1
- General information 1.3.2
- Testing and adjusting relief valve 1.3.3
- Removal, Replacement 1.3.4
- Disassembly and Inspection 1.3.5
- Spool Seal Replacement 1.3.6

HYDRAULIC CYLINDERS 1.4
- Specifications 1.4.1
- General information 1.4.2
- Testing, Piston Seals 1.4.3
- Cylinder Removal 1.4.4
- Disassembly and Inspection 1.4.5

OIL FILTER 1.5
- Specifications 1.5.1
- General information 1.5.2
- Filter Replacement 1.5.3

OIL RESERVOIR 1.6
- Specifications 1.6.1
- General information 1.6.2
- Checking and adding oil 1.6.3

TROUBLE SHOOTING 1.7

MidWestTech | Ford CL-25 Compact Loader Service Manual | Publication 40002510 Order the manual at mid-west-tech.com >