

NEW HOLLAND

REPAIR MANUAL

TR96

TR97

TR98

Combines

NEW HOLLAND AGRICULTURE

SERVICE

40009630

Order the manual at mid-west-tech.com >

TR96, TR97, TR98 COMBINE REPAIR MANUAL CONTENTS

SECTION 0 - GENERAL AND SAFETY INFORMATION
SECTION 1 - ELECTRICAL SYSTEM
SECTION 2- HYDRAULIC SYSTEM
SECTION 3- MONITOR SYSTEM
SECTION 4- SEPARATOR CLUTCH
SECTION 5- ENGINE PTO
SECTION 6- FEEDER
SECTION 7- ROTOR DRIVE
SECTION 8- ROTORS
SECTION 9- ROTOR GEARBOXES
SECTION 10 - CONCAVES
SECTION 11 - SEPARATOR GRATES
SECTION 12 - DISCHARGE BEATER AND GRATE
SECTION 13 - CLEANING FAN
SECTION 14 - CLEANING SHOE
SECTION 15 - CLEAN GRAIN AND FILLING SYSTEM
SECTION 16 - TAILINGS SYSTEM
SECTION 17 - UNLOADING SYSTEM
SECTION 18 - MAIN SHAFT
SECTION 19 - HYDROSTATIC SYSTEM
SECTION 20 - TRANSMISSION
SECTION 21 - POWERED REAR AXLE
SECTION 22 - FINAL DRIVES
SECTION 23 - BRAKES
SECTION 24 - CYLINDERS

MidWestTech | New Holland TR96, TR97, TR98 Combine Service Manual | Publication 400... Order the manual at mid-west-tech.com >