NEW HOLLAND

Operator's Manual

FORD
NEW HOLLAND

Skid-Steer Loader
L-778



42077812

Reprinted

MidWestTech | New Holland L-778 Skid Steer Loader Operator's Manual | Publication 4207... Order the manual at mid-west-tech.com >

CAUTION!

1. AVOID STEEP HILLSIDE OPERATION.
2. KEEP BOOM AS LOW AS POSSIBLE WHILE OPERATING.
3. REDUCE SPEED WHEN TURNING AND AVOID ABRUPT STARTS AND STOPS.
4. BEFORE DISMOUNTING FROM LOADER
   MOVE CONTROL LEVERS TO NEUTRAL POSITION.
   SHUT OFF ENGINE AND REMOVE IGNITION KEY.
   ENGAGE BOOM LOCKS IF BOOM IS RAISED.
5. BE CAREFUL WHEN GETTING ON AND OFF LOADER.
6. **ALWAYS USE SEAT BELT WHEN OPERATING.**
7. WHEN PARKING THE LOADER ON ANY SLOPE, BLOCK THE WHEELS.
8. KEEP ALL SHIELDS AND GUARDS IN PLACE.

CONTENTS

DELIVERY REPORT 49

HYDRAULIC CIRCUIT CHART 35

MAINTENANCE AND ADJUSTMENTS
- Attachment "Quick Switch" 30
- Boom Lock Linkage 30
- Bucket and Boom Control Pedals 30
- Engine Speed and Governor Adjustment (Gas) 31
- Engine Speed (Diesel) 32
- Final Drive Chains 33
- Hydraulic System 33
- Left Side Drive Control 27
- Right Side Drive Control 28
- Throttle Control Handle 33

OPERATION
- Controls and Instrument Panel 6
- Field Operation 15
- Loader Operation 12
- Operating the New Engine 10
- Pre-Starting Check List 10
- "Quick Switch" Attachment Mounting System 14
- Starting the Loader 11
- Stopping the Loader 11
- Winching Valve 12

OPTIONAL EQUIPMENT AND REFERRAL ATTACHMENTS 43

PERIODIC SERVICE AND LUBRICATION CHART 18

PERIODIC SERVICE
- Air Cleaner 19
- Battery 19
- Chain Case 25
- Engine 21
- Gear Box 24
- Grease Points 22
- Hydraulic System 23
- Muffler 25
- Radiator and Oil Cooler 22
- Tires 19

SAFETY INFORMATION 5

SPECIFICATIONS 45

STORING THE LOADER 38

TROUBLE SHOOTING CHART 39

WIRING DIAGRAMS 36-37

MidWestTech | New Holland L-778 Skid Steer Loader Operator's Manual | Publication 4207... Order the manual at mid-west-tech.com >