570NXT
Tier 4
Tractor Loader

from PIN NCC570600

SERVICE MANUAL

Part number 47441594
1st edition English
September 2012

CASE CONSTRUCTION

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 47441594

Order the manual at mid-west-tech.com >

Contents

INTRODUCTION

Engine 10

Engine and crankcase 10.001

Fuel tanks 10.216

Engine cooling system 10.400

Exhaust Gas Recirculation (EGR) - Diesel Particulate Filter (DPF) exhaust treatment .. 10.501

Transmission 21

Power Shuttle transmission 21.112

Power Shuttle transmission external controls 21.134

Power Shuttle transmission internal components 21.154

Front axle system 25

Powered front axle 25.100

Front bevel gear set and differential 25.102

Final drive hub, steering knuckles, and shafts 25.108

Non-powered front axle 25.400

Rear axle system 27

Powered rear axle 27.100

Rear bevel gear set and differential 27.106

Planetary and final drives 27.120

Brakes and controls 33

Parking brake / Parking lock 33.110

Hydraulic service brakes 33.202

Hydraulic systems 35

Hydraulic systems 35.000

Pump control valves 35.102

Fixed displacement pump 35.104

Three-point hitch control valve 35.114

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >

Three-point hitch cylinder 35.116
Remote control valves 35.204
Reservoir, cooler, and filters 35.300
Safety and main relief valves 35.350
Front loader bucket hydraulic system 35.723
Tool quick coupler hydraulic system 35.734
Hitches, drawbars, and implement couplings 37
Rear three-point hitch external controls 37.108
Frames and ballasting 39
Frame 39.100
Ballasts and supports 39.140
Steering 41
Steering control 41.101
Hydraulic control components 41.200
Cylinders 41.216
Wheels 44
Front wheels 44.511
Rear wheels 44.520
Cab climate control 50
Air conditioning 50.200
Electrical systems 55
Electrical system 55.000
Harnesses and connectors 55.100
Engine starting system 55.201
Alternator 55.301
Battery 55.302
External lighting 55.404
Warning indicators, alarms, and instruments 55.408

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >

Cab/Platform harnesses and connectors 55.510
Cab engine controls 55.525
FAULT CODES 55.DTC
Front loader and bucket 82
Arm 82.100
Bucket 82.300
Platform, cab, bodywork, and decals 90
Machine shields and guards 90.105
Protections - ROPS and FOPS 90.114
Cab 90.150


MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >

Accumulator - General specification Ride control

Torque, accumulator charging valve cap	**1.1 N·m (10 lb in)**
Weight (approximate)	**4.9 kg (10.8 lb)**

Accumulator - Special tools Ride control

Nitrogen charging kit with regulator **380001737**



RCIL10TL001684AP 1

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >

Wire harnesses - Electrical schematic frame 07 Hydraulics

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 47441594
Order the manual at mid-west-tech.com >

3283-Sensor Supply Voltage 2 - High

NOTICE: *Check alternator output voltage. Troubleshoot charging system before proceeding.*

NOTE: *Besides the 3 independent 5V voltage supplies the ECU also provides a 12V supply for the sensors. This 12V supply is monitored to ensure it remains within a certain range. This is done by using an analog input of the ECU. The lower and upper thresholds depend on the battery voltage.*

Cause:

1. Faulty alternator output.
2. Faulty wiring.
3. Connectors not mated fully, pins not pushed into connector fully, bent pin or broken wire at rear of connector.
4. Faulty reading from ECU.

Solution:

1. Verify that the fault code is active.

   (1) Connect the Electronic Service Tool to the service tool connector.

   (2) To check for fault code: Start and operate machine.

   A. NOT OK – Fault code 3283 is recorded again. Go to Step **2**.

   B. OK – Fault is not recorded again. OK for return to service.

2. Measure the ECU unswitched input voltage

   (1) Turn ignition OFF. Disconnect Engine Control Unit (ECU) connector B from engine controller.

   (2) Inspect pins on Engine Control Unit (ECU) connector and on engine controller. Clean connections.

   (3) Turn the ignition ON.

   (4) Measure the voltage from pins 1, 3, 5, and 28 on ECU connector X-461 to ground (ECU connector X-461 pins 2, 4, and 6). The voltage should be between **11.5 V** and . **13 V**.

   A. NOT OK – Voltage is too high. Troubleshoot the charging system. Return to Step **1** to confirm elimination of fault.

   B. NOT OK – Voltage is to low. Verify battery voltage. Check fuses and wiring to ECU. Return to Step **1** to confirm elimination of fault.

   C. OK – Go to Step **3**.


3. Replace the engine control unit.

   (1) Remove and replace engine control unit.

   A. Return to Step 1 to confirm elimination of fault.

Wire harnesses - Electrical schematic frame 04 (55.100.DP-C.20.E.04)
Wire harnesses - Electrical schematic frame 05 (55.100.DP-C.20.E.05)

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >



RAL12FRK1170GA 2

F5C/F5H Tier 4a Fuel and Emission System – above 56kW

Component Locations:

- Black = Engine mounted
- Red = Vehicle mounted
- Blue = Exhaust pipe mounted

F5C/F5H Tier 4a Diesel Particulate Filter (DPF) System Components	
14. Turbocharger Compressor	30. Heated Exhaust Gas Oxygen Sensor (HEGO)
16. Intake Throttle Valve (TVA)	31. DOC Inlet Temperature Sensor
17. Exhaust Manifold Temperature Sensor (T3)	32. Diesel Oxidation Catalyst (DOC)
18. Exhaust Manifold Pressure Sensor (P3)	33. DPF Inlet Temperature Sensor
19. EGR Valve with Position Feedback	34. Diesel Particulate Filter (DPF)
20. Exhaust Gas Recirculation (EGR) Cooler	35. DPF Differential Pressure Sensor
23. Engine	44. Turbocharger Waste Gate Diaphragm
28. Waste Gate Turbo Pressure Modulator	45. Turbocharger Waste Gate Valve
29. Fixed Geometry Turbocharger Turbine	

MidWestTech | Case 570NXT Tier 4 Tractor Loader Service Manual | Publication 4744... Order the manual at mid-west-tech.com >

CONTACT CONFIGURATIONS

1-P. ST | 1-P. OT | D-P. ST | D-P. OT

MISCELLANEOUS SYMBOLS

FUSE | RELAY | GROUND | BATTERY

SYMBOLS

PRESSURE SWITCH | LAMP | MOTOR | DIODE

PRESSURE | TEMPERATURE | SPEAKER | LIGHT EMITTING DIODE (LED)

VARIABLE RESISTOR | RESISTOR | COIL

CIRCUIT DIAGRAM LEGENDS

WIRE BREAK OUT | WIRE ID | COLOR | WIRE SIZE | SPLICE

WB - WIRE ID BREAKOUT
FB - FUSE BREAKOUT
GB - GROUND BREAKOUT

SP-XXX — INDICATES CIRCUIT SPLICE

INDICATES CIRCUIT CONNECTION

INDICATES CIRCUIT CROSSING NOT CONNECTED

INDICATES INTERNALLY GROUNDED UNITS

STANDARD SYMBOLD/ LEGEND

POWER DISTRIBUTION/ CHARGING SYSTEM 1

STARTING SYSTEM 2

GROUNDING 3

ENGINE CONTROL 4

ENGINE CONTROL 5

DRIVES 6

HYDRAULICS 7

FRONT EXTERIOR LIGHTS 8

INTERIOR LIGHTING 9

WIPERS AND WASHERS 10

INSTRUMENT CLUSTER 11

POWER POINTS 12

SAHR PARK BRAKE 13

HVAC 14

570NXT
ELECTRICAL SCHEMATIC
RAC 47430251

LEGEND

INDICATES CONSTANT POWER

INDICATES POWER WHEN KEY SWITCH IS ON

INDICATES POWER WHEN KEY SWITCH IS IN START POSITION

INDICATES SWITCHED POWER FROM CONTROL RELAY #1

INDICATES SWITCHED POWER FROM CONTROL RELAY #2 and #3

RAC47430251S1S1

Order the manual at mid-west-tech.com >