621F, 721F
Waste Handling Wheel Loader
Tier 4A

Parts Catalog

Print No. 47525798
Issued II/2016

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.000.00		PICTORIAL INDEX - MAIN SECTIONS
00.000.21		PICTORIAL INDEX - TRANSMISSION
00.000.25		PICTORIAL INDEX - FRONT AXLE SYSTEM
00.000.33		PICTORIAL INDEX - BRAKES & CONTROLS
00.000.39		PICTORIAL INDEX - FRAMES AND BALLASTING
05.000.00		SECTION INDEX - MACHINE COMPLETION AND EQUIPMENT
05.100.01	01	INITIAL STOCKING LIST (ISL), 721F
05.100.01	04	INITIAL STOCKING LIST (ISL), 621F
05.100.03	01	FILTERS
05.100.03	01	FILTERS
05.100.03	01	FILTERS & CAPACITIES, 621F TIER 4A
10.000.00		SECTION INDEX - ENGINE
10.001.AD		ENGINE BLOCK HEATER
10.001.AK		ENGINE MOUNT
10.102.AA		COVERS, DRIVE BELT, WITH AIR CONDITIONING
10.202.AB		AIR CLEANER ASSY
10.202.AM		SYKLONE AIR PRECLEANER AND ADAPTER
10.206.AF		FUEL FILTER, SEPARATOR, WITHOUT HEAT
10.216.AI	01	FUEL TANK ASSEMBLY
10.216.AI	02	FUEL TANK COVER
10.216.AI	03	FUEL TANK COVER
10.218.AI		FUEL LINE INSTALLATION
10.254.AI		EXHAUST SYSTEM, MUFFLER AND INTAKE, TIER 4
10.310.AD		CHARGE AIR COOLER, HOSES AND TUBES
10.400.AA		FAN DRIVE ASSEMBLY
10.400.AY		RADIATOR HOSES AND TUBE INSTALLATION
10.400.BD		COOLANT RECOVERY SYSTEM
10.400.BE	01	COOLER INSTALLATION, STANDARD PACKAGE
10.400.BE	02	COOLER INSTALLATION, HD
10.408.AO	01	RADIATOR, CHARGE AIR COOLER INSTALLATION, STANDARD
10.408.AO	02	RADIATOR, CHARGE AIR COOLER INSTALLATION, HEAVY DUTY
10.418.AA		COOLER SCREEN INSTALLATION
10.500.AA	01	DEF TANK INSTALLATION
10.500.AA	02	DEF TANK ASSEMBLY
10.500.AA	03	DEF TANK INSTALLATION
21.000.00		SECTION INDEX - TRANSMISSION

MidWestTech | Case 621F, 721F Waste Handling Wheel Loader Parts Catalog | Public... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

41.910.AE	01	AUXILIARY STEERING PACKAGE
41.910.AE	02	AUXILLARY STEERING PACKAGE HOSES
41.910.AE	03	AUXILLARY STEERING PACKAGE
44.000.00		SECTION INDEX - WHEELS
44.511.AE		WHEEL ASSY
50.000.00		SECTION INDEX - CAB CLIMATE CONTROL
50.100.AC		HEATER LINES INSTALLATION
50.100.AI		HEATER INSTALLATION
50.100.AI		HEATER, INSTALLATION, CAB (NA)
50.100.AI	01	HEATER ASSEMBLY
50.100.AK		TEMPERATURE CONTROL ASSEMBLY
50.104.AC		FITTING INSTALL NO HEAT CANOPY
50.104.AC	01	FITTING INSTALL NO HEATER
50.104.AH		HEATER AND AIR CONDITIONING DUCTS
50.104.AH	01	HEATER AND AIR CONDITIONING DUCTS
50.104.AO	01	HEATER AND AIR CONDITIONING DUCTS, CAB
50.104.AO	02	HEATER AND AIR CONDITIONING DUCTS, CAB
50.200.AK	01	AIR CONDITIONING CONDENSER INSTALLATION
50.200.AK	02	AIR CONDITIONING, PLUMBING AND MOUNTING
50.200.BB		A/C CONDENSER LINE INSTALLATION
50.200.CA		AIR CONDITIONING WITH HEATER ASSEMBLY
50.200.CA	01	AIR CONDITIONING EVAPORATOR
55.000.00		SECTION INDEX - ELECTRICAL SYSTEM
55.020.AB	01	TRANSMISSION 4-SPEED, SPEED SENSOR, TEMPERATURE SENSOR, AND PUMP COVER
55.020.AB	02	TRANSMISSION 5-SPEED, SPEED SENSOR, TEMPERATURE SENSOR, AND PUMP COVER
55.020.AB	03	TRANSMISSION, 5-SPEED, SPEEDOMETER
55.024.AA	01	TRANSMISSION HARNESS INSTALLATION, Z-BAR AND XR/LR BAR
55.024.AA	02	TRANSMISSION HARNESS
55.051.AB		GRID HEATER INSTALLATION
55.100.04		HARNESS, TRANSMISSION
55.100.05		HARNESS INSTALLATION, TRANSMISSION
55.100.06		HARNESS INSTALLATION, FRONT CHASSIS
55.100.07		HARNESS, FRONT CHASSIS
55.100.08		HARNESS, BACKUP ALARM AND INSTALLATION
55.100.08		HARNESS, BACKUP ALARM AND INSTALLATION - EU LIGHTING
55.100.09	01	HARNESS, ENGINE AND REAR CHASSIS

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

55.100.09	01	HARNESS, ENGINE AND REAR CHASSIS, EU
55.100.09	02	HARNESS, ENGINE AND REAR CHASSIS
55.100.10		HARNESS, REAR RELAY PANEL
55.100.11	01	HARNESS INSTALLATION, ENGINE
55.100.11	02	HARNESS INSTALLATION, ENGINE
55.100.12	01	HARNESS, MAIN CAB
55.100.12	02	HARNESS, MAIN CAB
55.100.12	03	HARNESS, MAIN CAB
55.100.13		MAIN CAB AND CANOPY HARNESS FUSES AND RELAYS
55.100.14	01	HARNESS INSTALLATION, MAIN CANOPY COMPONENTS
55.100.14	02	HARNESS INSTALLATION, MAIN CAB COMPONENTS
55.100.15		RIGHT CONSOLE FUSE AND RELAY MOUNTING
55.100.16		RIGHT CONSOLE SWITCH INSTALLATION
55.100.17		HARNESS, CAB ROOF
55.100.18		HARNESS , CANOPY ROOF INSTALLATION
55.100.19		HARNESS, CAB BOTTOM
55.100.20		HARNESS, CAB BOTTOM INSTALLATION
55.100.21		HARNESS, CAB ROOF
55.100.22		HARNESS, CAB ROOF INSTALLATION
55.100.DO	01	HARNESS, RIGHT CONSOLE FUSE AND RELAY MOUNTING
55.100.DO	02	HARNESS, REAR RELAY PANEL
55.100.DP		HARNESS INSTALLATION, FRONT CHASSIS
55.201.AE		ENGINE STARTER INSTALLATION
55.301.AB		ALTERNATOR MOUNTING WITH AIR CONDITIONING
55.302.AG	01	BATTERY INSTALLATION, STANDARD
55.302.AG	02	BATTERY INSTALLATION, HEAVY DUTY
55.302.AV		BATTERY CABLE INSTALLATION
55.404.AC		BEACON ASSY, ROTATING, MOUNTING
55.404.AP		LIGHT GUARD INSTALLATION
55.404.BM		REAR LIGHT INSTALLATION
55.404.BS		WORK LIGHT, HIGH OUTPUT FRONT ONLY
55.415.AA	01	CONTROL, RETURN-TO-DIG (Z-BAR)
55.415.AA	02	CONTROL, RETURN-TO-DIG (XR)
55.415.AB	01	CONTROL, BUCKET HEIGHT AND RETURN-TO-TRANSPORT (Z-BAR LOADER)
55.415.AB	02	CONTROL, BUCKET HEIGHT AND RETURN-TO-TRANSPORT (XR LOADER)
55.415.AQ	01	JOYSTICK CONTROL INSTALLATION, LOADER CONTROL

MidWestTech | Case 621F, 721F Waste Handling Wheel Loader Parts Catalog | Public... Order the manual at mid-west-tech.com >