SERVICE MANUAL

T7.175 / T7.190 / T7.210
T7.175 AutoCommand™ / T7.190 AutoCommand™
T7.210 AutoCommand™ / T7.225 AutoCommand™
TIER 4B (FINAL)

Tractor

Part number 47936463
English
November 2015

NEW HOLLAND AGRICULTURE

© 2015 CNH Industrial Osterreich GmbH. All Rights Reserved.

Order the manual at mid-west-tech.com >

Contents

INTRODUCTION

Engine 10

[10.001] Engine and crankcase 10.1

[10.101] Cylinder heads 10.2

[10.216] Fuel tanks 10.3

[10.210] Lift pump and lines 10.4

[10.218] Fuel injection system 10.5

[10.202] Air cleaners and lines 10.6

[10.250] Turbocharger and lines 10.7

[10.254] Intake and exhaust manifolds and muffler 10.8

[10.500] Selective Catalytic Reduction (SCR) exhaust treatment 10.9

[10.400] Engine cooling system 10.10

[10.414] Fan and drive 10.11

[10.408] Oil cooler and lines 10.12

Clutch 18

[18.112] Slip clutch or flywheel damper 18.1

Transmission 21

[21.111] Semi-Powershift transmission 21.1

[21.133] Semi-Powershift transmission external controls 21.2

[21.103] Semi-Powershift transmission lubrication system 21.3

[21.152] Semi-Powershift transmission internal components 21.4

[21.113] Powershift transmission 21.5

[21.504] Continuously Variable Transmission (CVT) 21.6

[21.505] Continuously Variable Transmission (CVT) external controls 21.7

[21.506] Continuously Variable Transmission (CVT) lubrication system 21.8

[21.507] Continuously Variable Transmission (CVT) internal components 21.9

[21.160] Creeper 21.10

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >

[21.166] Overdrive 21.11

Four-Wheel Drive (4WD) system 23

[23.202] Electro-hydraulic control 23.1

[23.314] Drive shaft 23.2

Front axle system 25

[25.100] Powered front axle 25.1

[25.102] Front bevel gear set and differential 25.2

[25.108] Final drive hub, steering knuckles, and shafts 25.3

[25.122] Axle suspension control 25.4

Rear axle system 27

[27.100] Powered rear axle 27.1

[27.106] Rear bevel gear set and differential 27.2

[27.120] Planetary and final drives 27.3

[27.126] Spur gear and final drives 27.4

Power Take-Off (PTO) 31

[31.101] Rear mechanical control 31.1

[31.104] Rear electro-hydraulic control 31.2

[31.114] Two-speed rear Power Take-Off (PTO) 31.3

[31.116] Three-speed rear Power Take-Off (PTO) 31.4

[31.146] Front Power Take-Off (PTO) 31.5

Brakes and controls 33

[33.202] Hydraulic service brakes 33.1

[33.300] Pneumatic service brakes 33.2

[33.110] Parking brake or parking lock 33.3

[33.220] Trailer brake hydraulic control 33.4


[33.224] Trailer brake pneumatic control 33.5

Hydraulic systems 35


MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >

[35.000] Hydraulic systems 35.1
[35.300] Reservoir, cooler, and filters 35.2
[35.106] Variable displacement pump 35.3
[35.105] Charge pump 35.4
[35.220] Auxiliary hydraulic pump 35.5
[35.322] Regulated/Low pressure system 35.6
[35.204] Remote control valves 35.7
[35.114] Three-point hitch control valve 35.8
[35.160] Front hitch controls and lines 35.9
[35.162] Front hitch cylinders and lines 35.10
Pneumatic system 36
[36.100] Pneumatic system 36.1
Hitches, drawbars, and implement couplings 37
[37.110] Rear three-point hitch 37.1
[37.120] Rear three-point hitch linkage 37.2
[37.162] Front hitch 37.3
Frames and ballasting 39
[39.100] Frame 39.1
Steering 41
[41.101] Steering control 41.1
[41.106] Tie rods 41.2
[41.200] Hydraulic control components 41.3
[41.216] Cylinders 41.4
[41.432] Autoguidance steering 41.5
Wheels 44
[44.511] Front wheels 44.1
[44.520] Rear wheels 44.2
Cab climate control 50

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >



87747169 13




SVIL1878030444AA 14

Cab right-hand side behind operator's seat

T7.175, T7.190, T7.210, T7.225 AutoCommand
T7.175, T7.190, T7.210 – Sidewinder II

CONNECTOR X-082 - On harness 84167030			
PIN NUMBER	**WIRE NUMBER**	**CIRCUIT REFERENCE**	**ELECTRICAL SCHEMATIC FRAME**
1	FC-3271A (BL)	From X-082 to FC-SP-3271	**Wiring harnesses - Electrical schematic sheet 48 (55.100)**



82803289 15

T7.175, T7.190, T7.210 – Standard

CONNECTOR X-082 - On harness 82034348			
PIN NUMBER	**WIRE NUMBER**	**CIRCUIT REFERENCE**	**ELECTRICAL SCHEMATIC FRAME**
1	FC-3271 (RD)	From X-082 to FC-SP-3271A	**Wiring harnesses - Electrical schematic sheet 48 (55.100)**
2	FC-57FP (BK)	From X-082 to FC-SP-57F	


MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >

Wire connectors - Component diagram 55


CONNECTOR X-551 - Exhaust brake switch

T7.175, T7.190, T7.210, T7.225 AutoCommand
T7.175, T7.190, T7.210 – Sidewinder II

CONNECTOR X-551 - On harness 47754421			
PIN NUMBER	**WIRE NUMBER**	**CIRCUIT REFERENCE**	**ELECTRICAL SCHEMATIC FRAME**
1	CM-010AA (GN)	From X-551 to CM-SP-010	**Wiring harnesses - Electrical schematic sheet 15 (55.100)**
4	CM-2087 (OR)	From X-551 to **X-956**	



82918832 1



3VL15TR01940AA 2

Front left-hand side cab floor

T7.175, T7.190, T7.210 – Standard

CONNECTOR X-551 - On harness 47841698			
PIN NUMBER	**WIRE NUMBER**	**CIRCUIT REFERENCE**	**ELECTRICAL SCHEMATIC FRAME**
1	CM-010AA (GN)	From X-551 to CM-SP-010	**Wiring harnesses - Electrical schematic sheet 15 (55.100)**
4	CM-2087 (OR)	From X-551 to **X-956**	

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >

12024-Fault on ignition key

Control Module : EPL

NOTE: *When the cause of the error code has been rectified, clear the error code and test the system for normal operation.*

NOTE: *To electronically release and disable the Electronic Park Lock (EPL) when carrying out maintenance on the system, use the H1 calibrations menu in the XA module. Select* ***(SC)*** *and perform the accelerometer stroke calibration procedure but stop the process when* ***(M)*** *is displayed and turn the ignition switch OFF. For further information, refer to* ***Electronic park lock actuator/controller - H1 - Calibration procedures (55.031).***

If electronic release is not possible, remove the EPL cover and use the special tool supplied in the cab to manually disengage the EPL.

NOTE: *When clearing the stored memory in H8 in the XA module or installing a new EPL, make sure the correct EPL orientation is selected in H3 in the XA module, channel 3. Refer to* ***Electronic park lock actuator/controller - H3 - Configurations and options (55.031).***

Cause:
The fault triggering condition is 'always'.

Possible failure modes:

1. Faulty fuse F-015 (**20 A**)
2. Faulty fuse F-051 (**25 A**)
3. Faulty connector
4. Faulty wire harness
5. Faulty EPL assembly


Solution:

1. Make sure the machine is parked on a level surface and chock the front wheels using suitable wheel stops.
   A. Continue to Step **2**.
2. Check for other error codes being displayed.
   A. If any other error code is being displayed, continue to these tests.
   B. If no other error code is displayed, continue to Step **3**.
3. Before proceeding clear the error code using either the on board HH menu or approved diagnostic equipment. Turn the ignition switch OFF, wait for 5 seconds and then turn the ignition switch ON. Operate the system and check for the error code.
   A. If the error code is not indicated, check that the system is operating correctly.
   B. If the error code is indicated, continue to Step **4**.
4. Check the EPL connector **X-745**. Ensure the connector is connected, not damaged, the pins are in the correct position and that the fit is tight.
   A. If a fault is indicated, repair or replace as required.
   B. If the connectors are okay, continue to Step **5**.
5. Check the stop lamps fuse F-015 (**20 A**) and the EPL fuse F-051 (**25 A**).
   A. If the fuse(s) is blown, replace the blown fuse(s) and retest.
   B. If the fuse(s) is okay, continue to Step **6**.
6. Check for **12 V**.

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >

Step 5c. Accumulator Test Procedure:


- On the DATAR Scope, in the bottom left corner, verify the capture trigger is "ready" to start capturing data. This is indicated with a green ball highlighted in blue as shown in the figure to the right. If the scope is not ready, then press the keyboard SPACE bar to change the scope trigger state to ready.
- Press and hold the DOWN SHIFT button on the transmission shift lever to run the accumulator test. The machine display will count up from 1 to 10. When the test is finished the display will show "END". This test will take about 15 seconds.



BAIL11CCM283AVA 49

NOTE: *The accumulator test can only be run if "ACC" is selected in step 3 above. Only the down shift button is used with this test.*

- On the DATAR Scope, when the test ramp is finished, then press the PC SPACE bar to capture and hold the result trace.
- Compare the DATAR measured trace with the expected result trace shown on the next Valve Test Assistant screen. (Remember ALT-TAB to switch between the programs)



BAIL11CCM284AVA 50

NOTE: *During the ACC test, the machine software makes five quick engagements of the L, M, H clutches.*

Step 6. Save the waveform in DATAR Scope:

- On the DATAR scope, go to the FILE menu and select one of the SAVE options to store the waveform on the PC (e.g. Save Current Waveform).


NOTE: *It is recommended that you save the waveform so that you can refer to this historical data in the future for this machine serial number.*

Unexpected Conditions

If the test conditions are not correct then the following fault codes will be displayed:

Code	Error
CL	Transmission oil temperature is below **45 °C** (**113 °F**)
CH	Transmission oil temperature is above **55 °C** (**131 °F**)
U17	Seat switch not activated (Operator not in seat)
U20	Handbrake not applied
U21	Engine speed is below **1100 RPM**
U22	Engine speed is above **1300 RPM**
U23	Shuttle lever is in neutral, shift to forward
U26	Clutch pedal is not fully up, release clutch pedal
U127	Transmission oil temperature is below **10 °C** (**50 °F**)
U128	Transmission oil temperature is above **105 °C** (**221 °F**)

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >



BAIL13TR00581FA 6

Waveform notes (with load applied)


The example waveform shows the same test, but with load applied (dyno test).

During the example waveform the tractor is started and run at idle for approximately 20 seconds. It is then increased to maximum RPM and dyno tested. Once the dyno test has finished the engine RPM was increased to maximum and then returned to idle at the end of the trace.

The fuel rail pressure signal has been annotated to aid analysis

1. Engine at low idle
2. Engine at maximum RPM
3. Dyno engaged
4. Dyno auto run started
5. Fuel rail pressure gradually increases as engine load increases
6. Fuel rail pressure starts to drop off as engine rpm falls due to dyno load
7. Test finished and engine goes back to maximum RPM, rail pressure returns to high RPM pressure
8. Engine is returned to idle for cool down before being keyed off, rail pressure falls to idle pressure

MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tr... Order the manual at mid-west-tech.com >



MidWestTech | New Holland T7.175, T7.190, T7.210, T7.225 AutoCommand Tier 4B Tractor Service Manual | Publication 47936463
Order the manual at mid-west-tech.com >