921C
Wheel Loader

Parts Catalog
ASN JEE0155001

Print No. 530100069PC
Issued 9/2016

CASE
CONSTRUCTION

MidWestTech | Case 921C Wheel Loader Parts Catalog | Publication 530100069PC
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0. 0039	SERVICE MAINTENANCE KIT (Sep 14 2007 6:29AM)
0. 0039	SERVICE MAINTENANCE KIT (Sep 14 2007 6:40AM)
02-01	RADIATOR - MOUNTING
02-01	RADIATOR MOUNTING - COOLER, CHARGE AIR
02-02	MOUNTING, ENGINE (Apr 8 2011 4:45PM)
02-02	MOUNTING, ENGINE (Dec 17 2009 3:29PM)
02-02A	COOLER, CHARGE AIR - HOSES, CONNECTING
02-03	FAN - MOUNTING
02-04	COOLANT RECOVERY SYSTEM
02-04	TANK, SURGE - MOUNTING AND CONNECTIONS
02-05	AIR CLEANER - AIR INTAKE PARTS (Apr 8 2011 2:49PM)
02-05	AIR CLEANER - AIR INTAKE PARTS (Dec 17 2009 4:31PM)
02-06	AIR CLEANER ASSY (Feb 15 2005 4:18PM)
02-06	AIR CLEANER ASSY (Sep 8 2003 9:30AM)
02-07	MUFFLER - EXHAUST SYSTEM (Nov 12 2008 1:25PM)
02-07	MUFFLER - EXHAUST SYSTEM (Nov 19 2008 2:30PM)
02-08	OIL DRAIN
02-08	WATER PUMP SYSTEM
02-09	FRONT GEAR COVER
02-09	OIL PRESSURE SENDER
02-10	REMOTE OIL GAUGE
02-10	TURBOCHARGER SYSTEM - MANIFOLDS
02-11	TURBOCHARGER ASSY
02-12	WASTEGATE ACTUATOR
02-13	FILTER AND COOLER - OIL
02-14	OIL PUMP, PAN - HEATER
02-15	CYLINDER HEAD - COVER
02-16	THERMOSTAT - FILTER, WATER
02-17	CRANKCASE, BREATHER - ALTERNATOR MOUNTING
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	CAMSHAFT
02-20	CYLINDER BLOCK
02-21	CRANKSHAFT
02-22	FLYWHEEL AND HOUSING
02-23	PISTONS - CONNECTING RODS
02-24	GASKET KIT (Jul 21 2006 10:41AM)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-24	GASKET KIT (Mar 7 2011 3:15PM)
02-25	GASKET KIT
03-01	CONTROLS - THROTTLE, FOOT (Apr 2 2008 8:25AM)
03-01	CONTROLS - THROTTLE, FOOT (Nov 26 2008 7:37AM)
03-01A	PEDAL ASSY - THROTTLE, FOOT
03-02	FUEL TANK FILLER - SENDER
03-03	FUEL LINES - FILTER, FUEL
03-03	FUEL LINES - FILTER, IN-LINE FUEL
03-04	COOLER - FUEL
03-05	FUEL INJECTION SYSTEM
03-06	ANEROID AND WASTEGATE SYSTEM
03-07	FUEL FILTER - PUMP, FUEL TRANSFER
03-08	FUEL INJECTION - PUMP AND DRIVE
03-09	FUEL INJECTION NOZZLE
04-01	ALTERNATOR ASSY (Jul 12 2010 11:44AM)
04-01	ALTERNATOR ASSY (Jul 15 2010 11:38AM)
04-02	STARTER ASSY (Sep 13 2010 11:20AM)
04-02	STARTER ASSY (Sep 14 2010 9:08AM)
04-02A	SOLENOID - STARTER
04-03	PANEL, CONTROL
04-04	PANEL, CONTROL
04-04A	HARNESS - COUPLER
04-05	HARNESS, FRONT - LAMPS AND SWITCHES (Mar 11 2010 9:50AM)
04-05	HARNESS, FRONT - LAMPS AND SWITCHES (Nov 11 2008 10:49AM)
04-06	HARNESS - PEDESTAL (Nov 10 2011 4:23PM)
04-06	HARNESS - PEDESTAL (Nov 10 2011 4:27PM)
04-07	HARNESS - CANOPY ROOF
04-08	HARNESS - CAB ROOF
04-09	HARNESS - CAB, MAIN (Dec 1 2008 3:43PM)
04-09	HARNESS - CAB, MAIN (Dec 4 2008 2:13PM)
04-10	HARNESS - CANOPY, MAIN
04-11	HARNESS - RIDE CONTROL
04-12	HARNESS, REAR (Aug 27 2008 2:43PM)
04-12	HARNESS, REAR (Dec 4 2008 2:19PM)
04-13	HARNESS, REAR CHASSIS (Dec 18 2009 9:45AM)
04-13	HARNESS, REAR CHASSIS (Sep 25 2007 1:25PM)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-13A	HARNESS, FAN
04-14	HARNESS, REAR - RELAY PANEL (Nov 11 2008 10:49AM)
04-14	HARNESS, REAR - RELAY PANEL (Nov 30 2009 2:42PM)
04-15	BATTERY - CABLES (Sep 9 2010 2:45PM)
04-15	BATTERY - CABLES (Sep 14 2010 9:09AM)
04-15A	ALTERNATOR - MOUNTING
04-16	ELECTRICAL - STEERING, AUXILIARY
04-16	ELECTRICAL STEERING, AUXILIARY
04-17	MOUNTING - LAMPS, FRONT
04-17A	MOUNTING - LAMPS, FRONT - IF USED (Jul 20 2009 3:10PM)
04-17A	MOUNTING - LAMPS, FRONT - IF USED (Nov 19 2008 11:24AM)
04-17B	MOUNTING - LAMPS, FRONT (Nov 13 2008 2:50PM)
04-17B	MOUNTING - LAMPS, FRONT (Nov 20 2008 9:15AM)
04-18	LAMPS, FRONT
04-18A	LAMP ASSY - LAMP, FRONT - IF USED
04-19	LAMP - TURN SIGNAL
04-20	LAMPS - CLEARANCE, FRONT AND REAR (Nov 30 2009 2:27PM)
04-20	LAMPS - CLEARANCE, FRONT AND REAR (Sep 8 2003 12:37PM)
04-21	MOUNTING - BACKUP ALARM AND REAR LAMP (Dec 18 2009 9:45AM)
04-21	MOUNTING - BACKUP ALARM AND REAR LAMP (Nov 30 2009 2:42PM)
04-22	MOUNTING - BACKUP ALARM (Dec 18 2009 9:45AM)
04-22	MOUNTING - BACKUP ALARM (Nov 30 2009 2:42PM)
04-23	MOUNTING - LAMPS, REAR COMBINATION (Dec 18 2009 2:12PM)
04-23	MOUNTING - LAMPS, REAR COMBINATION (Nov 30 2009 3:04PM)
04-23A	MOUNTING - LAMPS, REAR COMBINATION
04-24	LAMP ASSY, COMBINATION
04-25	LAMP, LICENSE PLATE (Nov 30 2009 1:46PM)
04-25	LAMP, LICENSE PLATE (Nov 30 2009 3:12PM)
04-26	LAMP ASSY, FRONT AND REAR
04-27	LAMPS - TURN SIGNAL, FLASHER, STOP AND TAIL
04-28	BEACON ASSY, ROTATING - MOUNTING
04-29	BEACON ASSY, ROTATING - MOUNTING
04-30	HARNESS - CIGAR LIGHTER (Sep 15 2006 10:17AM)
04-30	HARNESS - CIGAR LIGHTER (Sep 15 2006 10:20AM)
04-31	CAB - WIPER, FRONT
04-32	CAB - WIPER, REAR

Order the manual at mid-west-tech.com >

AXLE, FRONT - HUB, DISC BRAKES

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		298445A2		1	FRONT AXLE Front, With Limited Slip; Includes Figures 06-19 - 06-21A; Replaced By 87313936
		87313936		1	FRONT AXLE Front, With Limited Slip; Includes Figures 06-19 - 06-21A; Same As 298445A2 Except Oil Filled
		87358597		1	FRONT AXLE ZF No 4474 054 047; See Figure 06-18 - 06-21; Same As 87313936 Except Wheel End/A And Brake Disc
		437374A2		2	GEAR REDUCTION UNIT Replaced By 87441327
		87441327		2	END ASSY. End Assy. Incl. Ref 1 - 15; Includes Figures 06-20A; Also Includes Ref Shaft Shims On Figure 06-19; Replaces 437754A2 End Assy.
		87358692		2	END ASSY. End Assy. Incl. Ref 1 - 15; Includes Figures 06-20A; Also Includes Ref Shaft Shims On Figure 06-19; Replaces 87441327 End Assy.
1		8603165		1	PISTON Brake
2		8605314		1	SEAL 298mm ID x 310mm OD x 8mm Thk
3		8603577		1	RING Piston Seal Support; Replaces 384317A1
4		8605315		1	SEAL U-Ring
5		8603579		1	RING Piston Seal Support; Replaces 384319A1
6		8603580		1	SNAP RING Brake Piston Guide; Replaces 384321A1
		87365254		1	REPAIR KIT Standard Brake Pack; Incl. Refs. 7, 8A, 8B
		87482112		1	REPAIR KIT Bronze Brake Upgrade, Front Axle; Incl. Refs. 1 - 5, (2) 8A, 12, 15, (12) 8603163 Adjuster Pins, (18) 87521419 2.4 mm Separator Plates, and (14) 87521418 Bronze Brake Discs; Not Illustrated

MidWestTech | Case 921C Wheel Loader Parts Catalog | Publication 530100069PC Order the manual at mid-west-tech.com >

CANOPY, ROPS - COVERS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			NORTH AMERICA ONLY
1		399194A1		1	COVER
		{}			Control, Tan
		{}			See Figure 9-159, REF 09-34 for wrist support components
2		239105A1		16	SCREW Cross Pan Hd, M6 x 20mm
2A		833-40306		2	SPRING NUT M6, U No Longer used with Canopies with Glass
3		1990502C1		14	WASHER 1/4 x 13/16 x 1/16 in
4		333631A2		1	COVER Front Cover; No Longer Used With Canopies With Glass
		{}			Front Cover
5		361331A3		1	PANEL
		{}			Console
6		294765A2		1	COVER
		{}			Floor
7		239105A1		8	SCREW Cross Pan Hd, M6 x 20mm
8		1990503C1		8	WASHER
9		324533A2		1	COVER
		{}			Harness Access
10		297850A1		4	SCREW Cross Pan Hd, M6 x 16
11		297865A1		2	WASHER 6.6mm ID x 12mm OD x 1.6mm Thk M6
12		380766A2		1	PANEL
		{}			Access
13		187787C1		2	SEALING STRIP 600 mm (23-5/8 in)
		{}			Access Panel
		{}			Top
		{}			Cut From 180624C1
14		187782C1		2	SEALING STRIP
		{}			Access Panel
		{}			Side
15		297850A1		6	SCREW Cross Pan Hd, M6 x 16
16		1990502C1		6	WASHER 1/4 x 13/16 x 1/16 in

821C-CASE WHEEL LOADER (S/N JEE0155001 & AFTER) 921C-CASE WHEEL LOADER (S/N JEE0155001 & AFTER)

Order the manual at mid-west-tech.com >

DECALS - NORWEGIAN, SWEDISH

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION REF 6 USED FOR ALL
6		87358697		1	TAG DECAL Do Not Operate
		{}			NORWEGIAN
1		E133921		1	DECAL
		{}			Transmission Oil Level
2		124275A1		1	DECAL
		{}			Do Not Jump
		{}			If Used
2A		386241A1		1	WARNING DECAL
		{}			Do Not Jump
		{}			If Used
3		316034A1		1	DECAL
		{}			Fuse Location
4		315110A2		1	DECAL
		{}			Maintenance Chart
5		412476A1		2	DECAL
		{}			Jump Start
		{}			SWEDISH
1		E133807		1	DECAL
		{}			Transmission Oil Level
2		124274A1		1	DECAL
		{}			Do Not Jump
		{}			If Used
2A		386241A1		1	WARNING DECAL
		{}			Do Not Jump
		{}			If Used
3		316020A1		1	DECAL
		{}			Fuse Location
4		315105A2		1	DECAL
		{}			Maintenance Chart
5		412476A1		2	DECAL
		{}			Jump Start

821C-CASE WHEEL LOADER (S/N JEE0155001 & AFTER) 921C-CASE WHEEL LOADER (S/N JEE0155001 & AFTER)

Order the manual at mid-west-tech.com >