TM 09135C-OI

TEREX®

SHOP MANUAL

Document 57.4400.8200 - Rev. 0A 07/2007

Light Capability Rough Terrain Forklift (LCRTF)

TX 51-19MD

CONTRACT NO. SP050001D0044D.O.0024



From serial n. ***700000***
To serial n. ***xxxxxx***

PCN 500 091352 00

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Publication 57.4400.8200_070701
Order the manual at mid-west-tech.com >

Section 1 - Introduction

1.0 Introduction 3
1.1 Symbols 4

Section 2 - Safety Rules

2.0 Safety Rules 7
2.1 General 7
2.2 Operators Maintenance Staff Responsibilities 7
2.3 Clothing 7
2.4 Personal Equipment 8
2.5 Safety Precautions 8
2.6 Getting Ready to Work 8
2.7 During Work or Maintenance 8

Section 3 - General Information and Specification

3.0 Machine References 13
3.1 Machine Position 13
3.2 Labels and Warning Decals 14
3.3 Explanation of the Different Symbols 19
3.4 Machine Model and Type 20
3.5 Manufacturer 20
3.6 Machine Identification 20
3.7 Chassis Serial Number 21
3.8 Identification Plates 21
3.9 Allowed Use 21
3.10 Improper Use 21
3.11 Applicable Standards 22
3.12 List of Main Components 22
3.13 Description of Main Components 23
3.14 Optional Accessories 23
3.15 Technical Data and Performance 24

Section 4 - Controls and Instruments

4.0 Preoparation, Inspection and Adjustments 29
4.1 Adjusting the Seat 29
4.2 Fastening the Seat Belts 30
4.3 Adjusting the Rear View Mirrors 30
4.4 Controls and Operations 32
4.5 Controls and Instruments 33
4.6 Control Description 34
4.7 Control Lever 43
4.8 Operating the Control Lever 44
4.9 Tilting the Forks Forward and Rearward 45
4.10 Side Shifting the Forks 46
4.11 Rotating the Forks 47
4.12 Quick-Coupling the Fork Attachment 48

Section 5 - Pre-operation Inspection and Adjustment

5.0 Pre-operation Inspection and Adjustment 51
5.1 Pre-operation Inspection and Check List 51
5.2 Starting the Engine 51
5.3 Jump-Starting the Engine 52
5.4 Battery Disconnect Switch 52
5.5 Stopping / Parking Machine 53
5.6 Refueling the Machine 53

Section 6 - Lubrication

6.0 Lubrication 57
6.1 Lubricant Specification 57
6.2 Lubricant Chart 58
6.3 Lube and Fluid Capacity Chart 59

Section 7 - Preventive Maintenance

7.0 Preventive Maintenance 63
7.1 Using the Suggested Schedule Check Sheet . 63
7.2 50 Hours or Weekly Services 65
7.3 250 Hours or Monthly Services 66
7.4 500 Hours or Quarterly Services 67
7.5 1000 Hours or Semi-Annually Services 68
7.6 3000 Hours or Three Years Services 69

Section 8 - 50 Hours or Weekly Maintenance

8.0 50 Hours Or Weekly Maintenance 73
8.1 Check Engine Oil 73
8.2 Drain Engine Fuel Filter 73
8.3 Check Hydraulic Reservoir Oil 74
8.4 Check Brake Oil Reservoir Level 74
8.5 Lube Boom Pads 74
8.6 Lube Drive Shaft 75
8.7 Lube Axle King Pins 75
8.8 Lube Axle Rear Pivot Pin 75
8.9 Lube Cylinders 75
8.10 Lube Fork Attachments 76
8.11 Lube Boom Pivot 76
8.12 Check Tire Inflation 76
8.13 Check Tire Wheel Nuts 76
8.14 Check Drive Shaft Bolts 77

Section 9 - 250 Hours or Monthly Maintenance

9.0 250 Hours Or Monthly Maintenance 81
9.1 Engine and Hydraulic Oil Sampling 81
9.2 Check Engine Air Filter 81
9.3 Check Engine Drive Belts 82
9.4 Check Axle Wheel Ends Oil 82
9.5 Check Axle Differential Oil 83
9.6 Check Battery 83

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

Section 10 - 500 Hours or Quarterly Maintenance

10.0 500 Hours or Quarterly Maintenance Checks . 87
10.1 Change Engine Oil 87
10.2 Change Engine Oil Filter 88
10.3 Change Engine Air Filter (external cartridge) ... 89
10.4 Change Engine Fuel Filter 90
10.5 Check Engine Glow Plugs 91
10.6 Change Hydraulic Reservoir Filter 91

Section 11 - 1000 Hours or Semi-Annually Maintenance

11.0 1000 Hours or Semi-Annually Maintenance ... 95
11.1 Check Engine Valve Tip Clearance 95
11.2 Check Electrical Alternator 95
11.3 Check Electrical Starter 95
11.4 Check Electrical System 96
11.5 Check Hydraulic Hoses and Fitting 96
11.6 Change Hydraulic Reservoir Oil Filter, Cleaning Hydraulic Magnet 96
11.7 Change Axle Wheel End Oil 97
11.8 Change Axle Differential Oil 97
11.9 Check Accumulator Pre-charge Pressure 98
11.10 Change Engine Air Filter (internal cartridge) 98

Section 12 - 3000 Hours or Three Years Maintenance

12.0 3000 Hours or Three Years 101
12.1 Check Atomisers (Fuel Injector) 101

Section 13 - Routine Maintenance

13.0 Routine Maintenance 105
13.1 Replacing the Attachments 105
13.2 Slider Pads Adjustment 106
13.3 Changing Slider Pads 106
13.4 Attachment Plate Removal / Installation 108
13.5 Parking Brake Adjustment 109
13.6 Bleeding Brake System 111
13.7 Proximity Switch Adjustment 111
13.8 Drive Shaft 111
13.9 Fuel Tank 113
13.10 Oil Tank 114
13.11 Radiator 115

Section 14 - Hydraulic Boom

14.0 Boom Introduction 121
14.1 Boom Removal / Installation 121
14.2 Tilt Cylinder Replacement 124
14.3 Boom Disassembly 125
14.4 Boom Assembly 126
14.5 Compensation Cylinder Removal / Installation 127
14.6 Locking Cylinder Removal / Installation 128
14.7 Boom Hoist Cylinder - Removal / Installation . 130
14.8 Extend Cylinder Removal / Installation 133

Section 15 - Carraro Axles

15.0 Front Alxe - Removel / Installation 137
15.1 Rear Axle - Removel / Installation 141
15.2 Carraro Axles - Repair manual 143

Section 16 - Troubleshooting Guide

16.0 Troubleshooting Guide 275
16.1 General Troubleshooting 275
16.2 Hydraulic Troubleshooting 276
16.3 Electrical Troubleshooting 281

Section 17 - Hydraulic System

17.0 Hydraulic System 297
17.1 Hyd. Drive Pump - Removal / Installation 297
17.2 Cylinder Holding Valve - Removal / Installation 298
17.3 Hydraulic Motor - Removel / Installation 298
17.4 Rexroth Pump (A4vG) - Repair istructions 299
17.5 Rexroth Motor (A6Vm107) - Repair istructions 341
17.6 Rexroth Operating Istructions 381

Section 18 - Engine

18.0 Operating Manual 399

Section 19 - Tables and Enclosures

19.0 Torque Wrench Settings 453
19.1 Pressure Setting 455
19.2 Special Tool List 457

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

Section 20 - 3B6 Technologies LMI System

20.0 3B6 Load Moment Indicator Manual 465
20.1 System lay-out and connections 466
20.2 Components location on the machine 467
20.3 Infolift main unit: Characteristics 468
20.4 Infolift main unit: Dimensions 469
20.5 Load cell amplifier: Dimensions, characteristics, cable 470
20.6 Control panel description 471
20.7 Display information: Working messages 472
- Power-on sequence
- Safe working condiotion
- Warning condition
- Shut-off condition
- Setting mode
- Shut-off over ride
20.8 Display information: Diagnostics messages ... 475
- A01 crc error
- A02 cellalarm
- A03 cellallarm
20.9 Standard operating mode 476
- Normal / safe working load
- Pre-warning working load
- Overload working load
- By-pass pushbutton
20.10 Accuracy verification 480
- Pushbuttons functions
- Procedure
20.11 Accuracy verification mode 482
- First time accuracy verification
- Re-accuracy verification
- Load cell reading
- Empty accuracy verification
- Laden accuracy verification
- Cut-off percentage
- Empty moment
- Laden moment
- Filter
20.12 How to set a numeric value 485
20.13 How to set the password 486
20.14 External wiring 487
20.15 Spare parts list 488
20.16 Warnings 488


MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >


13.10 OIL TANK

DISASSEMBLY

Follow the procedures listed below to disassembly the oil tank.

1. Remove the drive shaft protection cover by using a 13 mm wrench to loosen the four locking screws.






2. Carefully clean the area around the drain plug of the oil tank.





4. Place suitable container under oil tank drain plug.
3. Using a 32 mm wrench remove the drain plug and allow the oil to completely drain.
4. Close the oil valves.
5. Using a 32 mm and 36 mm wrench disconnect the valve.
6. Disconnect the three side flexible hoses by using a 22 mm – 27 mm and 32 mm wrench.



7. Disconnect the electrical wire from the sending unit.
8. Use a 38 mm and a 50 mm wrench to disconnect the flexible hoses under the valve.
9. Disconnect the hose clamp of the filler extension by using a 10 mm wrench.
10. Remove the tank vent line.
11. Place a pallet with shims under the tank to support its weight.

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

16.0 TROUBLESHOOTING GUIDE

This section provides troubleshooting and schematic for the electrical and hydraulic system.
There are three troubleshooting charts one for General, Electrical and Hydraulic. These charts are of general nature, but should provide an intuitive feeling for a specific system. Knowing the system is the greatest aid to troubleshooting. Every component has a purpose in the system. The construction and operating characteristics of each one should be understood. Know the capabilities of the system. Each component in the system has a maximum rated speed, torque or pressure. Loading the system beyond the specification increases the possibility of failure. Know the correct operating pressures. Always set and check pressures with a gauge that is know to be accurate.

16.1 GENERAL TROUBLESHOOTING

FAULT	CAUSE	SOLUTION
The hydraulic oil Thermometer does not function	This is normal, when the outside temperature is low and / or the machine is used for short periods, since the hydraulic oil cannot warm up over 40-50°C	
	The oil temperature bulb is damaged.	Check and replace the bulb
High temperature of the Engine coolant	Water level in the overflow tank	Check and, if necessary, refill
	The temperature bulb is defective	Change bulb
	The dashboard manometer is defective	Change
Low hydraulic oil level	Oil Leaks	Refill
High hydraulic oil temperature	The radiator grill is dirty	Clean the grill regularly
Low engine performance	The air filter is dirty	Clean the air filter regularly
The steering column Response is slow or noisy	Joints are damaged	Change the joints
	The spiders of the driving shaft are damaged	Change the spiders
The differential is noisy and its body temperature is high	No Oil	Check and refill
	Bearing are damaged	Change the bearings as per HURTH instructions.
Oil leaks from axles and/or gearbox	Seals are worn	Change as per HURTH instructions


MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

2.4 Fuel System Schematic

2.4.1 Fuel System

1 Fuel line from tank to fuel pump
2 Fuel pump
3 Fuel line from fuel pump to easy-change fuel filter
4 Easy-change fuel filter
5 Fuel line from filter to injection pump
6 Injection pump
7 Fuel distributor line
8 Injection line
9 Injection valves
10 Fuel leakage line
11 Fuel overflow pipe
12 Fuel return line to tank

The installation of a fuel pre-filter/hand pump between the fuel tank and the engine is prescribed to protect the engines against dirt in the fuel.



© 31 863 0

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

3B6 LOAD MOMENT INDICATOR (LMI)
TX 51-19MD USMC TELEHANDLER

USER AND ACCURACY VERIFICATION MANUAL



CE

Complies to the MACHINES DIRECTIVE Standards: EN60204-1, EN954, EN12077-2
EMC according to the " Heavy Industrial Environment" category: EN50081-2, EN50082-2

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >

9. Insert the pin holding coupling to the boom mask and the pin attaching the tilt cylinder.





10. Reconnect the hydraulic hoses to the boom.



11. Start the engine and function boom to check for leaks.

14.2 TILT CYLINDER REPLACEMENT

1. Position the machine on a hard level surface.
2. Remove the pin holding coupling to boom mask and the pin attaching the tilt cylinder.



3. Unplug quick disconnect hoses.



4. Tag and remove hoses from holding valve.



5. Attach adequate lifting device, to tilt cylinder, carefully remove pin from top of boom head.



6. When removing tilt cylinder use caution not to damage holding valve.

DO NOT DISASSEMBLE ANY COMPONENT (S) DURING WARRENTY PERIOD WITHOUT CONTACTING TEREXLIFT.

MidWestTech | Terex TX 51-19MD LCRTF Rough Terrain Forklift Service Manual | Pu... Order the manual at mid-west-tech.com >