
PARTS MANUAL

Compactors CV1500



NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001-00	01	COMPONENT INDEX - CAB
00-002-00	01	COMPONENT INDEX - CANOPY
01-001-00	01	QUICK REFERENCE TO FREQUENTLY ORDERED PARTS
02-001-00	01	ENGINE - ENGINE MOUNTING
02-001-01	01	ENGINE
02-002-00	01	WATER CIRCUIT - ENGINE
02-003-00	01	RADIATOR AND OIL COOLER
02-004-00	01	FAN GUARD - ENGINE
02-005-00	01	EXHAUST - ENGINE
02-006-00	01	AIR FILTRATION - ENGINE
02-007-00	01	AIR FILTRATION - ENGINE
03-001-00	01	FUEL SYSTEM
03-002-00	01	ENGINE ACCELERATION
04-001-00	01	ELECTRICAL CIRCUIT
04-001-01	01	ELECTRICAL CIRCUIT - CAB
04-001-02	01	REAR WINDSCREEN WIPER - CAB
04-001-03	01	REAR WINDSCREEN WIPER - CAB
04-001-04	01	FRONT WINDSCREEN WIPER - CAB
04-001-05	01	LAMP, WORK- CANOPY (CV1100)
04-001-06	01	LAMP, WORK - CAB (CV1100)
04-001-07	01	FRONT LIGHTS - REAR LIGHTS
04-001-08	01	REAR LIGHTS
04-002-00	01	INSTRUMENT PANEL
04-002-01	01	DRUM ANTI-SLIP CONTROL
04-002-02	01	TACHOMETER
04-004-00	01	ROTATING BEACON
04-005-00	01	HORN
04-006-00	01	ELECTRICAL CIRCUIT - OPERATOR"S COMPARTMENT TILTING CONTROL AND ENGINE HOOD
04-007-00	01	ELECTRICAL CIRCUIT - DIFFERENTIAL LOCK
04-007-01	01	DIODE
04-008-00	01	ALTERNATEUR SHIELD
04-009-00	01	BULB - FUSE
06-001-00	01	STEERING WHEEL AND FIXED STEERING COLUMN
06-002-00	01	HYDRAULIC CIRCUIT, STEERING
06-003-00	01	HYDRAULIC CIRCUIT, STEERING - DOZER BLADE
06-004-00	01	STEERING CYLINDER
06-005-00	01	STEERING CONTROL VALVE
07-001-00	01	TRANSMISSION - DRUM
07-002-00	01	TRANSMISSION - REAR
07-003-00	01	REDUCTION GEAR - DRUM
07-003-01	01	TRAVEL REDUCTION GEAR - REAR
07-004-00	01	REAR WHEELS
07-005-00	01	REAR WHEELS
09-001-00	01	HYDRAULIC CIRCUIT, BRAKING
10-001-00	01	HYDRAULIC RESERVOIR
10-002-00	01	HYDRAULIC CIRCUIT - VIBRATION
10-003-00	01	HYDRAULIC CIRCUIT, TRAVEL - DRUM
10-004-00	01	HYDRAULIC CIRCUIT, TRAVEL -REAR
10-005-00	01	HYDRAULIC CIRCUIT- OPERATOR"S COMPARTMENT TILTING CONTROL AND ENGINE HOOD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

10-005-01	01	HYDRAULIC CIRCUIT- OPERATOR"S COMPARTMENT TILTING CONTROL AND ENGINE HOOD
10-006-00	01	HYDRAULIC CIRCUIT - OPERATOR"S COMPARTMENT TILTING CYLINDER
10-007-00	01	HYDRAULIC CIRCUIT - ENGINE HOOD OPENING CYLINDER - RIGHT
10-008-00	01	HYDRAULIC CIRCUIT - ENGINE HOOD OPENING CYLINDER - LEFT
10-009-00	01	HYDRAULIC CIRCUIT PRESSURE TEST POINT
10-010-00	01	HYDRAULIC CIRCUIT, DOZER BLADE
10-011-00	01	HYDRAULIC PUMP
10-012-00	01	HYDRAULIC PUMP -TRAVEL
10-013-00	01	HYDRAULIC PUMP - VIBRATIONS
10-013-01	01	HYDRAULIC PUMP - VIBRATIONS - ROTOR
10-014-00	01	HYDRAULIC MOTOR - VIBRATION
10-015-00	01	HYDRAULIC MOTOR - VIBRATION
10-016-00	01	TRAVEL HYDRAULIC MOTOR - REAR
10-017-00	01	TRAVEL MOTOR - REGULATOR
10-018-00	01	TRAVEL MOTOR - DRUM
10-019-00	01	TRAVEL MOTOR - REGULATOR - DRUM
10-020-00	01	BRAKE RELEASE VALVE
10-021-00	01	HAND PUMP - OPERATOR"S COMPARTMENT MANUAL TILTING
10-022-00	01	DOZER BLADE CYLINDER
10-023-00	01	QUICK COUPLER - HYDRAULIC RESERVOIR
12-001-00	01	CHASSIS
12-001-01	01	SOUNDPROOFING (CV1100)
12-002-00	01	LINKAGE
12-003-00	01	LINE FASTENERS
12-004-00	01	LOCKING - LINKAGE
12-005-00	01	CHASSIS - DRUM
12-006-00	01	SCRAPERS
12-007-00	01	SCRAPERS
12-008-00	01	VIBRATORY DRUM
12-009-00	01	ADAPTING THE DRUM FOR TAMPING COMPACTION
12-010-00	01	FIXING CLAMPS
12-011-00	01	DRUM FOR TAMPING COMPACTION
12-012-00	01	VIBRATORY - DRUM
12-013-00	01	OPERATORS COMPARTMENT
12-014-00	01	OPERATORS COMPARTMENT - BELLOWS
12-015-00	01	OPERATORS COMPARTMENT
12-016-00	01	OPERATORS COMPARTMENT
12-017-00	01	OPERATORS COMPARTMENT
12-018-00	01	SEAT - PIVOTING LEVER
12-019-00	01	MOUNTING
12-020-00	01	CAB (CV1100)
12-020-01	01	CAB - VITRE
12-020-02	01	CAB - GUARD
12-020-03	01	CAB - ROOF
12-021-00	01	ROPS FRAME
12-022-00	01	OPERATORS COMPARTMENT
12-022-01	01	CANOPY
12-022-02	01	CANOPY
12-022-03	01	HEATING
12-022-04	01	HEATER UNIT

Order the manual at mid-west-tech.com >