PARTS CATALOG

LB110.B
BACKHOE LOADER

Serial Number 031044996 and After

6036803400NA

NEW HOLLAND CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

MAIN	00	SECTIONS
MPARTS	00	MAINTENANCE PARTS
SEC. 01	00	ENGINE 1/2
SEC. 01	01	ENGINE 2/2
0.021/1	01	ENGINE
0.040	01	CYLINDER BLOCK
0.040	02	CYLINDER BLOCK
0.042	01	OIL PUMP, PAN
0.043	01	CYLINDER BLOCK - COVERS
0.043	02	CYLINDER BLOCK - COVERS
0.043	03	CYLINDER BLOCK - COVERS
0.045	01	BREATHER - ENGINE
0.060	01	CYLINDER HEAD
0.063	01	CYLINDER HEAD - COVERS
0.066	01	CYLINDER HEAD - VALVE MECHANISM
0.071/1	01	MANIFOLD - INTAKE
0.077/1	01	MANIFOLD - EXHAUST
0.080	01	CRANKSHAFT
0.081	01	PISTONS - CONNECTING ROD
0.082	01	PISTONS - CONNECTING ROD
0.083	01	FLYWHEEL - ENGINE
0.084	01	PULLEY - CRANKSHAFT
0.105	01	DYNAMIC BALANCER, GEARS & SHAFTS
0.105	02	DYNAMIC BALANCER, GEARS & SHAFTS (2830952)
0.120	01	CAMSHAFT
0.140/1	01	FUEL INJECTION PUMP
0.140/1	02	FUEL INJECTION SYSTEM
0.142	01	FUEL INJECTION SYSTEM
0.149	01	FUEL INJECTION SYSTEM
0.200	01	FUEL FILTER
0.201	01	FUEL PUMP
0.203	01	FUEL INJECTION SYSTEM
0.204	01	FUEL INJECTION SYSTEM
0.240/1	01	TURBOCHARGER
0.270	01	ENGINE, OIL
0.300	01	OIL PUMP - ENGINE
0.302	01	OIL FILTERS - ENGINE
0.305	01	PIPING - ENGINE OIL
0.315	01	OIL FILTER AND COOLER
0.320	01	WATER PUMP
0.323	01	COOLING SYSTEM - ENGINE
0.326	01	THERMOSTAT - ENGINE COOLING SYSTEM
0.340	01	WATER PUMP - CONTROL
0.345	01	FAN DRIVE
0.350	01	POWER TAKE-OFF
0.360	01	STARTER MOTOR
0.400	01	ALTERNATOR
0.450	01	ENGINE - LIFT HOOK
636A	01	ACCESSORY ENGINE
636A	02	ACCESSORY ENGINE - VENTILATOR
636A	03	ACCESSORY ENGINE - STARTER

MidWestTech | New Holland LB110.B Backhoe Loader Parts Catalog | Publication 6036803... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

636A	04	ACCESSORY ENGINE- ALTERNATOR
636A	05	ACCESSORY ENGINE - BRACKET MUFFLER
639A	01	ACCESSORY ENGINE - VENTILATOR
SEC. 02	00	FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS
1.14.0	01	FUEL TANK & RELATED PARTS
1.15.0	01	MUFFLER & EXTENSIONS
1.15.0	02	MUFFLER & EXTENSIONS
1.17.2	01	EXPANSION TANK
1.19.1	01	AIR CLEANER & HOSES
1.21.5/ 1	01	FRAME (CENTER PIVOT)
175	01	AIR INTAKE CAP & PRE-CLEANER
176	01	AIR INTAKE CAP & PRE-CLEANER
203	01	FRONT WEIGHTS
215	01	FRONT WEIGHTS
638	01	RADIATOR
638	02	RADIATOR
638	03	RADIATOR
638	04	RADIATOR - ALTERNATOR MOUNTING
638	05	RADIATOR - TENSIONER
639	01	RADIATOR
SEC. 03	00	TRANSMISSION 1/2
SEC. 03	01	TRANSMISSION 2/2
1.28.0	01	GEARING SPEED GEAR
1.28.0/ B	01	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	02	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	03	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	04	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	05	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	06	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	07	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	08	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ C	01	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	02	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	03	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	04	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	05	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	06	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	07	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	08	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	09	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	10	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	11	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	12	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	13	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	14	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	15	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.0/ C	16	TRANSMISSIONGEARING SPEED GEAR (4WD-4WS POWER-SHIFT)
1.28.6	01	GEAR FILTER PIPES (POWER-SHUTTLE)
1.28.6/ 1	01	GEAR FILTER PIPES (POWER-SHIFT)
1.29.1	01	TRANSMISSION ESTERNALSHIFTING CONTROLS (POWER-SHUTTLE)
1.32.1	01	HYDRAULIC DIFFERENTIAL LOCK (CENTER PIVOT)

MidWestTech | New Holland LB110.B Backhoe Loader Parts Catalog | Publication 6036803... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

1.38.1	01	FRONT & REAR DRIVESHAFT, POWER-SHUTTLE
1.38.1-1	01	FRONT & REAR DRIVESHAFT, POWER-SHIFT
1.39.8	01	TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE)
1.39.8/ 1	01	TRANSMISSION OIL COOLING PIPES (POWER-SHIFT)
SEC. 04	01	FRONT AXLE
1.42.0	01	POWER STEERING HYDRAULIC SYSTEM
1.42.0/ A	01	POWER STEERING HYDRAULIC SYSTEM
402	01	4WD FRONT AXLE, HOUSING, BUSHINGS & SUPPORTS
402	02	4WD FRONT AXLE, SWIVEL HOUSING & STEERING CYLINDER
402	03	4WD FRONT AXLE, HUBS
402	04	4WD FRONT AXLE, RING GEAR & PINION ASSEMBLY
402	05	4WD FRONT AXLE, DIFFERENTIAL
402	06	4WD FRONT AXLE, DRIVE SHAFT
415	01	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	02	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	03	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	04	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	05	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	06	FRONT AXLE - (4WD) W/GEAR,BEVEL
SEC. 05	00	REAR AXLE
1.44.0A	01	REAR AXLE (POWER-SHUTTLE)
1.44.0A	02	REAR AXLE (POWER-SHUTTLE)
1.44.0A	03	REAR AXLE (POWER-SHUTTLE)
1.44.0A	04	REAR AXLE (POWER-SHUTTLE)
1.44.0B	01	REAR AXLE (POWER-SHIFT)
1.44.0B	02	REAR AXLE (POWER-SHIFT)
1.44.0B	03	REAR AXLE (POWER-SHIFT)
1.44.0B	04	REAR AXLE (POWER-SHIFT)
SEC. 06	00	ELECTRICAL
1.75.2	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2	03	ENGINE HARNESS (POWER SHUTTLE)
1.75.2/ 1	01	CHASSIS HARNESS & GROUND WIRE (POWER SHIFT)
1.75.2/ 1	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHIFT)
1.75.2/ 1	03	ENGINE HARNESS (POWER SHIFT)
1.75.2/ 3	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	03	ENGINE HARNESS (POWER SHUTTLE)
1.75.2/ 4	01	CHASSIS HARNESS & GROUND WIRE (POWER SHIFT)
1.75.2/ 4	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHIFT)
1.75.2/ 4	03	ENGINE HARNESS (POWER SHIFT)
131	01	SINGLE BATTERY
321	01	DOUBLE BATTERY
995	01	COLD START
995	02	COLD START
SEC. 07	00	SLIDES VALVES
1.82.0	01	HYDRAULIC OIL RESERVOIR
1.82.3/ 1	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.6	01A	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	01B	FRONT HYDRAULIC PUMP INTAKE & OUTLET HOSES (CENTER PIVOT)
1.82.6	02A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)

Order the manual at mid-west-tech.com >