OPERATOR'S MANUAL

Dozer Crawler DC180 PS
Includes LGP



NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland DC180 PS (Includes LGP) Dozer Crawler Operator's Manual |...

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SUBJECT	PAGE
SAFETY RULES	I-VII
Decommisioning the machine	VII
Foreword	VIII
Identification data	2
Quantitative sides of comfort	3
GENERAL SPECIFICATIONS	4
Main dimensions	6
List and location of safety decals	9
Preliminary instructions and break-in period	17
Operation rules	18
Controls and instruments	19
Operation instructions	32
General information	32
Prior to starting	32
Engine starting	32
Stopping the machine	34
Stopping the engine	35
Operator's seat adjustment	35
Fuel reservoir	36
Blade adjustment	36
Cab tilting	37
Lowering the cab	38
Oil refilling and bleeding of the cab tilting system	38
Brakes disengagement	39
Towing the machine	41
Moving the machine with outside means	42
Instructions for lowering the equipment to the ground with engine inoperative	43
Transporting the machine	43
Long storage of the machine	44
Cold climate precautions	44
Starting the machine at low temperatures	45
Starting the machine with booster batteries	45
Machine operation	46
Cab	55
MAINTENANCE	59
Maintenance operations	60
Walk around inspection	60
List of on board tools	61
List of programmed maintenance	62
Every 10 hours work	63
Every 50 hours work	66
Every 100 hours work	66
Every 250 hours work	67
Every 500 hours work	70
Every 1000 hours work	73
Every 2000 hours work	76
When required	78
Operations to be performed when required	80
Electrical system	82
Electrical diagram of protection tree	83
Tables of fluid capacities	84

MidWestTech | New Holland DC180 PS (Includes LGP) Dozer Crawler Operator's Manual |... Order the manual at mid-west-tech.com >