OPERATOR'S MANUAL

Backhoe Loaders LB75.B - LB90 - LB110 - LB115.B



NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland LB75.B, LB90, LB110, LB115.B Loader Backhoe Operator's Ma...

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Section 1 ..... **1–1**
FIRST 50 HOUR SERVICE 1–2
PRODUCT IDENTIFICATION 1–2
VEHICLE IDENTIFICATION PLATES 1–2
IMPORTANT ECOLOGICAL CONSIDERATIONS 1–6
SAFETY PRECAUTIONS 1–6
OPERATING THE MACHINE 1–9
DRIVING THE UNIT 1–12
LIFTING AND CRANING 1–19

Section 2 ..... **2–1**
CONTROLS AND OPERATION 2–1
SEAT ADJUSTMENTS (VINYL) 2–5
FRONT INSTRUMENT PANEL – OVERVIEW 2–14
SIDE MOUNTED INSTRUMENT PANEL – OVERVIEW 2–18
4X2 POWER SHIFT TRANSMISSION CONTROL LEVER ... 2–35

Section 3 ..... **3–1**
ANTI THEFT ISOLATOR (where fitted) 3–2
KEY–START AND STOP SWITCH 3–2
STARTING THE ENGINE 3–3
COLD WEATHER STARTING, DOWN TO –18 C (0.5F) 3–4
STOPPING THE ENGINE 3–5
RUNNING–IN PROCEDURE 3–5
ALL WHEEL STEER PHASING 3–6
LOADING OPERATIONS 3–10
LIFT FORK PERFORMANCE 3–13
MACHINE STORAGE 3–24
BALLASTING AND TIRES 3–25
TOWING 3–27
TRANSPORTING 3–29
CLEANING 3–29
OPERATING THE BACKHOE 3–15

Section 4 ..... **4–1**
LOADER ARM SUPPORT 4–3
SERVICING THE ENGINE AIR CLEANER 4–9
HYDRAULIC SYSTEM – OIL LEVEL 4–12
EVERY 300 HOURS : 4–21
EVERY 600 HOURS : 4–25
FUEL SYSTEM WITH MECHANICAL LIFT PUMP 4–28
FUEL SYSTEM WITH ELECTRIC LIFT PUMP 4–29
EVERY 1200 HOURS OR YEARLY 4–32
1200 HOURS OR EVERY TWO YEARS, ... 4–37
GENERAL MAINTENANCE 4–38
ADJUSTMENTS 4–53

MidWestTech | New Holland LB75.B, LB90, LB110, LB115.B Loader Backhoe Operator's Ma... Order the manual at mid-west-tech.com >

Section 5 ..... **5–1**
ENGINE 5–1
TRANSMISSION – POWER SHUTTLE 5–3
TRANSMISSION – POWER SHIFT 5–3
ELECTRICAL 5–4
WHOLE UNIT 5–5
HYDRAULICS 5–6
CAB 5–7

Section 6 ..... **6–1**
STORAGE 6–1
TYRES AND WHEELS 6–1
STARTING THE MACHINE WITH JUMP LEADS 6–2
TURBOCHARGER 6–3
PREPARING THE MACHINE FOR USE AFTER STORAGE: 6–3

Section 7 ..... **7–1**
OPTIONS AND ACCESSORIES 7–1
BACKHOE HAMMER ATTACHMENT 7–5

Section 8 ..... **8–1**
ENGINE 8–21
COOLING SYSTEM 8–21
FUEL SYSTEM 8–21
TRANSMISSION 8–21
ELECTRICAL SYSTEM 8–22
BRAKES 8–22
STEERING 8–22
REAR AXLE 8–22
TIRE PRESSURES AND PERMISSIBLE LOADS 8–23

Section 9 ..... **9–1**
FORMS AND DECLARATIONS 9–1

MidWestTech | New Holland LB75.B, LB90, LB110, LB115.B Loader Backhoe Operator's Ma... Order the manual at mid-west-tech.com >