OPERATOR'S MANUAL

ARTICULATED DUMP TRUCKS
AD250

NEW HOLLAND
CONSTRUCTION

6045429100

MidWestTech | New Holland AD250 Articulated Dump Truck Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - TO THE OWNER/SAFETY **1-1**

AD250 articulated truck 1-1

Right, left, front and rear of the machine 1-3

Type, serial number and year of manufacture 1-4

Position of identification data on main component groups 1-5

Noise levels 1-8

Identification of the main components of the machine 1-9

Safety rules 1-10

Prevention of fires 1-11

Instructions for use 1-12

Maintenance instructions 1-15

Decals 1-18

Hand signals 1-30

SECTION 2 - CONTROLS/INSTRUMENTS/ACCESSORIES **2-1**

Accessing the cab 2-1

Accessing the platforms 2-1

Door 2-2

Location of controls, instruments and accessories 2-3

Driver's seat 2-7

Trainer's seat 2-8

Seat belts 2-8

Accessory functions 2-9

SECTION 3 - OPERATING INSTRUCTIONS **3-1**

Before operating the machine 3-1

Operating the machine 3-2

Run-in period 3-3

Starting and stopping the engine 3-4

Starting the vehicle 3-6

Stopping and parking the vehicle 3-8

Driving the vehicle 3-9

Using the automatic transmission 3-10

Using the differential lock 3-14

Working with the vehicle 3-15

Towing the vehicle 3-17

Replacing a complete wheel 3-19

External hoist control 3-21

Climate control system operation 3-22

MidWestTech | New Holland AD250 Articulated Dump Truck Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 4 - SERVICING INTERVALS/LUBRICATION/FLUIDS 4-1

Servicing intructions 4-1
Preliminary operations 4-3
Scheduled maintenance programme 4-6
Lubrication and scheduled replacement chart 4-8
Operations to be carried out every day 4-10
Engine 4-12
Fuel supply system 4-16
Air intake system 4-20
Cooling system 4-24
Automatic transmission 4-28
Front axle/rear tandem axles 4-31
Hydraulic system 4-34
Greasing 4-38

SECTION 5 - MAINTENANCE/ADJUSTMENTS 5-1

Suspension 5-1
Braking circuit 5-4
Tires and wheels 5-5
Air conditioning system 5-6
Bodywork 5-8
Troubleshooting 5-10

SECTION 6 - ELECTRICAL SYSTEM 6-1

Precautions 6-1
Battery maintenance (not sealed) 6-2
Fuse and relay box 6-4
Lighting system 6-7

SECTION 7 - STORAGE 7-1

Storing the vehicle 7-1

SECTION 8 - SPECIFICATIONS 8-1

Main groups 8-1
Dimensions 8-1
Weights 8-2
Horizontal center of gravity (during transport with unladen vehicle) (mm/ft) 8-2
Performance 8-3
Performance alignment chart 8-4
Main group characteristics 8-5
Capacities 8-8

SECTION 9 - MISCELLANEOUS FORMS 9-1

SECTION 10 - ALPHABETICAL INDEX 10-1

MidWestTech | New Holland AD250 Articulated Dump Truck Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >