1020 Flexible Cutter Bar Grain Header

Operators Manual

P.I.N. JJC0315001 and After

Rac 6-1012

CASE IH AGRICULTURE

MidWestTech | Case 1020 Flexible Cutter Bar Grain Header Operator's Manual | Publication 6-1012

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

1 - TO THE OWNER **1**

2 - IDENTIFICATION NUMBERS **3**
PRODUCT IDENTIFICATION NUMBERS 3
MAIN MACHINE COMPONENTS 4

3 - SAFETY/DECALS **5**
SAFETY 5
WARNING LIGHTING 12
DECALS 13
INFORMATIONAL DECALS 16

4 - CONTROLS/COMBINE CONNECTIONS **17**
HEADER CONTROLS 17
HEADER AND COMBINE CONNECTIONS 17
CUTTER BAR CONVERSION 28

5 - FIELD OPERATION/TROUBLESHOOTING **35**
PICTORIAL INDEX 35
REEL ADJUSTMENTS 37
REEL POSITION FOR CROP CONDITIONS 45
AUXILIARY PICKUP TINE - PLASTIC (IF EQUIPPED) 49
AUXILIARY PICKUP TINE - STEEL (IF EQUIPPED) 50
PICTORIAL INDEX 51
HEADER HEIGHT OPERATION 54
FLEXIBLE CUTTER BAR OPERATION 57
RIGID CUTTER BAR OPERATION 63
DIVIDERS 64
KNIFE DRIVE PULLEY 71
AUXILIARY SKID SHOES (IF EQUIPPED) 72
GRAIN LIFTERS (IF EQUIPPED) 72
EXTRA KNIFE STORAGE 73
PICTORIAL INDEX 74
AUGER ADJUSTMENTS 76
TROUBLESHOOTING 97

6 - SERVICE **105**
SERVICE INTERVALS 105

7 - LUBRICATION **109**
LUBRICATION CHART 111
GREASE FITTINGS 112

MidWestTech | Case 1020 Flexible Cutter Bar Grain Header Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

8 - MAINTENANCE/ADJUSTMENTS **117**
AUGER FINGER REPLACEMENT 117
AUGER SLIP CLUTCH 118
AUTOMATIC HEADER HEIGHT CONTROL 119
HEADER POTENTIOMETER CALIBRATION 124
SENSOR TUBE RETURN SPRING 131
KNIFE 132
BELTS AND CHAINS 136
HEADER DRAIN HOLES 140
SPECIAL TOOL OPERATED LATCHES 141

9 - STORAGE **143**
STORING THE HEADER 143
REMOVING FROM STORAGE 145

10 - SPECIFICATIONS **147**
GENERAL SPECIFICATIONS 147
RECOMMENDED HEADER SIZE 149

DETAIL INDEX **151**

MidWestTech | Case 1020 Flexible Cutter Bar Grain Header Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >