STX275
STX325
STX375
STX440

STX Series 9 Liter Engine

SERVICE MANUAL

6-10450

CASE IH AGRICULTURE

MidWestTech | Case STX275, STX325, STX375, STX440 STX Series 9 Liter Engine Service Manual | Publication 6-10450

Order the manual at mid-west-tech.com >

Section TS - Troubleshooting Symptoms

Section Contents

Troubleshooting Procedures and Techniques 1

Troubleshooting Symptoms Charts 1
- Communication Error Electronic Service Tool or Control Device 2
- Coolant Loss External 4
- Coolant Loss Internal 5
- Coolant Temperature Above Normal Gradual Overheat 6
- Coolant Temperature is Above Normal -- Sudden Overheat 9
- Coolant Temperature is Below Normal 11
- Coolant in the Lubricating Oil 12
- Crankcase Gases (Blowby) Excessive 13
- Cranking Fuel Pressure is Low 14
- Engine Acceleration or Response Poor 15
- Engine Decelerates Slowly 21
- Engine Difficult to Start or Will Not Start (Exhaust Smoke) 22
- Engine Difficult to Start or Will Not Start (No Exhaust Smoke) 26
- Engine Noise Excessive 29
- Engine Noise Excessive Combustion Knocks 32
- Engine Noise Excessive Connecting Rod 33
- Engine Noise Excessive Main Bearing 34
- Engine Noise Excessive Piston 35
- Engine Noise Excessive Turbocharger 36
- Engine Power Output Low 37
- Engine Runs Rough at Idle 44
- Engine Runs Rough or Misfires 48
- Engine Shuts Off Unexpectedly or Dies During Deceleration 52
- Engine Speed Surges at Low or High Idle 54
- Engine Speed Surges Under Load or in Operating Range 58
- Engine Speed Surges in PTO 63
- Engine Starts But Will Not Keep Running 64
- Engine Vibration Excessive 66
- Engine Will Not Crank or Cranks Slowly (Air Starter) 68
- Engine Will Not Crank or Cranks Slowly (Electric Starter) 70
- Engine Will Not Reach Rated Speed (RPM) 72
- Engine Will Not Shut Off 75
- Fault Code Warning Lamps Do Not Illuminate 76
- Fuel Consumption Excessive 77
- Fuel in Coolant 81
- Fuel in the Lubricating Oil 82
- Intake Manifold Air Temperature Above Specification 83
- Low Idle Adjust Switch Does Not Work 85
- Intake Manifold Pressure (Boost) is Below Normal 86
- Lubricating Oil Consumption Excessive 87
- Lubricating Oil Contaminated 89
- Lubricating Oil Pressure High 90
- Lubricating Oil Pressure Low 91
- Lubricating Oil Sludge in the Crankcase Excessive 93
- Lubricating Oil Temperature Above Specification 94
- Lubricating or Transmission Oil in the Coolant 95
- Smoke, White Excessive 96
- Smoke, Black Excessive 100
- Turbocharger Leaks Engine Oil or Fuel 103

MidWestTech | Case STX275, STX325, STX375, STX440 STX Series 9 Liter Engine Service... Order the manual at mid-west-tech.com >

Engine Noise Diagnostic Procedures General Information 104

Main Bearing Noise 104

Connecting Rod Bearing Noise 104

Piston Noise 104

MidWestTech | Case STX275, STX325, STX375, STX440 STX Series 9 Liter Engine Service... Order the manual at mid-west-tech.com >