621C - 721C Loader

Operators Manual

Bur 6-1231

CASE CONSTRUCTION

MidWestTech | Case 621C, 721C Loader Operator's Manual | Publication 6-1231

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
- AFTER DELIVERY CHECK 3
- RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
- IDENTIFICATION NUMBERS 4
- MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
- SAFETY RULES 9
- UTILITY SAFETY 10
- BEFORE OPERATION 11
- MACHINE OPERATION 12
- PARKING THE MACHINE 12
- MAINTENANCE 13
- BURN PREVENTION 14
- FIRE OR EXPLOSION PREVENTION 14
- WHEELS AND TIRES SAFETY 15
- HAZARDOUS CHEMICALS 16
- INFORMATIONAL DECALS 17
- SAFETY DECALS 17
- HAND SIGNALS 25

INSTRUMENT/CONTROLS **29**
- FRONT CONSOLE ..... 29 - 33
- INSTRUMENT PANEL INDICATORS ..... 34 - 49
- INFORMATION CENTER ..... 50 - 55
- GAUGE DISPLAY ..... 56 - 62
- TRANSMISSION DISPLAY CENTER ..... 63 - 65
- FOOT PEDALS 66
- LOADER CONTROL LEVERS 67
- SIDECONSOLE ..... 72 - 79
- MASTER DISCONNECT SWITCH 79
- OPERATORS SEAT 83
- SEAT BELT 86

TRIM THIS EDGE

MidWestTech | Case 621C, 721C Loader Operator's Manual | Publication 6-1231 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

OPERATING INSTRUCTIONS **89**
- BEFORE STARTING THE ENGINE 89
- RUN - IN PROCEDURE 89
- SEAT BELT 90
- STARTING THE ENGINE 91
- STOPPING THE ENGINE AND PARKING THE MACHINE 93
- MACHINE OPERATION 98
- LOADER CONTROL LEVERS 102
- LOADER FUNCTION SWITCHES 108
- BRAKE ACCUMULATORS 111
- CLUTCH CUTOUT 111
- BUCKET LEVEL INDICATOR 112
- AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 112
- ROTATING BEACON (IF EQUIPPED) 113
- RIDE CONTROL 113
- COUPLER PIN ENGAGEMENT (IF EQUIPPED) 114
- LOADER OPERATING TIPS 115
- TOWING THE MACHINE 117
- TRANSPORTING THE MACHINE 118
- OPERATING IN COLD WEATHER 120
- OPERATING IN HOT WEATHER 122

WHEELS/TIRES/BALLAST **123**
- BALLAST 123
- WHEELS AND TIRES 123

TRIM THIS EDGE

MidWestTech | Case 621C, 721C Loader Operator's Manual | Publication 6-1231 Order the manual at mid-west-tech.com >

LUBRICATION/FILTERS/FLUIDS **129**
GENERAL SAFETY BEFORE YOU SERVICE 129
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 130
PLASTIC AND RESIN PARTS 130
ENVIRONMENT 131
TRANSPORT/SERVICE LINK 131
ENGINE HOURMETER 132
FLUIDS AND LUBRICANTS - 621C 133
FLUIDS AND LUBRICANTS - 721C 134
LUBRICATION/MAINTENANCE CHART ..... 135 - 137
ACCESS DOORS 138
GREASE FITTINGS - 50 HOURS 139, 142
GREASE FITTINGS - 100 HOURS 140, 143
GREASE FITTINGS - 1000 HOURS 141, 144
FLUID LEVELS 145
ENGINE LUBRICATION 148
AIR FILTER SYSTEM 153
ENGINE COOLING SYSTEM 158
DIESEL FUEL SYSTEM 162
HYDRAULIC/BRAKE SYSTEM 167
TRANSMISSION 174
AXLES - EARLY PRODUCTION 177
AXLES - LATE PRODUCTION 180
CAB AIR FILTER 184

MAINTENANCE/ADJUSTMENT **189**
ETHER CONTAINER 189
CAB SERVICE 190
TRANSMISSION CLUTCH CALIBRATION 193
CLUTCH CUTOUT ADJUSTMENT 194
SECONDARY STEERING CHECK 196
PARKING BRAKE CHECK 197
LOADER ADJUSTMENTS 199
ROLL-OVER PROTECTIVE STRUCTURE 207
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 209
FAN BELT, ALTERNATOR BELT AND
AIR CONDITIONING COMPRESSOR BELT 210
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 211
SPARK ARRESTING MUFFLER (IF EQUIPPED) 212

TRIM THIS EDGE

MidWestTech | Case 621C, 721C Loader Operator's Manual | Publication 6-1231 Order the manual at mid-west-tech.com >