821C Loader

Operators Manual

Bur 6-1241

CASE
CONSTRUCTION

MidWestTech | Case 821C Loader Operator's Manual | Publication 6-1241

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
- AFTER DELIVERY CHECK 3
- RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
- IDENTIFICATION NUMBERS 4
- MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
- SAFETY RULES 9
- UTILITY SAFETY 10
- BEFORE OPERATION 11
- MACHINE OPERATION 12
- PARKING THE MACHINE 12
- MAINTENANCE 13
- BURN PREVENTION 14
- FIRE OR EXPLOSION PREVENTION 14
- WHEELS AND TIRES SAFETY 15
- HAZARDOUS CHEMICALS 16
- INFORMATIONAL DECALS 17
- SAFETY DECALS 17
- HAND SIGNALS 25

INSTRUMENT/CONTROLS **29**
- FRONT CONSOLE ..... 29 - 33
- INSTRUMENT PANEL INDICATORS ..... 34 - 49
- INFORMATION CENTER ..... 50 - 55
- GAUGE DISPLAY ..... 56 - 62
- TRANSMISSION DISPLAY CENTER ..... 63 - 65
- FOOT PEDALS 66
- LOADER CONTROL LEVERS 67
- SIDECONSOLE ..... 72 - 79
- MASTER DISCONNECT SWITCH 79
- OPERATORS SEAT 83
- SEAT BELT 86

MidWestTech | Case 821C Loader Operator's Manual | Publication 6-1241 Order the manual at mid-west-tech.com >

OPERATING INSTRUCTIONS **89**
BEFORE STARTING THE ENGINE 89
RUN - IN PROCEDURE 89
SEAT BELT 90
STARTING THE ENGINE 91
STOPPING THE ENGINE AND PARKING THE MACHINE 93
MACHINE OPERATION 98
LOADER CONTROL LEVERS 102
LOADER FUNCTION SWITCHES 108
BRAKE ACCUMULATORS 111
CLUTCH CUTOUT 111
BUCKET LEVEL INDICATOR 112
AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 112
ROTATING BEACON (IF EQUIPPED) 113
RIDE CONTROL 113
COUPLER PIN ENGAGEMENT (IF EQUIPPED) 114
LOADER OPERATING TIPS 115
TOWING THE MACHINE 117
TRANSPORTING THE MACHINE 118
OPERATING IN COLD WEATHER 120
OPERATING IN HOT WEATHER 122

WHEELS/TIRES/BALLAST **123**
BALLAST 123
WHEELS AND TIRES 123

MidWestTech | Case 821C Loader Operator's Manual | Publication 6-1241 Order the manual at mid-west-tech.com >

LUBRICATION/FILTERS/FLUIDS **127**
GENERAL SAFETY BEFORE YOU SERVICE 127
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 128
PLASTIC AND RESIN PARTS 128
ENVIRONMENT 129
TRANSPORT/SERVICE LINK 129
ENGINE HOURMETER 130
FLUIDS AND LUBRICANTS 131
LUBRICATION/MAINTENANCE CHART ..... 132 - 134
ACCESS DOORS 135
GREASE FITTINGS - 50 HOURS 136
GREASE FITTINGS - 100 HOURS 137
GREASE FITTINGS - 1000 HOURS 137
FLUID LEVELS 138
ENGINE LUBRICATION 141
AIR FILTER SYSTEM 146
ENGINE COOLING SYSTEM 150
DIESEL FUEL SYSTEM 153
HYDRAULIC/BRAKE SYSTEM 156
TRANSMISSION 163
AXLES - EARLY PRODUCTION 166
AXLES - LATE PRODUCTION 169
CAB AIR FILTER 172

MAINTENANCE/ADJUSTMENT **177**
ETHER CONTAINER 177
CAB SERVICE 178
TRANSMISSION CLUTCH CALIBRATION 181
CLUTCH CUTOUT ADJUSTMENT 182
SECONDARY STEERING CHECK 184
PARKING BRAKE CHECK 185
LOADER ADJUSTMENTS 187
ROLL-OVER PROTECTIVE STRUCTURE 195
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 197
FAN BELT, ALTERNATOR BELT AND
AIR CONDITIONING COMPRESSOR BELT 198
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 199
SPARK ARRESTING MUFFLER (IF EQUIPPED) 200

MidWestTech | Case 821C Loader Operator's Manual | Publication 6-1241 Order the manual at mid-west-tech.com >