9045B EXCAVATOR

Operator's Manual

Bur 6-1250NA

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 9045B Excavator Operator's Manual | Publication 6-1250NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS 4, 5, 6

SAFETY / DECALS / HAND SIGNALS 7
MACHINE SAFETY FEATURES 7, 8, 9
SAFETY MESSAGE 10
BEFORE OPERATION 11
MACHINE OPERATION 13
PARKING THE MACHINE 15
BURN PREVENTION 15
FIRE OR EXPLOSION PREVENTION 16
MAINTENANCE 17
SAFETY DECALS 19
HAND SIGNALS 28, 29, 30, 31, 32

INSTRUMENTS AND CONTROLS 33
LOCATION OF COMPONENTS (Operator's Cab) 33
HAND AND FOOT CONTROLS 34
STANDARD CONTROLS (Control Pattern D When Quick Change Kit Is Installed) 35
OPTIONAL CONTROLS (Control Pattern C When Quick Change Kit Is Installed) 36
RIGHT FRONT CONTROL PANEL 38,40
LEFT FRONT CONTROL PANEL 42
SYSTEMS DISPLAY PANEL 44, 47, 48
RIGHT REAR CONTROL PANEL 50
LEFT REAR CONTROL PANEL 51
OPERATION OF HEATING AND AIR CONDITIONING (If Equipped) 52
AM / FM RADIO 54
OPERATOR'S SEAT 55
SEAT BELT 56
CAB WINDOW AND DOOR CONTROLS 57
ANTI-VANDAL GUARD 60

MidWestTech | Case 9045B Excavator Operator's Manual | Publication 6-1250NA Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

OPERATING INSTRUCTIONS 61
- RUN-IN PERIOD OF A NEW MACHINE 61
- ENGINE OPERATION 62
- ENGINE STARTING AIDS 66
- ETHER COLD START AID 67
- BOOSTER BATTERY CONNECTION TO MACHINE BATTERY 68
- MACHINE OPERATION 70
- DRIVING THE MACHINE 71
- AUXILIARY ATTACHMENT OPERATION 77
- AUXILIARY HYDRAULIC SYSTEMS 78
- LIFTING LOADS WITH THE MACHINE 85
- TRANSPORTING THE MACHINE ON A TRAILER 86
- DISABLED MACHINE 86
- MACHINE LIFTING EYES 88
- OPERATING IN HOT WEATHER 89
- OPERATING IN COLD WEATHER 90

LUBRICATION / FILTERS / FLUIDS 91
- GENERAL SAFETY BEFORE YOU SERVICE 91
- ENVIRONMENT 91
- LUBRICATION CHART 92
- PLASTIC AND RESIN PARTS 94
- ENGINE HOURMETER 94
- FLUIDS AND LUBRICANTS 95
- ENGINE OIL RECOMMENDATIONS 96
- HYDRAULIC FLUID CHART 97
- SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 98
- ACCESS DOORS 99, 100
- GREASE FITTINGS 100
- ENGINE LUBRICATION SYSTEM 103
- AIR FILTER SYSTEM 105
- ENGINE COOLING SYSTEM 108
- DIESEL FUEL SYSTEM 114
- HYDRAULIC SYSTEM 118
- SWING GEARBOX 126
- FINAL DRIVE GEARBOXES 128

MidWestTech | Case 9045B Excavator Operator's Manual | Publication 6-1250NA Order the manual at mid-west-tech.com >

MAINTENANCE AND ADJUSTMENTS 129
DRIVE BELT 129
WINDSHIELD WASHER RESERVOIR 129
BUCKET INSTALLATION 130
WELDING ON THE MACHINE 130
SEAT BELT 131
FIRE EXTINGUISHER 131
ETHER STARTING FLUID 132
TRACKS 133
TRACK SHOE BOLTS 136
ELECTRICAL SYSTEM 137
BATTERIES 137
ELECTRICAL SYSTEM CONTROLLER 139
FUSES 140
MACHINE STORAGE 141

SPECIFICATIONS 143
ENGINE DATA 143
DIMENSIONS 144
OPERATING DATA 146
WEIGHTS 148
LIFTING CAPACITES FOR STANDARD MACHINES 149
LIFTING CAPACITY CHARTS 150
BUCKETS (Central Fabricators) 154
BOLT TORQUES 155

INDEX 157

AFTER DELIVERY CHECK 165, 167

TRIM THIS EDGE

MidWestTech | Case 9045B Excavator Operator's Manual | Publication 6-1250NA Order the manual at mid-west-tech.com >