1000 Series Corn Head

Operators Manual

P.I.N. JJC0335001 and After

Rac 6-1330

CASE IH AGRICULTURE

MidWestTech | Case 1000 Series Corn Head Operator's Manual | Publication 6-1330

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER 1
TO THE OWNER 1

IDENTIFICATION NUMBERS 2
PRODUCT IDENTIFICATION NUMBERS 2

SAFETY/DECALS 3
SAFETY 3
WARNING LAMP 5
SAFETY DECALS 6

CONTROLS/COMBINE CONNECTIONS 9
CORN HEAD CONTROLS 9
CONNECTING THE CORN HEAD 10
WARNING LIGHTING 14
FIELD TRACKER AND AUTOMATIC HEADER HEIGHT CONTROL CONNECTION ... 15
(IF EQUIPPED) 15
DISCONNECTING THE CORN HEAD 19
BEFORE GOING TO FIELD 22

FIELD OPERATION/TROUBLESHOOTING 23
PICTORIAL INDEX 23
FOR BEST HARVESTING RESULTS 26
CORN HEAD OPERATING HEIGHT 27
DIVIDER POINT ADJUSTMENT 28
MAIN DRIVE SPEEDS 30
GATHERER CHAINS 33
STALK ROLLS 36
SLIP CLUTCH - STALK ROLL DRIVE 41
AUGER ADJUSTMENT 42
GATHERER EXTENSIONS - REAR AND SIDE 44
WHEEL SHIELDS (IF EQUIPPED) 46
FIELD TRACKER GROUND SENSOR 46
TROUBLESHOOTING 47

LUBRICATION 51
LUBRICATION CHART 51
GENERAL SERVICE INFORMATION 52
GREASE FITTINGS 54
FLUID LEVEL 55
CHAIN LUBRICATION 56

TRIM THIS EDGE

MidWestTech | Case 1000 Series Corn Head Operator's Manual | Publication 6-1330 Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENT 57
GENERAL 57
CLEANING CORN HEAD 57
PICTORIAL INDEX 58
GATHERER SHIELDS 61
CORN HEAD LOWERING SPEED ADJUSTMENT 65
STALK ROLL REMOVAL AND INSTALLATION 66
STALK ROLL TIMING AND SPACING 72
STALK ROLL KNIFE REPLACEMENT 74
CHAINS 75
AUGER SLIP CLUTCH ADJUSTMENT 85
ROW SPACING ADJUSTMENT 87
WARNING LAMP BULB REPLACEMENT 97

STORAGE 98
STORING THE CORN HEAD 98
REMOVING FROM STORAGE 99

SPECIFICATIONS 100
GENERAL SPECIFICATIONS 100
SPEED CHART - MAIN DRIVE 102
CORN HEAD/COMBINE COMBINATIONS 103
CORN HEAD STORAGE SIZE 104

DETAIL INDEX 105

TRIM THIS EDGE

MidWestTech | Case 1000 Series Corn Head Operator's Manual | Publication 6-1330 Order the manual at mid-west-tech.com >