570LXT Loader/ Loader Landscaper Series 2

Operators Manual

Bur 6-1381NA

CASE CONSTRUCTION

MidWestTech | Case 570LXT Series 2 Loader Landscaper Operator's Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
- AFTER DELIVERY CHECK 3
- RIGHT, LEFT, FRONT AND REAR OF MACHINE 3
- IDENTIFICATION NUMBERS 4
- MACHINE COMPONENTS 7, 8

SAFETY/DECALS/HAND SIGNALS 9
- SAFETY FEATURES 9, 10
- SAFETY RULES 11
- BEFORE OPERATION 12
- MACHINE OPERATION 13
- PARKING THE MACHINE 15
- BURN PREVENTION 15
- FIRE OR EXPLOSION PREVENTION 16
- MAINTENANCE 17
- WHEEL AND TIRE MAINTENANCE 19
- ROLL-OVER PROTECTION STRUCTURE 19
- CAST DUCTILE IRON 20
- SAFETY DECALS 21
- HAND SIGNALS 28

INSTRUMENTS AND CONTROLS 31
- INSTRUMENT CLUSTER 31
- TRANSMISSION CONTROLS 34
- FOOT PEDALS 36
- FRONT CONSOLE CONTROLS 37
- LEFT SIDE INSTRUMENT CONSOLE CONTROLS 38, 39, 40, 42
- LOADER CONTROLS 44
- THREE-POINT HITCH CONTROL 47
- STANDARD SEAT 49
- STANDARD SUSPENSION SEAT 50
- SEAT BELTS 52
- CAB CLIMATE CONTROL PANEL (IF EQUIPPED) 53
- CAB AND CANOPY OPTIONS 55
- STORAGE AND CONVENIENCE OPTIONS 61

MidWestTech | Case 570LXT Series 2 Loader Landscaper Operator's Manual | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

OPERATING INSTRUCTIONS 63
- RUN-IN PERIOD OF A NEW MACHINE 63
- ENGINE OPERATION 64
- ENGINE STARTING AIDS 67
- MACHINE OPERATION 71
- TOWING A DISABLED MACHINE 76
- OPERATING IN COLD WEATHER 79
- OPERATING IN HOT WEATHER 80
- LOADER OPERATION 81
- LOADER HYDRAULIC COUPLER (OPTIONAL) 87
- THREE POINT HITCH OPERATION 89
- VANDAL LOCKUP KITS 90

WHEELS/TIRES 91

LUBRICATION / MAINTENANCE CHARTS 95
- GENERAL SAFETY BEFORE YOU SERVICE 95
- ENGINE HOURMETER 95
- SUPPORT STRUT FOR LOADER LIFT ARMS 96
- FLUIDS AND LUBRICANTS 97
- LUBRICATION/MAINTENANCE CHART 98, 99
- SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 100
- ENVIRONMENT 100

LUBRICATION/FILTERS/FLUIDS 101
- OPENING THE ENGINE HOOD 101
- LOADER GREASE FITTINGS 102
- MACHINE GREASE FITTINGS 104
- THREE POINT HITCH GREASE FITTINGS 108
- FLUID LEVELS 110
- ENGINE OIL RECOMMENDATIONS 112
- ENGINE SERVICE SPECIFICATIONS 113
- AIR FILTER SYSTEM 116
- ENGINE COOLING SYSTEM 120
- DIESEL FUEL SYSTEM 123
- HYDRAULIC SYSTEM 126
- TRANSMISSION 129
- REAR AXLE 131
- FRONT FOUR WHEEL DRIVE AXLE 133
- CAB AIR FILTER 135

TRIM THIS EDGE

MidWestTech | Case 570LXT Series 2 Loader Landscaper Operator's Manual | Publication... Order the manual at mid-west-tech.com >

MAINTENANCE AND ADJUSTMENTS **137**
LOADER RETURN-TO-DIG ADJUSTMENT 137
ETHER STARTING AID 138
FAN DRIVE BELT REPLACEMENT 139
PLASTIC AND RESIN PARTS 139
SPARK ARRESTER MUFFLER (IF EQUIPPED) 140
RIDE CONTROL ACCUMULATOR 141
CAB AIR CONDITIONING 142
ROLL-OVER PROTECTIVE STRUCTURE 143
FIRE EXTINGUISHER 148

ELECTRICAL SYSTEM **149**
BATTERIES 149
LAMP REPLACEMENT 151
INSTRUMENT CLUSTER 153
FUSES 154
ACCESSORY OUTLETS (IF EQUIPPED) 154

MACHINE STORAGE **155**
REMOVAL FROM STORAGE 156

SPECIFICATIONS **157**
ENGINE DATA (Naturally Aspirated) 157
ENGINE DATA (Turbocharged) 157
BOLT TORQUES 158
MAIN RELIEF VALVE PRESSURES 158
TRAVEL SPEEDS 158
OPERATING WEIGHTS 159
LOADER BUCKETS 159
BASIC MACHINE DIMENSIONS 160
LOADER OPERATING DATA AND DIMENSIONS 161, 162
THREE POINT HITCH LIFT CAPACITIES 164

INDEX **165**

AFTER DELIVERY CHECK **175, 177**

TRIM THIS EDGE

MidWestTech | Case 570LXT Series 2 Loader Landscaper Operator's Manual | Publication... Order the manual at mid-west-tech.com >