1150H CRAWLER

Operators Manual

Bur 6-20971

CASE
CONSTRUCTION

MidWestTech | Case 1150H Crawler Operator's Manual | Publication 6-20971

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
REGULATIONS 2
AFTER DELIVERY CHECK 2
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 4
MACHINE COMPONENTS ..... 6 - 7

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY RULES 9
UTILITY SAFETY 10
BEFORE OPERATION 11
MACHINE OPERATION 12
PARKING THE MACHINE 13
FIRE EXTINGUISHER 13
BURN PREVENTION 14
HAZARDOUS CHEMICALS 14
FIRE OR EXPLOSION PREVENTION 15
MAINTENANCE 16
DUCTILE IRON 16
INFORMATION DECALS 17
SAFETY DECALS 18
HAND SIGNALS 24

INSTRUMENTS/CONTROLS **27**
INSTRUMENT PANEL ..... 27 - 34
ENGINE HAND THROTTLE AND TRANSMISSION CONTROL 35
TRANSMISSION CONTROLS AND HORN BUTTON 36
NEUTRAL LOCK/PARKING BRAKE CONTROL LEVER 37
OPTIONAL TRANSMISSION CONTROLS 38
BACK-UP ALARM 38
FOOT THROTTLE, STEERING AND BRAKE PEDAL 39
DECELERATOR 40
DOZER BLADE CONTROL LEVER ..... 41 - 42
CONTROL HANDLE POSITIONS 43
RIPPER CONTROL LEVER 44
CAB CONTROLS 45
BATTERY DISCONNECT SWITCH 48
OPERATORS SEAT 49
OPERATORS SEAT BELT 51

OPERATING INSTRUCTIONS **53**

TRIM THIS EDGE

MidWestTech | Case 1150H Crawler Operator's Manual | Publication 6-20971 Order the manual at mid-west-tech.com >

RUN-IN PERIOD OF A NEW MACHINE 53
ENGINE OPERATION 54
CRAWLER OPERATION 57
TOWING A DISABLED CRAWLER 62
TRANSPORTING THE MACHINE 64
OPERATING IN HOT WEATHER 65
OPERATING IN COLD WEATHER 65
DOZER OPERATION 70
RIPPER OPERATING TIPS 76
TRACK SYSTEMS 77
VANDAL LOCKUP 91
BLADE LIFT EYE 91

LUBRICATON/FILTERS/FLUIDS 93
GENERAL SAFETY BEFORE YOU SERVICE 93
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 94
ENGINE HOURMETER 95
FLUIDS AND LUBRICANTS 96
LUBRICATION/MAINTENANCE CHART ..... 97 - 98
GREASE FITTINGS 99
ACCESS DOORS 101
ENGINE LUBRICATION 102
ENGINE SERVICE 103
AIR FILTER SYSTEM 106
ENGINE COOLING SYSTEM 110
DIESEL FUEL SYSTEM 113
HYDRAULIC SYSTEM 118
TRANSMISSION 121
FINAL DRIVES 128
CAB AIR FILTER 128

MAINTENANCE/ADJUSTMENTS 129
ETHER STARTING FLUID 129
TRANSMISSION CONTROL LEVER ADJUSTMENT 130
REVERSIBLE FAN POSITIONS (If Equipped) 131
AIR CONDITIONER DRIVE BELT 132
ROLL-OVER PROTECTIVE STRUCTURE 133
BRAKE WEAR CHECK 136
MACHINE CLEANING 136

ELECTRICAL SYSTEM 137
BATTERY SERVICE 137

TRIM THIS EDGE

MidWestTech | Case 1150H Crawler Operator's Manual | Publication 6-20971 Order the manual at mid-west-tech.com >

WORK LAMPS 138
WARNING LAMPS 139
FUSES 140
ACCESSORY OUTLET 140
BATTERY DISCONNECT SWITCH 141

STORAGE 143
MACHINE STORAGE 143
REMOVAL FROM STORAGE 144

SPECIFICATIONS 145
ENGINE SPECIFICATIONS 145
TRAVEL SPEEDS 146
HYDRAULIC SYSTEM 146
TRACK SYSTEM 147
OPERATING DATA AND DIMENSIONS -1.75 M (62 INCH) GAUGE LONG TRACK (LT) 148
OPERATING DATA AND DIMENSIONS - 1.88 M (74 INCH) GAUGE WIDE TRACK (WT) OR LOW GROUND PRESSURE (LGP) CRAWLERS 150
OPERATING DATA AND DIMENSIONS - RIPPER 151
WEIGHTS 152
AFTER DELIVERY CHECK 163
AFTER DELIVERY CHECK 165

TRIM THIS EDGE

MidWestTech | Case 1150H Crawler Operator's Manual | Publication 6-20971 Order the manual at mid-west-tech.com >