MX100, MX110, MX120 and MX135 Tractors

Operator's Manual

P.I.N. JJA0108301 and After
P.I.N. JJE0966253 and After

Rac 6-24671

CASE IH AGRICULTURE

MidWestTech | Case MX100, MX110, MX120, MX135 Tractor Operator's Manual | Publication 6-24671

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER **1**

IDENTIFICATION NUMBERS/MACHINE COMPONENTS **5**
MACHINE COMPONENTS 7

SAFETY/DECALS **9**
SAFETY 9
HAZARDOUS CHEMICALS 13
ROLL OVER PROTECTIVE STRUCTURE (ROPS) 17

INSTRUMENTS/CONTROLS **19**
INSTRUMENTS AND CONTROLS 19
OPERATORS SEAT 20
STANDARD (ANALOG) INSTRUMENT CLUSTER 29
DELUXE (DIGITAL) INSTRUMENT CLUSTER 32
OPERATING CONTROLS 39

OPERATING INSTRUCTIONS **57**
OPERATING INSTRUCTIONS 57
NORMAL STARTING PROCEDURE 61
PARKING THE TRACTOR AND STOPPING THE ENGINE 70
OPERATING THE TRANSMISSION 72
DRAWBAR 84
HEIGHT ADJUSTABLE TRAILER HITCH 88
TRAILER BRAKE COUPLINGS 89
TOWING THE TRACTOR 97
HOW TO TRANSPORT THE TRACTOR 98

FIELD OPERATION **99**
FIELD OPERATION 99
WHEEL SLIP INDICATOR 100
PROGRAMMING THE INSTRUMENT CLUSTER 102
DISTANCE FUNCTION OPERATION 113
AREA FUNCTION OPERATION 114
REAR POWER TAKEOFF 115
REAR THREE POINT HITCH PREPARATION 127
REAR THREE POINT HITCH OPERATION 134
REAR THREE POINT HITCH DIAGNOSTIC DISPLAY 147
DIFFERENTIAL LOCK CONTROL 150
MECHANICAL FRONT DRIVE (MFD) OPERATION 154
FRONT HITCH PREPARATION (If Equipped) 163

MidWestTech | Case MX100, MX110, MX120, MX135 Tractor Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

FRONT HITCH OPERATION 167
REMOTE HYDRAULIC VALVES 168
REMOTE HYDRAULICS OPERATION 173
IMPLEMENT CABLE ACCESS 179
FOLDABLE ROPS FRAME (If Equipped) 180
LOADER OPERATION 182

TIRES/WHEELS/SPACING/BALLAST 183
TIRES, WHEELS, SPACING AND BALLAST 183
TIRE AND WHEEL SERVICE 191
INSTRUMENT CLUSTER PROGRAMMING FOR TIRE SIZES 192
FRONT AXLE AND FRONT TREAD ADJUSTMENTS 194
MECHANICAL FRONT DRIVE (MFD) TRACTORS 203
FRONT TO REAR TIRE SIZE COMBINATIONS 204
MFD FRONT WHEEL FENDERS (If equipped) 205
REAR WHEEL TREAD ADJUSTMENT 207
TRACTOR BALLAST 217

LUBRICATION/MAINTENANCE 231
LUBRICATION AND MAINTENANCE 231
HOURMETER 232
HOOD AND SIDE PANELS 233
LUBRICANTS AND CAPACITIES 234
LUBRICATION AND MAINTENANCE CHART 236

ELECTRICAL SYSTEM 289
ELECTRICAL SYSTEM 289
BULB AND LAMP REPLACEMENT 293
FUSES 305

MACHINE STORAGE 309
PUTTING THE TRACTOR INTO STORAGE 309

TRAVEL SPEEDS 311
TRAVEL SPEEDS - PRIOR TO P.I.N. 311
TRAVEL SPEEDS - P.I.N. AND AFTER 338

SPECIFICATIONS 355
SPECIFICATIONS 355
GENERAL MACHINE 358
APPROXIMATE TRACTOR DIMENSIONS 361

DETAIL INDEX 369

MidWestTech | Case MX100, MX110, MX120, MX135 Tractor Operator's Manual | Publicati... Order the manual at mid-west-tech.com >