60XT, 70XT Skid Steers

Operators Manual

Bur 6-29451NA

CASE CONSTRUCTION

MidWestTech | Case 60XT, 70XT Skid Steer Operator's Manual | Publication 6-29451na

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
70XT SKID STEER 1
60XT SKID STEER 2
AFTER DELIVERY CHECK 3
RIGHT, LEFT, FRONT AND REAR OF MACHINE 4
Machine Front 4
Machine Rear 4
Machine Right-Hand Side 4
Machine Left-Hand Side 4
PRODUCT IDENTIFICATION AND SERIAL NUMBERS 5
Model Number 5
Product Identification Number (P.I.N.) 5
Engine 5
Engine Data Plate 5
ROPS 6
Loader Bucket 6
Starter 6
Hydrostatic Pump 6
60XT AND 70XT MACHINE COMPONENTS 7

SAFETY/DECALS/HAND SIGNALS 9
60XT AND 70XT SAFETY FEATURES 9
SAFETY MESSAGE 10
UTILITY SAFETY 11
PERSONAL SAFETY 12
BEFORE OPERATION 13
BEFORE OPERATION 14
MACHINE OPERATION 15
MACHINE OPERATION 16
FAILURE IN OPERATION 16
PARKING THE MACHINE 17
CAST DUCTILE IRON 17
BURN PREVENTION 18
WHEEL AND TIRE SAFETY 18
FIRE OR EXPLOSION PREVENTION 18
FIRE OR EXPLOSION PREVENTION 19
HAZARDOUS MATERIALS 19
MAINTENANCE 20
PRESSURIZED HYDRAULIC FLIUD AND GREASE 21
LOADER LIFT ARM SUPPORT STRUT 21
Installing the Support Strut 22
Storing the Support Strut 23
OPERATOR RESTRAINT SYSTEM 24
Seat Belt 24
Seat Bar 25

TRIM THIS EDGE

TRIM THIS EDGE

RIGHT PAGE (Chapter First Page)

Bur 6-29451NA

MidWestTech | Case 60XT, 70XT Skid Steer Operator's Manual | Publication 6-29451na Order the manual at mid-west-tech.com >

Operator Presence Switch 25
SAFETY DECALS 26
BACKHOE SAFETY DECALS 34
HAND SIGNALS 36
FORKLIFT HAND SIGNALS 40
GETTING ON AND OFF THE MACHINE 42
REAR WINDOW (IF EQUIPPED) - EMERGENCY EXIT 43
FIRE EXTINGUISHER 44
Type of Fire Extinguisher 44

INSTRUMENTS AND CONTROLS 45
OVERHEAD INSTRUMENT PANELS 45
RIGHT HAND INSTRUMENT PANEL ..... 46 - 48
RIGHT HAND INSTRUMENT PANEL
(Machines Equipped With
Automatic Engine Shutdown System) ..... 49 - 56
LEFT HAND INSTRUMENT PANEL ..... 58 - 60
Battery Master Disconnect Switch 61
LEFT HAND CONTROL LEVER 63
LEFT HAND CONTROL LEVER 64
RIGHT HAND CONTROL LEVER 65
RIGHT HAND CONTROL LEVER 66
TRAVEL/STEERING CONTROLS 67
TRAVEL/STEERING CONTROLS 68
LOADER CONTROLS 69
THROTTLE CONTROLS 70
HYDRAULIC BYPASS CONTROL 71
AUXILIARY HYDRAULIC ATTACHMENT CONTROLS 72
HIGH FLOW SYSTEM CONTROLS
GEAR PUMP 204 BAR (3000 PSI) 74
BACKHOE CONTROLS 75
OPERATORS SEAT 76
OPERATORS SEAT 77
BASIC HEATER CONTROLS 78
CAB (DELUXE) HEATER CONTROLS 79
Air Louvers (If Equipped) 80
CAB DOOR LATCHES (If Equipped) 81
SLIDING SIDE WINDOWS (IF EQUIPPED) 81
WINDSHIELD WASHER CONTROLS 82
DOME LAMP CONTROLS 82
BI-DIRECTIONAL BUCKET SELF-LEVELING
(OPTIONAL) 83
AUXILIARY ELECTRICAL SWITCH 84
ROTATING BEACON 84

OPERATING INSTRUCTIONS 85
Daily Inspection 85

TRIM THIS EDGE

TRIM THIS EDGE

LEFT PAGE

Bur 6-29451NA

MidWestTech | Case 60XT, 70XT Skid Steer Operator's Manual | Publication 6-29451na Order the manual at mid-west-tech.com >

Starting The Engine 86
RUN-IN PERIOD 87
Engine 87
Wheel Nuts 87
Hydraulic Filter 87
Drive Chains 87
Preventing Damage to the Hydrostatic System in Cold Temperatures . . 88
Engine Speed 88
Parking the Machine and Stopping the Engine 88
Booster Battery Connection 89
MACHINE OPERATION 91
TRANSPORTING THE MACHINE 92
Prior to Loading 92
MOVING A DISABLED MACHINE 93
Standard Machine 93
Machines Equipped With Spring Applied Hydraulic Release Brakes and Brake Release System
(If Equipped) 93
LIFTING THE MACHINE WITH A CRANE 95
OPERATING IN COLD WEATHER 96
OPERATING IN HOT WEATHER 97
JOB SITE OPERATION 97
OPERATING THE LOADER 98
MANUAL ATTACHMENT COUPLER 100
Installing a Bucket or Attachment 100
Removing a Bucket or Attachment 102
HYDRAULIC ATTACHMENT COUPLER 103
BACKHOE OPERATION 105
HIGH FLOW HYDRAULIC SYSTEM 115
RIDE CONTROL 116
ANTI-VANDAL LOCKOUT 117

WHEEL AND TIRES 119

LUBRICATION/MAINTENANCE CHART 123
TILTING THE OPERATORS COMPARTMENT FORWARD 124
LOWERING THE OPERATORS COMPARTMENT INTO THE OPERATING POSITION 126
ENGINE HOURMETER 127
MAINTENANCE LUBRICATION SCHEDULE 127
MAINTENANCE SCHEDULE 128
FLUIDS AND LUBRICANTS 130
ENVIRONMENT 130
LUBRICATION/MAINTENANCE CHART 131
LUBRICATION/MAINTENANCE CHART 132
MAINTENANCE SCHEDULE FOR OPTIONAL ATTACHMENTS 132

TRIM THIS EDGE

TRIM THIS EDGE

RIGHT PAGE

Bur 6-29451NA

MidWestTech | Case 60XT, 70XT Skid Steer Operator's Manual | Publication 6-29451na Order the manual at mid-west-tech.com >