921C Wheel Loader

Operators Manual

P.I.N. JEE0126216 and After

Bur 6-34080NA

CASE CONSTRUCTION

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-34080

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
- AFTER DELIVERY CHECK 3
- RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
- IDENTIFICATION NUMBERS 3
- MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
- SAFETY RULES 9
- UTILITY SAFETY 10
- BEFORE OPERATION 11
- MACHINE OPERATION 12
- PARKING THE MACHINE 12
- MAINTENANCE 13
- BURN PREVENTION 14
- FIRE OR EXPLOSION PREVENTION 14
- WHEELS AND TIRES SAFETY 15
- HAZARDOUS CHEMICALS 16
- INFORMATIONAL DECALS 17
- SAFETY DECALS 17
- HAND SIGNALS 26

INSTRUMENT/CONTROLS **29**
- FRONT CONSOLE ..... 29 - 33
- INSTRUMENT PANEL INDICATORS ..... 34 - 47
- INFORMATION CENTER ..... 48 - 53
- GAUGE DISPLAY ..... 54 - 60
- TRANSMISSION DISPLAY CENTER ..... 61 - 63
- FOOT PEDALS 64
- LOADER CONTROL LEVERS 65
- SIDE CONSOLE ..... 76 - 83
- MASTER DISCONNECT SWITCH 83
- OPERATORS SEAT 87
- SEAT BELT 90

OPERATING INSTRUCTIONS **93**
- BEFORE STARTING THE ENGINE 93
- RUN-IN PROCEDURE 93
- SEAT BELT 94
- STARTING THE ENGINE 95
- STOPPING THE ENGINE AND PARKING THE MACHINE 97
- MACHINE OPERATION 102
- LOADER CONTROL LEVERS 106
- LOADER FUNCTION SWITCHES 111
- DECLUTCH 114

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-34080 Order the manual at mid-west-tech.com >

RIDE CONTROL 114
BUCKET LEVEL INDICATOR 115
AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 115
ROTATING BEACON (IF EQUIPPED) 116
BRAKE ACCUMULATORS 116
COUPLER PIN ENGAGEMENT (IF EQUIPPED) 117
LOADER OPERATING TIPS 118
TOWING THE MACHINE 120
TRANSPORTING THE MACHINE 121
OPERATING IN COLD WEATHER 123
OPERATING IN HOT WEATHER 125

WHEELS/TIRES/BALLAST 127
BALLAST 127
WHEELS AND TIRES 127

LUBRICATION/FILTERS/FLUIDS 131
GENERAL SAFETY BEFORE YOU SERVICE 131
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 132
PLASTIC AND RESIN PARTS 133
ENVIRONMENT 133
TRANSPORT/SERVICE LINK 133
ENGINE HOURMETER 134
FLUIDS AND LUBRICANTS 135
LUBRICATION/MAINTENANCE CHART . . . . . 136 - 138
ACCESS DOORS 139
GREASE FITTINGS - 50 HOURS 140
GREASE FITTINGS - 100 HOURS 140
GREASE FITTINGS - 250 HOURS 141
GREASE FITTINGS - 1000 HOURS 141
FLUID LEVELS 142
ENGINE LUBRICATION 145
AIR FILTER SYSTEM 150
ENGINE COOLING SYSTEM 154
DIESEL FUEL SYSTEM 157
HYDRAULIC/BRAKE SYSTEM 160
TRANSMISSION 167
AXLES 170
CAB AIR FILTER 173

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-34080 Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENT **177**
ETHER CONTAINER 177
CAB SERVICE 178
TRANSMISSION CLUTCH CALIBRATION 181
DECLUTCH ADJUSTMENT 182
SECONDARY STEERING CHECK 184
PARKING BRAKE CHECK 185
LOADER ADJUSTMENTS 187
ROLL-OVER PROTECTIVE STRUCTURE 195
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 197
ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT . 198
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 201

ELECTRICAL SYSTEM **203**
BATTERY SERVICE 203
FUSES 205
SERVICE ELECTRICAL CONNECTOR (IF EQUIPPED) 205
AUXILIARY POWER OUTLET (IF EQUIPPED) 206
AUXILIARY POWER EQUIPMENT MOUNTING BRACKET LOCATION . 206
REPLACEMENT BULBS 207

MACHINE STORAGE **209**

SPECIFICATIONS **211**
ENGINE DATA 211
OPERATING DATA AND DIMENSIONS 921C 213
Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket with Teeth and Bolt on Edges 214
Machines with 3.82 m3(5.0 yd3) General Purpose Bucket 215
OPERATING DATA AND DIMENSIONS 921C XR 216
XR Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket 216
XR Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket with Teeth and Bolt on Edges 217
XR Machines with 3.82 m3 (5.0 yd3) General Purpose Bucket 218
OPERATING WEIGHT ADJUSTMENTS 219
SPECIAL BOLT TORQUES 220
AFTER DELIVERY CHECK 229
AFTER DELIVERY CHECK 231

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-34080 Order the manual at mid-west-tech.com >