SV208, SV210, SV212, SV216
SV223, SV223,SV228
VIBRATORY ROLLERS

Operator's Manual

6-34420

CASE
CONSTRUCTION

MidWestTech | Case SV208, SV210,SV212, SV216, SV223, SV223,SV228 Vibratory Roller... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - TO THE OWNER/SAFETY 1-1

SV208, SV210, SV212, SV216, SV223 and SV228 vibratory rollers 1-1

Right, left, front and rear of the machine 1-3

Type, serial number and year of manufacture 1-4

Identification of the main components of the machine 1-5

Safety rules 1-6

Personal safety 1-7

Before using the machine 1-8

Operating the machine 1-9

Parking the machine 1-10

Maintenance and adjustments 1-11

Prevention of fire or explosions 1-12

Prevention of burns 1-12

ROPS protective structure 1-13

Read Operators Manual 1-13

Decals 1-14

Hand signals 1-22

SECTION 2 - CONTROLS/INSTRUMENTS/ACCESSORIES 2-1

Cab door 2-1

Steps and access handles 2-1

Location of controls, instruments and accessories 2-2

Front console control functions 2-6

Front upper control functions 2-12

Right-hand arm control functions 2-13

Operator's seat 2-16

Accessory functions 2-19

SECTION 3 - OPERATING INSTRUCTIONS 3-1

Before operating the machine 3-1

Operating the machine 3-1

Run in period 3-2

Starting the engine 3-3

Shutting down the engine 3-6

Engine emergency shut down 3-7

Machine travel and direction of travel 3-8

Parking the machine 3-11

Tilting the operator's compartment and hood 3-13

Tilting the operator's compartment and hood using the electric hydraulic system 3-16

Driving the machine on rough ground 3-19

ROPS frame removal and installation 3-20

Cab removal and installation 3-21

MidWestTech | Case SV208, SV210,SV212, SV216, SV223, SV223,SV228 Vibratory Roller... Order the manual at mid-west-tech.com >

Section 3 - Operating Instructions (continued)

Adapting the smooth drum for tamping compaction 3-22
Machine articulation locking 3-26
Transporting the machine 3-28
Handling the machine 3-30
Towing the machine 3-31
Filling the tires with liquid ballast 3-35
Drum ballast solution (SV223, SV228) 3-39
Operating the machine in special conditions 3-41
Dozer blade (except SV208/SV210) 3-43

SECTION 4 - SERVICING INTERVALS/LUBRICATION/FLUIDS 4-1

Servicing intructions 4-1
Hourmeter 4-1
Servicing interval table 4-2
Fluids and lubricants 4-4
Fluid and lubricant specifications 4-6
Fluid and lubricant capacities 4-6
Environment 4-6
Grease points 4-7
Levels 4-11
Engine 4-15
Cooling system 4-18
Fuel system 4-21
Air filter 4-27
Hydraulic system 4-32
Drum 4-39
Drum ballast solution (only for SV223, SV228) 4-41
Transmission 4-42
Planetary reduction gears (SV208, SV210, SV212, SV216) 4-44
Planetary reduction gears (SV223, SV228) 4-46

SECTION 5 - MAINTENANCE/ADJUSTMENTS 5-1

Warning and control devices 5-1
Engine fan 5-2
Engine alternator and fan belt 5-2
Tires and wheels 5-4
Engine air intake system 5-6
Radiator and oil cooler 5-6
Shock absorbers/Mounting blocks 5-7

MidWestTech | Case SV208, SV210,SV212, SV216, SV223, SV223,SV228 Vibratory Roller... Order the manual at mid-west-tech.com >

Section 5 - Maintenance/Adjustments (continued)

Engine valve clearance (SV208, SV210, SV223, SV228) 5-9
Engine valve clearance (SV212, SV216) 5-13
Operator's compartment and engine hood tilting system strainer 5-16
Drum vibration frequency 5-17
Vibration shock absorber 5-18
Cleaning the machine 5-18
Operator's compartment intake air dust filter (Cab version) 5-19
Air-conditioning 5-20
Scrapers (SV208, SV210) 5-22
Scrapers (SV212, SV216, SV223, SV228) 5-23
Hardware torque specifications 5-24
Engine troubleshooting 5-25

SECTION 6 - ELECTRICAL SYSTEM 6-1

Fuses 6-1
Batteries 6-3
Booster batteries 6-5

SECTION 7 - STORAGE 7-1

Storing the machine 7-1

SECTION 8 - SPECIFICATIONS 8-1

SV208 - SV210 specifications 8-1
SV212 - SV216 specifications 8-6
SV223 - SV228 specifications 8-14

SECTION 9 - ALPHABETICAL INDEX 9-1

MidWestTech | Case SV208, SV210,SV212, SV216, SV223, SV223,SV228 Vibratory Roller... Order the manual at mid-west-tech.com >