325 and 330 Articulated Trucks

Operator's Manual

Cre 6-34980NA

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 325, 330 Articulated Trucks Operator's Manual | Publication 6-34980NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - TO THE OWNER/SAFETY 1-1

325 and 330 articulated trucks 1-1
Right, left, front and rear of the machine 1-3
Type, serial number and year of manufacture 1-4
Position of identification data on main component groups 1-5
Identification of the main components of the machine 1-8
Safety rules 1-9
Personal safety 1-10
Prevention of fires 1-11
Overturning accidents 1-11
Instructions for use 1-12
Maintenance instructions 1-15
Read Operators Manual 1-18
Decals 1-19
Hand signals 1-31

SECTION 2 - CONTROLS/INSTRUMENTS/ACCESSORIES 2-1

Accessing the cab 2-1
Accessing the platforms 2-1
Door 2-2
Location of controls, instruments and accessories 2-4
Driver's seat (Standard) 2-8
Driver's seat (Electro-pneumatic) 2-9
Trainer's seat 2-10
Seat belts 2-10
Accessory functions 2-11

SECTION 3 - OPERATING INSTRUCTIONS 3-1

Before operating the machine 3-1
Operating the machine 3-2
Run-in period 3-3
Starting and stopping the engine 3-4
Starting the vehicle 3-8
Stopping and parking the vehicle 3-9
Driving the vehicle 3-10
Using the automatic transmission 3-11
Using the hydraulic retarder (330 model) 3-16
Using the differential lock 3-17
Working with the vehicle 3-18
Towing the vehicle 3-20
Emergency steering 3-21

MidWestTech | Case 325, 330 Articulated Trucks Operator's Manual | Publication 6-34980NA Order the manual at mid-west-tech.com >

Operating instructions (continued)

Replacing a complete wheel 3-22
Auxiliary hoist control 3-25
Climate control system operation 3-26
Overturning accidents 3-27

SECTION 4 - SERVICING INTERVALS/LUBRICATION/FLUIDS 4-1

Servicing instructions 4-1
Preliminary operations 4-3
Scheduled maintenance program in hours 4-6
Lubrication and scheduled replacement chart (325 model) 4-8
Lubrication and scheduled replacement chart (330 model) 4-10
Operations to be carried out every day 4-12
Engine 4-15
Fuel supply system (325 model) 4-29
Fuel supply system (330 model) 4-32
Air intake system 4-33
Cooling system 4-38
Automatic transmission 4-44
Front axle/rear tandem axles 4-50
Hydraulic system 4-53
Hood opening system 4-57
Greasing 4-58

SECTION 5 - MAINTENANCE/ADJUSTMENTS 5-1

Suspension 5-1
Braking circuit 5-4
Tires and wheels 5-5
Air conditioning system 5-10
Bodywork 5-12
Troubleshooting 5-14

SECTION 6 - ELECTRICAL SYSTEM 6-1

Precautions 6-1
Battery maintenance (not sealed) 6-2
Control unit location 6-5
Transmission control unit 6-5
Fuse and relay box 6-6
Lighting system 6-11

SECTION 7 - STORAGE 7-1

Storing the vehicle 7-1

Order the manual at mid-west-tech.com >