21D and 221D Canopy Small Wheel Loaders

Operator's Manual

Ber 6-35160NA

CASE

MidWestTech | Case 21D, 221D Canopy Small Wheel Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

PART 1 - INTRODUCTION

PREFACE

After-Sales-Service 3

Warnings and symbols 4

Designated use 4

Organizational measures 5

Selection and qualification of personnel 6

OPERATING, SAFETY INSTRUCTIONS

Standard operation 6

MAINTENANCE, SAFETY INSTRUCTIONS 7

WARNING OF SPECIAL DANGERS

Electric energy 8
Gas, dust, steam and smoke 8
Hydraulic and pneumatic equipment 9
Noise 9
Oil, grease and other chemical substances 9

TRANSPORTING AND TOWING - RECOMMISSIONING 9

MidWestTech | Case 21D, 221D Canopy Small Wheel Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

PART 2 - OPERATION

OPERATION - SAFETY INSTRUCTIONS 13

DESCRIPTION OF THE MACHINE

Layout of the machine 16
Basic unit 17
Chassis 17
Drive unit 17
Axles 17
Brakes 17
Hydraulic system 17
Electrical system 17
Working equipment 17

TECHNICAL DATA 18

21D Wheel Loader 18

TECHNICAL DATA 22

221D Wheel Loader 22

Noise emissions

Outside the machine 27

Vibration levels

Vertical vibration level at the operator's seat 27
Vibration level at hands and arms 27

STABILITY

Center of gravity position during transport 28
Rated load at stability limit 29

Warning and instruction signs

Machine number 34
Engine number 34
Axle number 34
Travel pump number 34
Travel motor number 34
Attachments 34

DRIVER'S CAB

Entering and leaving the machine - Safety instructions 35

Documentation 36

Adjusting the operator's seat

MidWestTech | Case 21D, 221D Canopy Small Wheel Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

Adjusting the weight-oriented suspension 37
Weight adjustment 37
Height adjustment 37
Fore-and-aft adjustment 38
Backrest adjustment 38
Adjusting the right armrest 39
Height adjustment 39
Fore-and-aft adjustment 39

WARNING, MONITORING AND CONTROL ELEMENTS 40

Driver's compartment, overall layout 41

Warning and control lamps 42

Switches and pushbuttons 46

PUTTING THE MACHINE INTO OPERATION 50

Refueling
Refueling - Safety instructions 50
Refueling 50

Electrical system ON / OFF
Battery main switch 51

Immobilizer 51

Electrical system key-switch
Starting and stopping the engine 52
Starting 52
Engine does not start 53
Stopping the engine 53

Horn, turn signal and main beam 54

Lighting 55

DRIVING 56

Driving - Safety instructions 56

Adjustment of steering column
Steering column - Safety instructions 56
Adjusting the steering column 57

Seat belt
Seat belt - Safety instructions 57

Control lever - Traveling / Working 58

MidWestTech | Case 21D, 221D Canopy Small Wheel Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >