321D Canopy Small Wheel Loader

Operator's Manual

Ber 6-35190NA

CASE

MidWestTech | Case 321D Canopy Small Wheel Loader Operator's Manual | Publication 6-... Order the manual at mid-west-tech.com >

PART 1 - INTRODUCTION

PREFACE

After-Sales-Service 3

Warnings and symbols 4

Designated use 4

Organizational measures 5

Selection and qualification of personnel 6

OPERATING, SAFETY INSTRUCTIONS

Standard operation 6

MAINTENANCE, SAFETY INSTRUCTIONS 7

WARNING OF SPECIAL DANGERS

Electric energy 8

Gas, dust, steam and smoke 8

Hydraulic and pneumatic equipment 9

Noise 9

Oil, grease and other chemical substances 9

TRANSPORTING AND TOWING - RECOMMISSIONING 9

MidWestTech | Case 321D Canopy Small Wheel Loader Operator's Manual | Publication 6-... Order the manual at mid-west-tech.com >

PART 2 - OPERATION

OPERATION - SAFETY INSTRUCTIONS 13

DESCRIPTION OF THE MACHINE

Layout of the machine 16
Basic unit 17
Chassis 17
Drive unit 17
Axles 17
Brakes 17
Hydraulic system 17
Electrical system 17
Working equipment 17

TECHNICAL DATA 18

321D Wheel Loader 18

Noise emissions

Outside the machine 23

Vibration levels

Vertical vibration level at the operator's seat 23
Vibration level at hands and arms 23

STABILITY

Center of gravity position during transport 24
Rated load at stability limit 25

Warning and instruction signs

Machine number 30
Engine number 30
Axle number 30
Travel pump number 30
Travel motor number 30
Attachments 30

DRIVER'S CAB

Entering and leaving the machine - Safety instructions 31

Documentation 32

Adjusting the operator's seat

Adjusting the weight-oriented suspension 33
Weight adjustment 33
Height adjustment 33
Fore-and-aft adjustment 34

MidWestTech | Case 321D Canopy Small Wheel Loader Operator's Manual | Publication 6-... Order the manual at mid-west-tech.com >

Backrest adjustment 34
Adjusting the right armrest 35
Height adjustment 35
Fore-and-aft adjustment 35

WARNING, MONITORING AND CONTROL ELEMENTS 36

Driver's compartment, overall layout 37

Warning and control lamps 38

Switches and pushbuttons 42

PUTTING THE MACHINE INTO OPERATION 46

Refueling
Refueling - Safety instructions 46
Refueling 46

Electrical system ON / OFF
Battery main switch 47

Immobilizer 47

Electrical system key-switch
Starting and stopping the engine 48
Starting 48
Engine does not start 49
Stopping the engine 49

Horn, turn signal and main beam 50

Lighting 51

DRIVING 52

Driving - Safety instructions 52

Adjustment of steering column
Steering column - Safety instructions 52
Adjusting the steering column 52

Seat belt
Seat belt - Safety instructions 53

Control lever - Traveling / Working 54

Driving
Warming up the machine 55
Engine 55

MidWestTech | Case 321D Canopy Small Wheel Loader Operator's Manual | Publication 6-... Order the manual at mid-west-tech.com >