821C Wheel Loader

Operators Manual

P.I.N. JEE0155001 and After

Bur 6-36670NA

CASE CONSTRUCTION

MidWestTech | Case 821C Wheel Loader Operator's Manual | Publication 6-36670NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
- AFTER DELIVERY CHECK 3
- RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
- IDENTIFICATION NUMBERS 4
- MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
- SAFETY RULES 9
- UTILITY SAFETY 10
- BEFORE OPERATION 11
- MACHINE OPERATION 12
- PARKING THE MACHINE 12
- MAINTENANCE 13
- BURN PREVENTION 14
- FIRE OR EXPLOSION PREVENTION 14
- WHEELS AND TIRES SAFETY 15
- HAZARDOUS CHEMICALS 16
- INFORMATIONAL DECALS 17
- SAFETY DECALS 17
- HAND SIGNALS 25

INSTRUMENT/CONTROLS **29**
- FRONT CONSOLE ..... 29 - 33
- INSTRUMENT PANEL INDICATORS ..... 34 - 47
- INFORMATION CENTER ..... 48 - 53
- GAUGE DISPLAY ..... 54 - 60
- TRANSMISSION DISPLAY CENTER ..... 61 - 63
- FOOT PEDALS 64
- LOADER CONTROL LEVERS 65
- SIDE CONSOLE ..... 76 - 83
- MASTER DISCONNECT SWITCH 84
- OPERATORS SEAT 88
- SEAT BELT 91

OPERATING INSTRUCTIONS **93**
- BEFORE STARTING THE ENGINE 93
- RUN - IN PROCEDURE 93
- SEAT BELT 94
- STARTING THE ENGINE 95
- STOPPING THE ENGINE AND PARKING THE MACHINE 97
- MACHINE OPERATION 102
- LOADER CONTROL LEVERS 106
- LOADER FUNCTION SWITCHES 111
- BRAKE ACCUMULATORS 114

MidWestTech | Case 821C Wheel Loader Operator's Manual | Publication 6-36670NA Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

DECLUTCH 114
BUCKET LEVEL INDICATOR 115
AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 115
ROTATING BEACON (IF EQUIPPED) 116
RIDE CONTROL 116
COUPLER PIN ENGAGEMENT (IF EQUIPPED) 117
LOADER OPERATING TIPS 118
TOWING THE MACHINE 120
TRANSPORTING THE MACHINE 121
OPERATING IN COLD WEATHER 123
OPERATING IN HOT WEATHER 125

WHEELS/TIRES/BALLAST 127
BALLAST 127
WHEELS AND TIRES 127

LUBRICATION/FILTERS/FLUIDS 133
GENERAL SAFETY BEFORE YOU SERVICE 133
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 134
PLASTIC AND RESIN PARTS 134
ENVIRONMENT 135
TRANSPORT/SERVICE LINK 135
ENGINE HOURMETER 136
FLUIDS AND LUBRICANTS 137
LUBRICATION/MAINTENANCE CHART 138
LUBRICATION/MAINTENANCE CHART 139
LUBRICATION/MAINTENANCE CHART 140
ACCESS DOORS 141
GREASE FITTINGS - 50 HOURS 142
GREASE FITTINGS - 100 HOURS 142
GREASE FITTINGS - 250 HOURS 143
GREASE FITTINGS - 1000 HOURS 143
FLUID LEVELS 144
ENGINE LUBRICATION 147
AIR FILTER SYSTEM 152
ENGINE COOLING SYSTEM 156
DIESEL FUEL SYSTEM 160
HYDRAULIC/BRAKE SYSTEM 163
TRANSMISSION 170
AXLES 173
CAB AIR FILTER 176

MAINTENANCE/ADJUSTMENT 179
ETHER CONTAINER 179
CAB SERVICE 180
TRANSMISSION CLUTCH CALIBRATION 183

MidWestTech | Case 821C Wheel Loader Operator's Manual | Publication 6-36670NA Order the manual at mid-west-tech.com >

DECLUTCH ADJUSTMENT 184
SECONDARY STEERING CHECK 186
PARKING BRAKE CHECK 187
LOADER ADJUSTMENTS 189
ROLL-OVER PROTECTIVE STRUCTURE 197
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 199
ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT . 200
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 201

ELECTRICAL SYSTEM 203
BATTERY SERVICE 203
FUSES 205
SERVICE ELECTRICAL CONNECTOR (IF EQUIPPED) 205
AUXILIARY POWER OUTLET (IF EQUIPPED) 206
AUXILIARY POWER EQUIPMENT MOUNTING BRACKET LOCATION . 206
REPLACEMENT BULBS 207

MACHINE STORAGE 209

SPECIFICATIONS 211
ENGINE DATA 211
OPERATING DATA AND DIMENSIONS 821C 213
OPERATING DATA AND DIMENSIONS 821C XR 216
OPERATING WEIGHT ADJUSTMENTS 219
SPECIAL BOLT TORQUES 220

INDEX 221

AFTER DELIVERY CHECK 229

AFTER DELIVERY CHECK 231

MidWestTech | Case 821C Wheel Loader Operator's Manual | Publication 6-36670NA Order the manual at mid-west-tech.com >