CX47
MINI-EXCAVATOR

Operator's Manual

Bur 6-37931

CASE

MidWestTech | Case CX47 Mini Excavator Operator's Manual | Publication 6-37931

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CHAPTER 1
GENERAL INFORMATION
To the Owner . . . 1-1
Right, Left, Front, and Rear of the Machine . . . 1-2
Machine Components . . . 1-3
Identification Numbers . . . 1-5

CHAPTER 2
SAFETY, DECALS, AND HAND SIGNALS
Table of Contents . . . 2-1
Safety Rules . . . 2-3
Personal Safety . . . 2-3
Safety Area . . . 2-3
Utility Safety . . . 2-4
Operator Precautions . . . 2-4
Decals . . . 2-10

CHAPTER 3
INSTRUMENTS AND CONTROLS
Table of Contents . . . 3-1
Cab (If Equipped) . . . 3-3
Steps and Access Handles . . . 3-5
Operator's Compartment Controls and Accessories . . . 3-6
Instrument Panel . . . 3-7
Switches . . . 3-9
Control Levers . . . 3-11
Access Covers and guards . . . 3-14
Operator's Seat Adjustment . . . 3-15
Seat Belt . . . 3-15

CHAPTER 4
OPERATING INSTRUCTIONS
Table of Contents . . . 4-1
Before Operating the Machine . . . 4-3
Operating the Machine . . . 4-3
Run-In Period . . . 4-4
Starting the engine . . . 4-4
Bringing the Machine Up To Operating Temperature . . . 4-6
Engine Operation . . . 4-7
Stopping the Engine . . . 4-7
Operating the Machine in Cold Weather . . . 4-8
Operating the Machine in Hot Weather . . . 4-8
Operation . . . 4-8
Machine Travel . . . 4-9
Transporting the Machine . . . 4-10
Operating the Machine in Water . . . 4-13
Parking the Machine . . . 4-14
Operating the Machine on Sloping Ground . . . 4-14
Moving A Disabled Machine . . . 4-14
Lowering the Attachment in the Event of a Machine Failure . . . 4-14
Operating the Bucket . . . 4-15
Machine Storage . . . 4-16

MidWestTech | Case CX47 Mini Excavator Operator's Manual | Publication 6-37931 Order the manual at mid-west-tech.com >

CHAPTER 5
LUBRICATION, FILTERS, AND FLUIDS
Table of Contents ... 5-1
Servicing Instructions ... 5-3
Fluids and Lubricants ... 5-4
Daily Inspections ... 5-7
Lubrication and Maintenance Chart ... 5-8
Grease Fittings and Lubrication Points ... 5-10
Engine Oil ... 5-14
Cooling System ... 5-16
Fuel System ... 5-19
Releasing Pressure in the Hydraulic System ... 5-24
Hydraulic System ... 5-25
Air Filter ... 5-33
Travel Reduction Gears ... 5-34

CHAPTER 6
MAINTENANCE AND ADJUSTMENTS
Table of Contents ... 6-1
Tracks ... 6-3
Checking the Condition of Rubber Tracks ... 6-6
Track Rollers and idlers ... 6-8
Replacing a Bucket ... 6-9
Fan and alternator Drive Belt ... 6-11
Inspecting and Cleaning the Machine ... 6-11
Checking for Cylinder Leakage ... 6-11
Fire Extinguisher (Not Supplied) ... 6-12
Plastic and Resin Parts ... 6-12
Welding on the Machine ... 6-12
Metric Torque Specifications ... 6-13

CHAPTER 7
ELECTRICAL
Table of Contents ... 7-1
Alternator ... 7-3
Starter Motor ... 7-3
Fuses ... 7-3
Battery ... 7-4
Connecting A Booster Battery ... 7-6
Attachment (Boom) Lamp ... 7-7

CHAPTER 8
SPECIFICATIONS
Table of Contents ... 8-1
Engine ... 8-3
Hydraulic Components ... 8-3
Speed and Gradeability ... 8-3
Boom Swing and Dozer Blade ... 8-3
Machine Overall Dimensions - ROPS Canopy ... 8-4
Machine Overall Dimensions - Cab Model ... 8-5
Working Range ... 8-6

CHAPTER 9
INDEX

MidWestTech | Case CX47 Mini Excavator Operator's Manual | Publication 6-37931 Order the manual at mid-west-tech.com >