bobcat

643

S/N 13001 -

Operation & Maintenance Manual



MELROE COMPANY

6566557 (4-83)-2.5C

Printed in U.S.A.

MidWestTech | Bobcat 643 Skid Steer Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

SAFETY INSTRUCTIONS

SAFETY IS YOUR RESPONSIBILITY

The Skid-Steer Loader is a highly maneuverable and compact machine. In operation, it is rugged and useful under a wide variety of conditions. This presents an operator with hazards which are common for off-highway, rough-terrain applications but are not unique for use of the Bobcat loaders.

The loader has an internal combustion engine with resultant heat and exhaust. All exhaust gases can kill so the loader must be used with adequate ventilation. The loader must not be used in space with ex' losive dusts or gases or so that the engine exhaust contacts flammable material. The loader has a spark arrestor muffler which is required for operation in certain areas.

For loader applications, the dealer recommends the capabilities and restrictions of the loader and attachments for each application use. The dealer demonstrates the safe operation of the loader according to the manufacturer's instructional materials which are also available to all operator's. The dealer can also identify unsafe modifications or use of unapproved attachments. The attachments and buckets are designed for rated capacity and secure fastening to the loader. For each model loader, the user must check with the dealer or manufacturer's literature to identify each bucket or attachment for safe loads of materials of specified densities.

The following publications provide information on the safe use of the loader and attachments:

1. The Delivery Report is used to check whether complete instructions have been given to the new owner.

2. The Operator's Manual delivered with every loader gives operating information as well as routine maintenance and service.

3. Every loader has signs (decals) which instruct on the safe care and operation of the loader. The complete signs and their location are shown in the Operator's Manual. All signs are available from the dealer.

4. The Bobcat loader has a plastic Operator Handbook fastened by cable to the operator cab. It has brief operations always available to the operator. The handbook is available from the dealer in an English edition or a combination English, French, German, Spanish edition.

5. The Service Manual and Parts Book are optional manuals from the dealer for use by mechanics to do shop-type service and repair work.

The dealer and owner/operator review the recommended uses of the loader and attachments at the time of delivery of the loader. If change of the use of the loader occurs in the future, the owner/operator must remember to ask the dealer for recommendations on the new use of the loader.

BEFORE YOU OPERATE THE BOBCAT LOADER

⚠ WARNING

All operators must have instruction before operating this loader.



B-6584

This Operator's Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Bobcat loader. READ AND UNDERSTAND THIS OPERATOR'S MANUAL BEFORE YOU OPERATE YOUR BOBCAT. If you have any questions, see your local Bobcat dealer.

Make sure your Bobcat loader is in good operating condition.

Check all of the items on the Service Schedule under the 8 - 10 hour column.

⚠ WARNING

For your safety, warnings are on the loader and in the manual. Failure to follow these warnings can cause injury or death.

IMPORTANT

This notice shows important procedures which must be followed to prevent damage to the loader.

MidWestTech | Bobcat 643 Skid Steer Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >