bobcat

1600

Operation & Maintenance Manual



MELROE COMPANY

6566667 (Revised 2-95)-1M

A BUSINESS UNIT OF [illegible] EQUIPMENT COMPANY

Printed in U.S.A.

MidWestTech | Bobcat 1600 Articulated Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >

SAFETY INSTRUCTIONS

SAFETY IS YOUR RESPONSIBILITY

The Bobcat loader is a higly maneuverable and compact machine. In operation, it is rugged and useful under a wide variety of conditions. This presents the operator with hazards which are common for off highway rough terrain applications but are not unique for use of Bobcat loaders. The loader has an internal combustion engine with resultant heat and exhaust. All exhaust gases can kill so that the loader must be used with adequate ventilation. The loader must not be used in space with explosive dusts or gases or so that the engine exhaust contacts flammable material. The loader has a spark arrestor muffler which is required for operation in certain area.

For loader applications, the dealer recommends the capabilities and restrictions of the loader and attachments for each application. The dealer demonstrates the safe operation of the loader according to the manufacturer's instructional materials which are also available to all operators. The dealer can also identify unsafe modifications or use of unapproved attachments. The attachments and buckets are designed for rated capacity and secure fastening to the loader. For each model loader, the user must check with the dealer or manufacturer's literature to identify each bucket or attachment for safe loads of materials of specified densities.

The following publications provide information on the safe use of the loader and attachments:

1. The Delivery Report is used to check whether complete instuctions have been given to the new owner.
2. The Operator's Manual delivered with every loader gives information as well as routine maintenance and service.
3. Every loader has signs (or decals) which instruct on the safe care and operation of the loader. The complete signs and their location are shown in the Operator's Manual. Any missing signs are available from the dealer.
4. The loader has a plastic Operator Handbook fastened to the operator cab. It has brief instructions always available to the operator.
5. The Service Manual and Parts Book are optional manuals from the dealer for use by mechanics to do shop-type service and repair work.

The dealer and owner/operator review the recommended uses of the loader and attachments at the time of delivery of the loader. If change of the use of the loader occurs in the future, the owner/operator must remember to ask the dealer for recommendations on the new use of the loader.

BEFORE YOU OPERATE THE BOBCAT LOADER

⚠ WARNING

All operators must have instruction before operating this loader.



8-6584

This Operator's Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Bobcat loader. READ AND UNDERSTAND THIS OPERATOR'S MANUAL BEFORE YOU OPERATE YOUR BOBCAT. If you have any questions, see your local Bobcat dealer.

Make sure your Bobcat loader is in good operating condition.

Check all of the items on the Service Schedule under the 8 - 10 hour column.

⚠ WARNING

For your safety, warnings are on loader and in manual. Failure to obey warnings can cause injury or death.

W-1003

IMPORTANT

This notice identifies procedures which must be followed to prevent damage to the loader.

I-1001

MidWestTech | Bobcat 1600 Articulated Wheel Loader Operation... Order the manual at mid-west-tech.com >