# JX55, JX65, JX75, JX85, JX95 Tractors

## Operator's Manual

6-61331

CASE IH AGRICULTURE

MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Operator's Manual | Publication 6-61331

Order the manual at mid-west-tech.com >

# CONTENTS


Page

**Section 1 - General Information and Safety** ..... 1-1
To the owner ..... 1-1
Introduction ..... 1-2
Using this manual ..... 1-3
Communication for the user ..... 1-4
Important ecological considerations ..... 1-5
Tractor identification data ..... 1-6
Working safely ..... 1-9
Safety covers and guards ..... 1-16
Safety decals ..... 1-18
Standardized symbols ..... 1-22

**Section 2 - Controls, Instruments and Operation** ..... 2-1
Driver's seat ..... 2-2
Instrument Panel ..... 2-6
Instrument console controls ..... 2-11
Operating controls, right-hand side ..... 2-13
Operating controls, left-hand side ..... 2-14
Cab controls ..... 2-16
Cab ..... 2-19
Cab air conditioning system ..... 2-26
Operation ..... 2-31
Before using the tractor ..... 2-31
Starting the engine ..... 2-32
12x12 Synchronized mechanical shuttle - 30 km/h (19 mph) (12F+12R - Synchro Shuttle) ..... 2-35
20x12 Synchronized mechanical shuttle with creeper - 30 km/h (19 mph) (20F+12R - Synchro Shuttle) ..... 2-37
Mechanical MFD engagement ..... 2-39
Mechanical controlled differential lock ..... 2-40
Lim-slip front differential lock ..... 2-40

**Section 3 - Field Operation** ..... 3-1
Power take-off ..... 3-1
Hydraulic lift ..... 3-5
Three-point linkage ..... 3-9
Towing equipment ..... 3-13
Folding ROPS ..... 3-15
Remote control valves ..... 3-16




MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >

Page

**Tires, wheels, tracks, ballast** ..... 3-18
Wheel track adjustment ..... 3-18
Steering angle adjustment ..... 3-23
Tire maintenance ..... 3-24
Tire loading information ..... 3-25
Data and inflation pressures ..... 3-26
Tire combinations ..... 3-27
Ballasting ..... 3-30
Maximum permitted weight ..... 3-35

**Section 4 - Lubrication and maintenance** ..... 4-1
Introduction ..... 4-1
Tractor Refueling ..... 4-2
Access for inspection and maintenance ..... 4-4
Products and quantities for refilling ..... 4-5
Lubrication and maintenance table ..... 4-7
Flexible maintenance ..... 4-9
When the warning light is on ..... 4-11
Every 10 hours of work ..... 4-13
Every 50 hours of work ..... 4-18
Every 300 hours of work ..... 4-21
Every 900 hours of work ..... 4-26
Every 1200 hours or every year ..... 4-27
Every 1200 hours of work or every 2 years ..... 4-29
General maintenance ..... 4-35
Recommendations for bodywork maintenance ..... 4-36

**Section 5 - Troubleshooting** ..... 5-1

**Section 6 - Tractor storage** ..... 6-1

**Section 7 - Accessories** ..... 7-1
Electrical system ..... 7-1

**Section 8 - Specifications and data** ..... 8-1

**Index** ..... 8-15

**Service Sheets** ..... 8-19



MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Operator's Manual | Publicatio... Order the manual at mid-west-tech.com >