921C Loader

Operators Manual

Bur 6-6221

Reprinted

CASE CONSTRUCTION

MidWestTech | Case 921C Loader Operator's Manual | Publication 6-6221

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
AFTER DELIVERY CHECK 3
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 4
MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY RULES 9
UTILITY SAFETY 10
BEFORE OPERATION 11
MACHINE OPERATION 12
PARKING THE MACHINE 12
MAINTENANCE 13
BURN PREVENTION 14
FIRE OR EXPLOSION PREVENTION 14
WHEELS AND TIRES SAFETY 15
HAZARDOUS CHEMICALS 16
INFORMATIONAL DECALS 17
SAFETY DECALS 17
HAND SIGNALS 26

INSTRUMENT/CONTROLS **29**
FRONT CONSOLE ..... 29 - 33
INSTRUMENT PANEL INDICATORS ..... 34 - 49
INFORMATION CENTER ..... 50 - 55
GAUGE DISPLAY ..... 56 - 62
TRANSMISSION DISPLAY CENTER ..... 63 - 65
FOOT PEDALS 66
LOADER CONTROL LEVERS 67
SIDE CONSOLE ..... 72 - 79
MASTER DISCONNECT SWITCH 79
OPERATORS SEAT 83
SEAT BELT 86

OPERATING INSTRUCTIONS **89**
BEFORE STARTING THE ENGINE 89
RUN-IN PROCEDURE 89
SEAT BELT 90
STARTING THE ENGINE 91
STOPPING THE ENGINE AND PARKING THE MACHINE 93
MACHINE OPERATION 98
LOADER CONTROL LEVERS 102
LOADER FUNCTION SWITCHES 108
CLUTCH CUTOUT 111

TRIM THIS EDGE

MidWestTech | Case 921C Loader Operator's Manual | Publication 6-6221 Order the manual at mid-west-tech.com >

RIDE CONTROL 111
BUCKET LEVEL INDICATOR 112
AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 112
ROTATING BEACON (IF EQUIPPED) 113
COUPLER PIN ENGAGEMENT (IF EQUIPPED) 114
LOADER OPERATING TIPS 115
TOWING THE MACHINE 117
TRANSPORTING THE MACHINE 118
OPERATING IN COLD WEATHER 120
OPERATING IN HOT WEATHER 122

WHEELS/TIRES/BALLAST 123
BALLAST 123
WHEELS AND TIRES 123

LUBRICATION/FILTERS/FLUIDS 127
GENERAL SAFETY BEFORE YOU SERVICE 127
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 128
PLASTIC AND RESIN PARTS 129
ENVIRONMENT 129
TRANSPORT/SERVICE LINK 129
ENGINE HOURMETER 130
FLUIDS AND LUBRICANTS 131
LUBRICATION/MAINTENANCE CHART 132
LUBRICATION/MAINTENANCE CHART 133
LUBRICATION/MAINTENANCE CHART 134
ACCESS DOORS 135
GREASE FITTINGS - 50 HOURS 136
GREASE FITTINGS - 100 HOURS 137
GREASE FITTINGS - 1000 HOURS 137
FLUID LEVELS 138
ENGINE LUBRICATION 141
AIR FILTER SYSTEM 146
ENGINE COOLING SYSTEM 150
DIESEL FUEL SYSTEM 153
HYDRAULIC/BRAKE SYSTEM 156
TRANSMISSION 163
AXLES EARLY PRODUCTION GKN (DANA) 166
AXLES LATE PRODUCTION ZF 169
CAB AIR FILTER 172

TRIM THIS EDGE

MidWestTech | Case 921C Loader Operator's Manual | Publication 6-6221 Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENT **177**
ETHER CONTAINER 177
CAB SERVICE 178
TRANSMISSION CLUTCH CALIBRATION 181
CLUTCH CUTOUT ADJUSTMENT 182
SECONDARY STEERING CHECK 184
PARKING BRAKE CHECK 185
LOADER ADJUSTMENTS 187
ROLL-OVER PROTECTIVE STRUCTURE 195
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 197
FAN, BELT, ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT 198
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 202
SPARK ARRESTING MUFFLER (IF EQUIPPED) 203

ELECTRICAL SYSTEM **205**
BATTERY SERVICE 205
FUSES 207
SERVICE ELECTRICAL CONNECTOR (IF EQUIPPED) 207
AUXILIARY POWER OUTLET (IF EQUIPPED) 208
AUXILIARY POWER EQUIPMENT MOUNTING BRACKET LOCATION 208
REPLACEMENT BULBS 209

MACHINE STORAGE **211**

SPECIFICATIONS **213**
ENGINE DATA 213
OPERATING DATA AND DIMENSIONS 921C 215
MACHINES WITH 3.63 M3 (4.75 YD3) GENERAL PURPOSE BUCKET WITH TEETH AND BOLT ON EDGES 216
MACHINES WITH 3.82 M3(5.0 YD3) GENERAL PURPOSE BUCKET 217
OPERATING DATA AND DIMENSIONS 921C XR 218
XR MACHINES WITH 3.63 M3 (4.75 YD3) GENERAL PURPOSE BUCKET 218
XR MACHINES WITH 3.63 M3 (4.75 YD3) GENERAL PURPOSE BUCKET WITH TEETH AND BOLT ON EDGES 219
XR MACHINES WITH 3.82 M3 (5.0 YD3) GENERAL PURPOSE BUCKET 220
OPERATING WEIGHT ADJUSTMENTS 221
SPECIAL BOLT TORQUES 222
AFTER DELIVERY CHECK 231
AFTER DELIVERY CHECK 233

TRIM THIS EDGE

MidWestTech | Case 921C Loader Operator's Manual | Publication 6-6221 Order the manual at mid-west-tech.com >