686G, 686GXR and 688G Telescopic Handler Series 2

Operators Manual

Bur 6-8750NA

CASE CONSTRUCTION

MidWestTech | Case 686G, 686GXR, 688G Series 2 Telescopic Handler Operator's Manual... Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

TO THE OWNER **1**
AFTER DELIVERY CHECK 2
PRODUCT IDENTIFICATION AND SERIAL NUMBERS 3
RIGHT, LEFT, FRONT AND REAR OF MACHINE 5
MACHINE MAIN COMPONENTS 6

SAFETY/DECALS **7**
SAFETY RULES 7
SAFE OPERATION 8
BEFORE OPERATION 9
MACHINE OPERATION 11
PARKING THE MACHINE 15
BURN PREVENTION 15
FIRE OR EXPLOSION PREVENTION 16
MAINTENANCE 17
TRANSPORTING AND HAULING 18
ROPS 19
OPERATOR PROTECTION EQUIPMENT 20
WHEEL AND TIRE MAINTENANCE 20
LOAD HANDLING 21
RATED CAPACITY CHART 22
HAZARDOUS SUBSTANCE PRECAUTION 37
SUPPORT STRUT 38
OPERATOR RESTRAINT SYSTEM 39
SAFETY DECALS 40
HAND SIGNALS 46

INSTRUMENTS/CONTROLS **49**
OPERATING CONTROLS 49
SEAT CONTROLS 57
SEAT BELTS 58
CAB OPTIONS 59

TRIM THIS EDGE

MidWestTech | Case 686G, 686GXR, 688G Series 2 Telescopic Handler Operator's Manual... Order the manual at mid-west-tech.com >

OPERATING INSTRUCTIONS **61**
GENERAL INFORMATION 61
STABILITY AND CENTER OF GRAVITY 62
INSPECTION BEFORE OPERATION 64
MACHINE OPERATION 66
STARTING PROCEDURES 68
PRE-OPERATION CHECKS 69
ENGINE STARTING AIDS 70
BASIC OPERATING PROCEDURES 74
STEERING AND TURNING 76
HANDLING AND MOVING LOADS 79
LIFTING, LOWERING, AND TILTING THE BOOM 80
TRAVELING 84
ATTACHMENTS 85
PARKING 85
TOWING 86
TRANSPORTATION 86
MOVING A DISABLED MACHINE 88
OPERATING IN COLD WEATHER 89
OPERATING IN HOT WEATHER 90
VANDAL LOCKUP KITS 90
QUICK ATTACH 91

WHEELS/TIRES **93**
WHEEL AND TIRES 93

FUEL AND LUBRICATION **95**
GENERAL SAFETY BEFORE YOU SERVICE 95
ENVIRONMENT 95
PLASTIC AND RESIN PARTS 96
ENGINE HOURMETER 96
FLUID CAPACITIES AND LUBRICANTS 97
ENGINE LUBRICATION 98
HYDRAULIC OIL REQUIREMENTS AND SPECIFICATIONS 101
LUBRICATING OIL/GREASE SPECIFICATIONS (EXCEPT ENGINE) 102
ENGINE LUBRICATING OIL SPECIFICATIONS 102
CASE FUEL SPECIFICATIONS 103
HAZARDOUS SUBSTANCE PRECAUTION 104

TRIM THIS EDGE

MidWestTech | Case 686G, 686GXR, 688G Series 2 Telescopic Handler Operator's Manual... Order the manual at mid-west-tech.com >

MAINTANENCE/ADJUSTMENTS **105**
GENERAL MAINTENANCE INFORMATION 105
ETHER COLD STARTING AID 106
ROLL-OVER PROTECTIVE STRUCTURE 107
FIRE EXTINGUISHER 111
BATTERY MAINTENANCE 112
FUSES 114
STORAGE 115
REMOVAL FROM STORAGE 116
INITIAL BREAK-IN MAINTENANCE 117
10 HOUR OR DAILY ROUTINE MAINTENANCE 118
50 HOUR OR WEEKLY ROUTINE MAINTENANCE 128
250 HOUR OR QUARTERLY ROUTINE MAINTENANCE 135
1000 HOUR OR ANNUAL ROUTINE MAINTENANCE 141

SPECIFICATIONS **147**
ISO METRIC TORQUE CHART 147
SAE TORQUE CHART 148
686G TELESCOPIC HANDLER DIMENSIONS 149
686GXR TELESCOPIC HANDLER DIMENSIONS 150
688G TELESCOPIC HANDLER DIMENSIONS 151
ENGINE 152
ELECTRICAL SYSTEM 152
DIESEL FUEL 153
HYDRAULIC SYSTEM 154
CAPACITIES 154
TRAVEL SPEEDS 154
OPERATING WEIGHTS 155
PERFORMANCE RATING SPECIFICATIONS 156

DETAIL INDEX **157**

AFTER DELIVERY CHECK **161**

TRIM THIS EDGE

MidWestTech | Case 686G, 686GXR, 688G Series 2 Telescopic Handler Operator's Manual... Order the manual at mid-west-tech.com >