
Bobcat®

Operation & Maintenance Manual
Planer

(18 Hyd Planer) S/N 231611101 & Above
(18 In.) S/N 341000101 & Above
(24 Hyd Planer) S/N 231711101 & Above
(24 In.) S/N 721700101 & Above



6900636 (6-06) Revised (9-09) (4)

Printed in U.S.A.

© Bobcat Company 2009

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

CONTENTS

CONTENTS 1

FOREWORD 3

SAFETY & TRAINING RESOURCES 11

OPERATING INSTRUCTIONS 19

PREVENTIVE MAINTENANCE 47

SPECIFICATIONS 59

WARRANTY 63

ALPHABETICAL INDEX 67

REFERENCE INFORMATION

Write the correct information for YOUR planer in the spaces below. Always use these numbers when referring to your planer.

Planer Serial Number _____

NOTES:

_____

_____

_____

_____

_____

YOUR BOBCAT DEALER:

_____

ADDRESS:

_____

PHONE:

_____

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Drève Richelle 167
B-1410 WATERLOO
Belgium

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

FOREWORD

This Operation & Maintenance Manual was written to give the owner /operator instructions on the safe operation and maintenance of the planer. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR PLANER. If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001:2000 CERTIFIED 5

SERIAL NUMBER LOCATION 7
Attachment Serial Number 7

DELIVERY REPORT 7

ATTACHMENT IDENTIFICATION 8

FEATURES AND ACCESORIES 9
Standard Items 9
Options And Accessories 9

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

Use Safety Rules

- Read and follow instructions in the machine and the attachment's Operation & Maintenance Manual before operating.
- Check for underground lines before operating attachment (if applicable).
- In addition to the design and configuration of equipment, hazard control and accident prevention are dependent upon the awareness, concern, prudence and proper training of personnel involved in the operation, transport, maintenance and storage of equipment.
- Check that the Bob-Tach™ levers are in the locked position and the wedges are fully engaged into the holes of the attachment (if applicable).
- Check that the attachment is securely fastened to the machine.
- Make sure all the machine controls are in the NEUTRAL position before starting the machine.
- Operate the attachment only from the operator's position.
- Operate the attachment according to the Operation & Maintenance Manual.
- When learning to operate the attachment, do it at a slow rate in an area clear of bystanders.
- DO NOT permit personnel to be in the work area when operating the machine and attachment.
- The attachment must be used ONLY on approved machines. See your Bobcat dealer for updated list of approved attachments for each machine model.
- DO NOT modify equipment or add attachments that are not approved by the manufacturer.
- DO NOT make any adjustments or repairs on the machine or attachment while the engine is running.
- Keep shields and guards in place. Replace if damaged.

Call Before You Dig



Call Before You Dig
Dial 811 (USA Only)
1-888-258-0808 (USA & Canada)

When you call, you will be directed to a location in your state / province, or city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.).

Avoid Silica Dust



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

SI ATT-0509

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >


Drive Carrier Oil Change

IMPORTANT

Fluid such as engine oil, hydraulic fluid, coolants, grease, etc. must be disposed of in an environmentally safe manner. Some regulations require that certain spills and leaks on the ground must be cleaned in a specific manner. See local, state and federal regulations for the correct disposal.

I-2067-0499


Figure 63



Change the oil after the first 300 hours and every 500 hours thereafter.

Position the drum with the plug (Item 1) **[Figure 63]** at the 6 o'clock position. Remove the plug and drain the oil into a suitable container.

Figure 64



Rotate the drum so the filler hole (Item 1) **[Figure 64]** is 45° from the 12 o'clock position. Fill the drive carrier with a non-extreme pressure SAE 40 industrial oil until the oil is at the bottom of the threaded hole.

Drum Carbide Bits Check

Check the bits every three hours of operation.


The bits must be free to rotate in their holders. If the bit will not rotate, uneven and rapid wear will result.

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

(18 HYD PLANER, 18 IN., 24 HYD PLANER & 24 IN.) PLANER SPECIFICATIONS

Dimensions

- All dimensions are shown in inches. Respective metric dimensions are given in millimeters enclosed by parentheses.
- Where applicable, specifications conform to **SAE and ISO** standards and are subject to change without notice.



DESCRIPTION	18 IN. PLANER	24 IN. PLANER
Width (A)	66.0 in. (1676 mm)	66.0 in. (1676 mm)
Length (B)	49 in. (1245 mm)	49 in. (1245 mm)
Height (C)	28.0 in. (711 mm)	28.0 in. (711 mm)

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

SAFETY INSTRUCTIONS

Safe Operation Is The Operator's Responsibility

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

W-2001-0502

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107

WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The Bobcat machine and attachment must be in good operating condition before use.

Check all of the items on the Bobcat Service Schedule Decal under the 8-10 hour column or as shown in the Operation & Maintenance Manual.

Safe Operation Needs A Qualified Operator

For an operator to be qualified, he or she must not use drugs or alcoholic drinks which impair alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine and the attachment.

A Qualified Operator Must Do The Following:

Understand the Written Instructions, Rules and Regulations

- The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
- Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.

Have Training with Actual Operation

- Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
- The new operator must start in an area without bystanders and use all the controls until he or she can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.

Know the Work Conditions

- Know the weight of the materials being handled. Avoid exceeding the machine load capacities. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
- The operator must know any prohibited uses or work areas, for example, he or she needs to know about excessive slopes.
- Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *Call Before You Dig* Section of this manual.
- Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, respiratory equipment, hearing protection, Special Applications Kits or a Front Window Guard are required for some work. See your Bobcat dealer about Bobcat Safety equipment for your machine.

SI ATT-0509

MidWestTech | Bobcat 18 Hyd, 18 In., 24 Hyd, 24 In. Planer Operation & Maintenance Manu... Order the manual at mid-west-tech.com >