
Bobcat

LT102 TRENCHER

Operation & Maintenance Manual

S/N 233600101 & Above



Bobcat

6901226 (2–01)

Printed in U.S.A.

© Bobcat Company 2001

MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD iii
SAFETY vii
OPERATING INSTRUCTIONS 1
TRENCHER MAINTENANCE 31
SPECIFICATIONS 41

REFERENCE INFORMATION

Write the correct information for YOUR Trencher in the spaces below. Always use these numbers when referring to your Trencher.

Trencher Serial Number ..... _____

_____

_____

_____

NOTES: _____

_____

_____

_____

_____

_____

_____

_____

YOUR BOBCAT DEALER:

_____

ADDRESS:

_____

PHONE:

_____

Bobcat Company
P.O. Box 128
Gwinner, ND 58040–0128

Bobcat Company Europe
J. Huysmanslaan 59
B–1651 LOT
Belgium

MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690... Order the manual at mid-west-tech.com >

PARKING THE BOBCAT LOADER

Stop the Bobcat loader on level ground.

Lower the lift arms fully and put the trencher flat on the ground **[A]**.

Move the engine speed control lever to low engine RPM. Turn the key switch to the OFF position.

Engage the parking brake.

(Foot Pedal Controls) Move pedals until both lock.

(Mechanical Hand Controls) Move the hand controls until both lock.

(Advanced Hand Controls) Move the hand controls to the NEUTRAL POSITION to make sure that both lift and tilt functions are deactivated.

Unbuckle the seat belt. Remove the key from the switch to prevent operation of the loader by unauthorized personnel.



⚠ WARNING

Before you leave the operator's seat:

- **Lower the lift arms, put the attachment flat on the ground.**
- **Stop the engine.**
- **Engage the parking brake.**
- **Raise seat bar.**
- ***(Foot Pedal Controls)* Move pedals until both lock.**
- ***(Mechanical Hand Controls)* Move the hand controls until both lock.**
  The seat bar system must lock the lift and tilt controls in neutral when the seat bar is up. Service the system if hand controls do not lock correctly.
- ***(Advanced Hand Controls)* Move the hand controls to the NEUTRAL POSITION to make sure that both lift and tilt functions are deactivated.**
  The seat bar system must deactivate the lift and tilt control functions when the seat bar is up. Service the system if hand controls do not deactivate.


W-2323-0698

MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690... Order the manual at mid-west-tech.com >

INSPECTION (Cont'd)

Trencher Mount Inspection

Inspect the trencher mounting flange (Item 1) **[A]** and all welds on the trencher mount for wear and damage each time the trencher is removed from the loader.



X–Change Mount Inspection


Inspect the X–Change mount (Item 1) **[B]** and all welds for wear or damage each time the trencher is removed.



Chain Guide Inspection

Inspect the top and bottom chain guide (Item 1) **[C]** for wear and damage.

NOTE: The digging chain is removed for photo clarity.



MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690... Order the manual at mid-west-tech.com >

SPECIFICATIONS

ADDITIONAL PUBLICATIONS 46
HYDRAULIC SCHEMATIC 44
GLOSSARY OF HYDRAULIC SYMBOLS FOR ATTACHMENTS 43
SPECIFICATIONS 45

MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690...
Order the manual at mid-west-tech.com >

SAFETY INSTRUCTIONS

SAFETY IS THE OPERATOR'S RESPONSIBILITY

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

The Bobcat product and attachment are designed to give maximum safety; but no machine design can prevent operator error or carelessness.

The Bobcat product and attachment must be in good operating condition before use.

Check all of the items on the Bobcat Service Schedule Decal under the 8–10 hour column or as shown in the Operation & Maintenance Manual.

WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W–2001–1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I–2019–0284

WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W–2044–1285

SAFE OPERATION NEEDS A QUALIFIED OPERATOR *

A QUALIFIED OPERATOR MUST DO THE FOLLOWING:

- **UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS**
  - The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
  - Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.
- **HAVE TRAINING WITH ACTUAL OPERATION**
  - Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
  - The new operator must start in an area without bystanders and use all the controls until he can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.
  - Operator Training Courses are available from your Bobcat dealer in English and Spanish. They provide information for safe and efficient equipment operation. Safety videos are also available.
  - Service Safety Training Courses are available from your Bobcat dealer. They provide information for safe and correct service procedures.
- **KNOW THE WORK CONDITIONS**
  - Know the weight of the materials being handled. Avoid exceeding the Rated Operating Capacity of the machine. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
  - The operator must know any prohibited uses or work areas, for example, he needs to know about excessive slopes.
  - Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *SAFETY INSTRUCTIONS* Section of this manual.
  - Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, hearing protection or special applications kit are required for some work. See your dealer about Bobcat Safety equipment.

* For an operator be qualified, he must not use drugs or alcoholic drinks which impair his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

MidWestTech | Bobcat LT102 Trencher Operation & Maintenance Manual | Publication 690... Order the manual at mid-west-tech.com >