B200

Bobcat®

Operation & Maintenance Manual

S/N 570211001 & Above



An Ingersoll-Rand business

6901847 (2–03) Revised (4–03) (4)

Printed in U.S.A.

© Bobcat Company 2003

MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD iii
SAFETY ix
OPERATING INSTRUCTIONS 1
PREVENTIVE MAINTENANCE 37
SPECIFICATIONS 71

CALIFORNIA
PROPOSITION 65 WARNING
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat loader backhoe in the spaces below. Always use these numbers when referring to your Bobcat loader backhoe.

Loader Backhoe Serial Number . . . _____

_____

_____

_____

NOTES: _____

_____

_____

_____

_____

_____

_____

_____

YOUR LOADER DEALER: _____

ADDRESS: _____

PHONE: _____

Bobcat Company
P.O. Box 128
Gwinner, ND 58040–0128

Bobcat Company Europe
J. Huysmanslaan 59
B–1651 LOT
Belgium

MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

REGULAR MAINTENANCE ITEMS

6960214	ENGINE OIL FILTER
6680585	FUEL FILTER
6689016	AIR CLEANER FILTER
6961187	HYDROSTATIC FILTER
6662222	BATTERY
6563328	FLUID Hydraulic/Hydrostatic–5 Gallons (2–2.5 Gallon Containers)

12 Qts.	Gal.	2.5 Gal.	
6657199	6724558	6674204	MOTOR OIL 15W40 CE/SG
6657301	6724557	6674205	MOTOR OIL 10W30 CE/SG
6657303	6724559	6674206	MOTOR OIL 30 CE/SG


MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

HYDRAULIC CONTROLS (REAR) (Cont'd)

Stabilizer Control Levers

The left lever (Item 1) **[A]** controls the left stabilizer.


The right lever (Item 2) **[A]** controls the right stabilizer.



Pull the levers (Item 1 & 2) **[A]** back to raise both stabilizers **[B]**.



Push the levers (Item 1 & 2) **[A]** forward to lower both stabilizers **[C]**.



MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

ATTACHMENTS AND BUCKETS

NOTE: Warranty is void if non–approved attachments are used on the loader backhoe.

⚠ WARNING

Never use attachments or buckets which are not approved by Bobcat Company. Buckets and attachments for safe loads of specified densities are approved for each model. Unapproved attachments can cause injury or death.

W–2052–0500


The dealer can identify, for each model loader backhoe the attachments and buckets approved by Bobcat. The buckets and attachments are approved for Rated Operating Capacity and for secure fastening to the Bob–Tach.


The Rated Operating Capacity is determined by using a standard dirt bucket, and material of normal density, such as dirt or dry gravel. If longer buckets are used, the load center moves forward and reduces the Rated Operating Capacity. If very dense material is loaded, the volume must be reduced to prevent overloading.

Exceeding the Rated Operating Capacity **[A]** can cause the following problems:

- Steering the loader may be difficult.
- Tires will wear faster
- There will be a loss of stability.
- The life of the Bobcat loader backhoe will be reduced.

Use the correct size bucket for the type and density of material being handled **[B]**. For safe handling of materials and avoiding machine damage, the attachment (or bucket) should handle a full load without going over the Rated Operating Capacity for the loader backhoe. Partial loads make steering more difficult.





⚠ WARNING

AVOID INJURY OR DEATH

Do not exceed rated operating capacity. Excessive load can cause tipping or loss of control.

W–2053–0887

MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

BEFORE OPERATING THE BOBCAT LOADER BACKHOE

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W-2001-1285

The Bobcat loader backhoe and attachment must be in good operating condition before use.

Check all of the items on the Bobcat Service Schedule Decal under the 8–10 hour column or as shown in this Manual.

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

SAFE OPERATION NEEDS A QUALIFIED OPERATOR *

A QUALIFIED OPERATOR MUST DO THE FOLLOWING:

- **UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS**
  - The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
  - Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.

WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

- **HAVE TRAINING WITH ACTUAL OPERATION**
  - Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
  - The new operator must start in an area without bystanders and use all the controls until he can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.
- **KNOW THE WORK CONDITIONS**
  - Know the weight of the materials being handled. Avoid exceeding the Rated Operating Capacity of the machine. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
  - The operator must know any prohibited uses or work areas, for example, he needs to know about excessive slopes.
  - Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *SAFETY INSTRUCTIONS* Section of this manual.
  - Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, hearing protection or special applications kit are required for some work. See your dealer about Bobcat Safety equipment.

* For an operator to be qualified, he must not use drugs or alcoholic drinks which impair his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

MidWestTech | Bobcat B200 Backhoe Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >