VIBRATORY COMPACTOR BCA12S

Bobcat®

Operation & Maintenance Manual

Bobcat S/N 491611050 & Above



An IR Ingersoll-Rand business

Printed in U.S.A.

6902244 (12-02)

©Bobcat Company 2002

MidWestTech | Bobcat BCA12S Vibratory Compactor Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
INTRODUCTION	1
Procedure When Receiving the Machine	2
Identification Data	2
Machine Identification	3
Engine Identification	3
Instruction Manual Storage	4
General Information	4
Machine Description	5
Drums	5
Engine	5
Main Frame	6
Controls	6
Drum Water Spray System	6
Brakes	6
Serviceability	7
ROPS	7
Identification of Major Components	8
SAFETY	1
Be Aware of Safety Information	1-1
Understand Signal Words	1-1
Overview	1-3
Warnings	1-3
General	1-4
Selection and Qualification of Personnel	1-5
Organizational Measures	1-6
Pre-Start Inspection	1-8
Safety Instructions Governing Operation	1-9
Starting	1-11
Operating	1-11
Stopping	1-13
Maintenance	1-13

MidWestTech | Bobcat BCA12S Vibratory Compactor Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
SAFETY (CONT'D.)	
Warning of Special Dangers	1-18
Transporting and Towing - Recommissioning	1-19
Hazardous Substance Precaution	1-22
Safety Related Decals	1-24
U.S. Decals	1-25
SYMBOL IDENTIFICATION	2
Bobcat Machine Symbols	2-1
International Machine Symbols	2-2
OPERATING CONTROLS & INSTRUMENTS	3
Articulation Lock Bar	3-1
Choke	3-4
Emergency Stop Switch	3-4
Check Engine Light	3-5
Brake Test Switch	3-5
Park Brake Switch and Indicator	3-5
Horn	3-5
Steering Wheel	3-5
Hourmeter	3-6
Water Flow Control	3-6
Ignition Switch	3-6
Engine Speed Control (Throttle)	3-6
Propulsion Control Lever	3-7
Vibration On/Off Switch	3-7
Optional Equipment	3-8
Auto/Manual Water Pump Switch	3-8

MidWestTech | Bobcat BCA12S Vibratory Compactor Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
OPERATING INSTRUCTIONS	4
General Information	4-1
Pre-Start Checks and Verifications	4-2
Starting the Machine and Other Checks and Verifications	4-10
Operating the Machine	4-13
Operating Suggestions and Checks While Operating the Machine	4-13
Moving the Machine (Propulsion Control)	4-14
Using the Vibration Controls	4-15
Parking, Stopping, and Shutting Down the Machine	4-16
Parking the Machine	4-16
Stopping the Machine	4-16
Shutting Down the Machine	4-17
Daily Precautions After Work	4-17
Movement of Machine Between Work Sites	4-18
Loading the Machine Under Its Own Power (Drive On) for Transporting	4-18
Securing the Machine to the Transporter (Tie-Down)	4-19
Towing the Machine	4-20
Park Brake Manual Release	4-23
MAINTENANCE INSTRUCTIONS	5
General Maintenance Information	5-1
Instructions Prior to Conducting Maintenance Work	5-1
Handling Fluids and Oil, Fuel Filters	5-2

MidWestTech | Bobcat BCA12S Vibratory Compactor Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >