VIBRATORY
COMPACTORS
BCA14S

Bobcat®

Operation And Maintenance Manual

S/N 491711050 & Above



Bobcat

Printed in U.S.A.

6902245 (11-02)

©Bobcat Company 2002

MidWestTech | Bobcat BCA14S Vibratory Compactors Operation And Maintenance Manual... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

TITLE	SECTION
INTRODUCTION	1
Procedure When Receiving the Machine	2
Identification Data	2
Machine Identification	3
Engine Identification	3
Instruction Manual Storage	4
General Information	4
Machine Description	5
Drums	5
Engine	5
Main Frame	6
Controls	6
Drum Water Spray System	6
Brakes	6
Serviceability	7
ROPS	7
SAFETY	1-1
Be Aware of Safety Information	1-1
Understand Signal Words	1-1
Overview	1-3
Warnings	1-3

MidWestTech | Bobcat BCA14S Vibratory Compactors Operation And Maintenance Manual... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
SAFETY (CONT'D.)	1
General	1-4
Selection and Qualification of Personnel	1-4
Organizational Measures	1-5
Pre-Start Inspection	1-7
Safety Instructions Governing Operation	1-8
Starting	1-10
Operating	1-10
Stopping	1-12
Maintenance	1-12
Warning of Special Dangers	1-17
Transporting and Towing	
Recommissioning	1-18
Hazardous Substance Warning	1-20
Safety Related Decals	1-22
U.S. Decals	1-23
International Decals With Interpretation	1-26
SYMBOL IDENTIFICATION	2
International Machine Symbols	2-1
International Highway Symbols	2-2
OPERATING CONTROLS & INSTRUMENTS	3
Articulation Lock Bar	3-1
Water Selection Switch	3-6
Emergency Stop Switch	3-6
Check Engine Light	3-6
Brake Test Switch	3-7
Park Brake Switch	3-7
Horn	3-7

MidWestTech | Bobcat BCA14S Vibratory Compactors Operation And Maintenance Manual... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
OPERATING CONTROLS & INSTRUMENTS (CONT'D.)	
Steering Wheel	3-7
Hourmeter	3-7
Water Flow Control	3-7
Ignition Switch	3-7
Engine Speed Control	3-8
Propulsion Control Lever	3-8
Vibration On/Off Switch	3-9
Options	3-10
OPERATING INSTRUCTIONS	4
General Information	4-1
Pre-Start Checks and Verifications	4-2
Starting the Machine and Other Checks/Verifications	4-10
Operating the Machine	4-15
Moving The Machine (Propulsion Control)	4-16
Using Vibration Controls	4-17
Parking, Stopping, and Shutting Down the Machine	4-22
Parking	4-22
Stopping the Machine	4-22
Shutting Down the Machine	4-24
Daily Precautions After Work	4-25
Mounting and Dismounting Attachments	4-25
Movement of Machine Between Worksites	4-25
Securing The Machine To The Transporter (Tie-Down)	4-26
Towing the Machine	4-27

MidWestTech | Bobcat BCA14S Vibratory Compactors Operation And Maintenance Manual... Order the manual at mid-west-tech.com >