VIBRATORY
COMPACTORS
BCA24

Bobcat®

Operation And Maintenance Manual

S/N 491911050 & Above



Bobcat

Printed in U.S.A.

6902246 (11-02)

©Bobcat Company 2002

MidWestTech | Bobcat BCA24 Vibratory Compactors Operation And Maintenance Manual |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

TITLE	SECTION
INTRODUCTION	1
Procedure When Receiving the Machine	2
Identification Data	2
Machine Identification	3
Engine Identification	4
Instruction Manual Storage	4
General Information	5
Machine Description	5
Drums	5
Engine	6
Main Frame	6
Controls	7
Drum Water Spray System	7
Brakes	8
Serviceability	8
ROPS	9
SAFETY	1-1
Be Aware of Safety Information	1-1
Understand Signal Words	1-1
Overview	1-3
Warnings	1-3

MidWestTech | Bobcat BCA24 Vibratory Compactors Operation And Maintenance Manual |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
SAFETY (CONT'D.)	1
General	1-4
Selection and Qualification of Personnel	1-5
Organizational Measures	1-6
Pre-Start Inspection	1-7
Safety Instructions Governing Operation	1-8
Starting	1-10
Operating	1-11
Stopping	1-12
Maintenance	1-13
Warning of Special Dangers	1-17
Transporting and Towing	
Recommissioning	1-18
Hazardous Substance Precaution	1-20
Safety Related Decals	1-23
U.S. Decals	1-24
International Decals With Interpretation	1-27
SYMBOL IDENTIFICATION	2
Bobcat Symbols	2-1
International Symbols	2-2
OPERATING CONTROLS & INSTRUMENTS	3
Articulation Lock Bar	3-1
Auto Vibration Switch	3-5
Drum Selector Switch	3-5
Auto/Manual Water Pump Switch	3-5
Emergency Stop Switch	3-5
Steering Wheel	3-6
Hourmeter	3-6
Indicator Lights	3-6

MidWestTech | Bobcat BCA24 Vibratory Compactors Operation And Maintenance Manual |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	SECTION
OPERATING CONTROLS & INSTRUMENTS (CONT'D.)	
Brake Test Switch	3-6
Park Brake Switch	3-6
Horn	3-7
Ignition Switch	3-7
Water Flow Control	3-7
Engine Speed Control (Throttle)	3-7
Propulsion Control Lever	3-8
Vibration On/Off Switch	3-8
Suspension Seat	3-9
Options	3-10
OPERATING INSTRUCTIONS	4
General Information	4-1
Pre-Start Checks and Verifications	4-2
Starting the Machine and Other Checks/Verifications	4-10
Operating the Machine	4-15
Using Vibration Controls	4-18
Parking, Stopping and Shutting Down The Machine	4-22
Parking	4-22
Stopping the Machine	4-23
Shutting Down the Machine	4-24
Daily Precautions After Work	4-25
Mounting and Dismounting Attachments	4-25
Movement of Machine Between Worksites	4-25
Loading the machine under its own power (drive on) for transporting	4-26
Securing the machine to the transporter (Tie-down)	4-26
Towing the Machine	4-27

MidWestTech | Bobcat BCA24 Vibratory Compactors Operation And Maintenance Manual |... Order the manual at mid-west-tech.com >