
T190
TURBO

T190
TURBO
HIGH FLOW

Bobcat®

Operation & Maintenance Manual

S/N 527011001 & Above



EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS)

6902692 (6-04) Revised (12-06) (4)

Ingersoll Rand
Compact Vehicle Technologies

Printed in U.S.A.

©Bobcat Company 2006

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD III

SAFETY XI

OPERATING INSTRUCTIONS OI-1

PREVENTIVE MAINTENANCE PM-1

SYSTEM SETUP & ANALYSIS SA-1

MACHINE SIGN TRANSLATIONS MST-1

SPECIFICATIONS SPEC-1

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat Loader in the spaces below. Always use these numbers when referring to your Bobcat Loader.

Loader Serial Number _____

Engine Serial Number _____

_____

_____

NOTES:

_____

_____

_____

_____

_____

YOUR BOBCAT DEALER:

_____

ADDRESS:

_____

PHONE:

_____

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Dréve Richelle 167
B-1410 WATERLOO
Belgium

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Bobcat Loader. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR LOADER. If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001:2000 CERTIFIED V

REGULAR MAINTENANCE ITEMS V

MOTOR OIL V

SERIAL NUMBER LOCATIONS VI
Engine Serial Number VI
Loader Serial Number VI

DELIVERY REPORT VI


MACHINE IDENTIFICATION VII

FEATURES, ACCESSORIES AND ATTACHMENTS VIII
Attachments IX
Buckets Available IX
Options and Accessories VIII
Standard Items VIII

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

Advanced Control System (ACS) in HAND Control Mode

Figure OI-18



Lift Arm Operation - **(Left Hand Lever)**

Move the lever outward (Item 1) **[Figure OI-18]** to raise the lift arms.

Move the lever inward (Item 2) **[Figure OI-18]** to lower the lift arms.

Lift Arm Float Position - **(Left Hand Lever)**

Press and hold the Float Button (Item 3) **[Figure OI-18]** while the lever is in neutral. Move the lever to lift arm down position (Item 2) **[Figure OI-18]**, then release the button.

Press Float Button again or move the lever to lift arm up position (Item 3) **[Figure OI-18]**.

Use the float position of the lift arms to level loose material while driving backward.

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

TRANSPORTING THE BOBCAT LOADER

Loading Onto Transport Vehicle


⚠ WARNING

Adequately designed ramps of sufficient strength are needed to support the weight of the machine when loading onto a transport vehicle. Wood ramps can break and cause personal injury.

W-2058-0494

Be sure the transport and towing vehicles are of adequate size and capacity. (See LOADER SPECIFICATIONS (T190) on Page SPEC-3.)

Figure OI-75




A loader with an empty bucket or no attachment must be loaded backward onto the transport vehicle **[Figure OI-75]**.

The rear of the trailer must be blocked or supported (Item 1) **[Figure OI-75]** when loading or unloading the loader to prevent the front end of the trailer from raising up.

Fastening To Transport Vehicle

Figure OI-76




Use the following procedure to fasten the Bobcat Loader to the transport vehicle to prevent the loader from moving during sudden stops or when going up or down slopes **[Figure OI-76]**.

- Lower the bucket or attachment to the floor.
- Stop the engine.
- Engage the parking brake.
- Install chains at the front and rear loader tie down positions (Inset) **[Figure OI-76]**.
- Fasten each end of the chain to the transport vehicle.

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

Replacing Oil And Filter (Cont'd)

Figure PM-42



Remove the oil filter (Item 1) **[Figure PM-42]**.

Clean the filter housing surface.

Put clean oil on the new oil filter gasket.


Install the filter and hand tighten.

Install and tighten the drain plug.

Open the rear grill.

Remove the fill cap (Item 2) **[Figure PM-42]**.

Figure PM-43



Put oil in the engine. (See Capacity on Page SPEC-4.) **[Figure PM-43]** (See Oil Chart **[Figure PM-41]**.)

Start the engine and let it run for several minutes.

Stop the engine and check for leaks at the oil filter.

Remove the dipstick and check the oil level.

Add oil as needed if it is not at the top mark (Item 1) **[Figure PM-43]** on the dipstick.

Install the dipstick and close the rear door.

⚠ WARNING

Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. Failure to use care around combustibles can cause explosion or fire which can result in injury or death.

W-2103-1285

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >

Safe Operation Is The Operator's Responsibility

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W-2001-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

The Bobcat Loader and attachment must be in good operating condition before use.

Check all of the items on the Bobcat Service Schedule Decal under the 8-10 hour column or as shown in the Operation & Maintenance Manual.

Safe Operation Needs A Qualified Operator

For an operator to be qualified, he or she must not use drugs or alcoholic drinks which impair alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine.

A Qualified Operator Must Do The Following:

Understand the Written Instructions, Rules and Regulations

- The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
- Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.

Have Training with Actual Operation

- Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
- The new operator must start in an area without bystanders and use all the controls until he or she can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.
- Operator Training Courses are available from your Bobcat dealer in English and Spanish. They provide information for safe and efficient equipment operation. Safety videos are also available.
- Service Safety Training Courses are available from your Bobcat dealer. They provide information for safe and correct service procedures.

Know the Work Conditions

- Know the weight of the materials being handled. Avoid exceeding the Rated Operating Capacity (R.O.C.) of the machine. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of the load if handling dense material.
- The operator must know any prohibited uses or work areas, for example, he or she needs to know about excessive slopes.
- Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the **Before Operation** Section of this manual.
- Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, hearing protection or Special Applications Kits are required for some work. See your Bobcat dealer about Bobcat Safety Equipment for your model.

SI SSL-0206

MidWestTech | Bobcat T190 Turbo, T190 Turbo High Flow Compact Track Loader Operation... Order the manual at mid-west-tech.com >