
BL-370

B Series

Ingersoll-Rand

Operation & Maintenance Manual

S/N 573211001 & Above



6903706
22535785 (10-04) Revised (5-05) (2)

Printed in U.S.A.

© Ingersoll-Rand 2004

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD III

SAFETY XI

OPERATING INSTRUCTIONS OI-1

PREVENTIVE MAINTENANCE PM-1

MACHINE SIGN TRANSLATIONS 1

SPECIFICATIONS SPEC-1

REFERENCE INFORMATION

Write the correct information for YOUR Ingersoll-Rand Backhoe Loader in the spaces below. Always use these numbers when referring to your Ingersoll-Rand Backhoe Loader.

CALIFORNIA
PROPOSITION 65 WARNING

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

Backhoe Loader Serial Number _____

Engine Serial Number _____

NOTES:

_____

_____

_____

YOUR Ingersoll-Rand® DEALER:

_____

ADDRESS:

_____

PHONE:

_____

Ingersoll-Rand Company
Utility Equipment
501 Sanford Avenue
Mocksville, NC 27028

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Ingersoll-Rand Backhoe Loader. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR BACKHOE LOADER. If you have any questions, see your Ingersoll-Rand dealer.

This manual may illustrate backhoe loaders with additional options and accessories not installed on your backhoe loader.

BACKHOE LOADER IDENTIFICATION VIII

BACKHOE LOADER SERIAL NUMBER. VII

DELIVERY REPORT. VII

ENGINE SERIAL NUMBER VII

FEATURES, OPTIONS, ACCESSORIES AND ATTACHMENTS . . . IX
- Attachments IX
- Backhoe Features IX
- Loader Features. IX
- Machine Features IX
- Options and Accessories IX

LUBRICANTS V

REGULAR MAINTENANCE ITEMS V

SERIAL NUMBER LOCATION VII

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

REGULAR MAINTENANCE ITEMS

	ENGINE OIL FILTER 81086522		HYDRAULIC FILTER 15395858
	FUEL FILTER 81046088		BATTERY 15396229
	FUEL FILTER (In- Line) 80988298		
	AIR CLEANER FILTER (Primary) 81039604		
	AIR CLEANER FILTER (Secondary) 81039612		

LUBRICANTS

	1 gal./3.8 liters	5 gals/19.0 liters	55 gals/208.2 liters
Engine Oil	54480918	36875938	36866903

	2.5 gals/9.5 liters	5 gals/19.0 liters
Hydraulic Oil	22526651	22526669

Grease (tube)	22530117

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

Backhoe Control Levers (Cont'd)

LEVER NO. 2 **[Figure OI-33]** - Arm and Bucket

To move the arm out, push the lever forward (Item 1) **[Figure OI-33]**.


To move the arm in, pull the lever backward (Item 3) **[Figure OI-33]**.

To curl the bucket (fill the bucket), move the lever to the left (Item 4) **[Figure OI-33]**.

To empty the bucket, move the lever to the right (Item 5) **[Figure OI-33]**.

NOTE: If you release the arm and bucket control lever, the lever will return to the neutral position.

Figure OI-33



MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

BACKHOE LOADER SPECIFICATIONS (CONT'D)

Loader Performance

*Loader Rated Operating Capacity (Per ISO 14397)	3150 lb. (1429 kg)
Loader Tipping Load (ISO)	6300 lb. (2858 kg)
Operating Weight	9260 lb. (4200 kg)
Travel Speed	10.9 MPH (17,5 Km/H)
Bucket Capacity (Loader)	17.7 ft^3 (0.5 m^3)
Loader Breakout	8430 lb. (3825 kg)

*Determined with equipment shown (backhoe in the center transport position).

Backhoe Performance

Std. Backhoe Bucket Width	16 in. (400 mm)
Diggingforce Bucket Dipper	 6821 lb. (3094 kg) 4627 lb. (2099 kg)

Controls

Hydraulics (Loader and Backhoe)	Hand Operated Levers
Auxiliary Hydraulics	Hand Operated Lever for Loader, Button Activated for Backhoe
Parking Brake	Button Activated Spring Applied Pressure Release (SAPR)
Travel Direction Control	Hand Operated Lever (FNR)

Engine

Make/Model	Kubota/V2203-MDI
Fuel/Cooling	Diesel/Liquid (Antifreeze Mixture)
Horsepower (SAE Net)	48.0 HP (36 kW) @ 3000 RPM
Displacement	134.07 ci (2,197 L)
Number Of Cylinders	Four
Lubrication	Pressure System with Filter
Air Cleaner	Dry replaceable cartridge
Equipped with spark arrestor exhaust system	

Hydraulic System

Hydraulic Pump	Gear Driven
Hydraulic Cooling	Cooler (part of radiator)

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

Safe Operation Is The Operator's Responsibility

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W-2001-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

The Ingersoll-Rand Backhoe Loader and attachment must be in good operating condition before use.

Check all of the items on the Service Schedule Decal under the 8-10 hour column or as shown in the Operation & Maintenance Manual.

Safe Operation Needs A Qualified Operator

For an operator to be qualified, he or she must not use drugs or alcoholic drinks which impair alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine.

A Qualified Operator Must Do The Following:

Understand the Written Instructions, Rules and Regulations

- The written instructions from Ingersoll-Rand include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
- Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.

Have Training with Actual Operation

- Operator training must consist of a demonstration and verbal instruction. This training is given by your Ingersoll-Rand dealer before the product is delivered.
- The new operator must start in an area without bystanders and use all the controls until he or she can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.
- Operator Training Courses are available from your Ingersoll-Rand dealer in English and Spanish. They provide information for safe and efficient equipment operation. Safety videos are also available.

Know the Work Conditions

- Know the weight of the materials being handled. Avoid exceeding the Rated Operating Capacity (R.O.C.) of the loader or the Rated Lift Capacity of the backhoe. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
- The operator must know any prohibited uses or work areas, for example, he or she needs to know about excessive slopes.
- Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the **Before Operation** Section of this manual.
- Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses or hearing protection are required for some work. See your Ingersoll-Rand dealer about available Safety Equipment.

MidWestTech | Bobcat BL-370 B Series Backhoe Loader Operation & Maintenance Manual... Order the manual at mid-west-tech.com >